

## **Część 1. Lista błędów EOBD/OBD2 wraz z opisami wersja polska - okrojona.**

### **Część 2. Wersja angielska zawiera większość kodów błędów**

**wyszukiwanie błędów link - <http://kody.fordtuning.pl/?all>**

Kody błędów OBD2 sklasyfikowano w/g normy J 2012 która zakłada pięciodziesiętny system kodowania:

Pierwszy znak opisuje z jakimi elementami pojazdu związana jest usterka. Poszczególne litery oznaczają:

- P - układ napędowy,
- B - karoseria,
- C - układ jezdny,
- U - komunikacja sieciowa.

Drugi znak związany jest z nazwą organizacji odpowiedzialnej za definicję kodu. Dla Stowarzyszenia Inżynierów Samochodowych (SAE), przeznaczono liczbę 0, natomiast dla indywidualnych producentów liczbę 1. Znak ten jest bardzo ważny, ponieważ przekazuje informację czy kod dotyczy wszystkich producentów (0) czy związany jest ze specyficzną konstrukcją pojazdu (1).

Trzeci znak wskazuje podgrupę związaną z funkcjami samochodu:

- 0 - usterka układu elektrycznego,
- 1, 2 - usterka układu zasilania paliwem lub powietrzem,
- 3 - usterka związana ze zjawiskiem wypadania zapłonów,
- 4 - usterka związana z emisją spalin,
- 5 - usterka dotycząca sterowania prędkością obrotową biegu jałowego,
- 6 - usterka związana z układami wyjścia i wejścia centralnej jednostki sterującej,
- 7 - usterka związana z przekazywaniem momentu obrotowego,
- 8 - usterki dotyczące elementów pojazdu nie sterowanych elektrycznie.

Kolejne znaki w kodzie oznaczają numer błędu wcześniej zdefiniowanej grupy i podgrupy elementów samochodu.

Przykładowo kod P0308 oznacza:

- P - usterka związana z układem napędowym,
- 0 - błąd określony przez normę SAE,
- 3 - usterka związana z układem zapłonowym,
- 08 - brak zapłonu w cylindrze numer 8.

### *Kody błędów*

- B0100,"Poduszka powietrzna kierowcy - usterka"
- B0101,"Poduszka powietrzna kierowcy - sygnał poza zakresem/wydajność"
- B0102,"Poduszka powietrzna kierowcy - niski sygnał wejściowy"
- B0103,"Poduszka powietrzna kierowcy - wysoki sygnał wejściowy"
- B0105,"Poduszka powietrzna pasażera - usterka"
- B0106,"Poduszka powietrzna pasażera - sygnał poza zakresem/wydajność"
- B0107,"Poduszka powietrzna pasażera - niski sygnał wejściowy"
- B0108,"Poduszka powietrzna pasażera - wysoki sygnał wejściowy"
- B0110,"Boczna poduszka powietrzna kierowcy - usterka"
- B0111,"Boczna poduszka powietrzna kierowcy - sygnał poza zakresem/wydajność"
- B0112,"Boczna poduszka powietrzna kierowcy - niski sygnał wejściowy"
- B0113,"Boczna poduszka powietrzna kierowcy - wysoki sygnał wejściowy"
- B0115,"Boczna poduszka powietrzna pasażera - usterka"
- B0116,"Boczna poduszka powietrzna pasażera - sygnał poza zakresem/wydajność"
- B0117,"Boczna poduszka powietrzna pasażera - niski sygnał wejściowy"
- B0118,"Boczna poduszka powietrzna pasażera - wysoki sygnał wejściowy"
- B0120,"Obwód kontrolny przełącznika pasa bezpieczeństwa #1 - usterka"
- B0121,"Obwód kontrolny przełącznika pasa bezpieczeństwa #1 - sygnał poza zakresem/wydajność"
- B0122,"Obwód kontrolny przełącznika pasa bezpieczeństwa #1 - niski sygnał wejściowy"
- B0123,"Obwód kontrolny przełącznika pasa bezpieczeństwa #1 - wysoki sygnał wejściowy"
- B0125,"Obwód kontrolny przełącznika pasa bezpieczeństwa #2 - usterka"

B0126,"Obwód kontrolny przełącznika pasa bezpieczeństwa #2 - sygnał poza zakresem/wydajność"  
B0127,"Obwód kontrolny przełącznika pasa bezpieczeństwa #2 - niski sygnał wejściowy"  
B0128,"Obwód kontrolny przełącznika pasa bezpieczeństwa #2 - wysoki sygnał wejściowy"  
B0130,"Obwód powrotu pasa bezpieczeństwa #1 - usterka"  
B0131,"Obwód powrotu pasa bezpieczeństwa #1 - sygnał poza zakresem/wydajność"  
B0132,"Obwód powrotu pasa bezpieczeństwa #1 - niski sygnał wejściowy"  
B0133,"Obwód powrotu pasa bezpieczeństwa #1 - wysoki sygnał wejściowy"  
B0135,"Obwód powrotu pasa bezpieczeństwa #2 - usterka"  
B0136,"Obwód powrotu pasa bezpieczeństwa #2 - sygnał poza zakresem/wydajność"  
B0137,"Obwód powrotu pasa bezpieczeństwa #2 - niski sygnał wejściowy"  
B0138,"Obwód powrotu pasa bezpieczeństwa #2 - wysoki sygnał wejściowy"  
B0300,"Obwód wentylatora chłodzącego #1 - usterka"  
B0301,"Obwód wentylatora chłodzącego #1 - sygnał poza zakresem/wydajność"  
B0302,"Obwód wentylatora chłodzącego #1 - niski sygnał wejściowy"  
B0303,"Obwód wentylatora chłodzącego #1 - wysoki sygnał wejściowy"  
B0305,"Obwód wentylatora chłodzącego #2 - usterka"  
B0306,"Obwód wentylatora chłodzącego #2 - sygnał poza zakresem/wydajność"  
B0307,"Obwód wentylatora chłodzącego #2 - niski sygnał wejściowy"  
B0308,"Obwód wentylatora chłodzącego #2 - wysoki sygnał wejściowy"  
B0310,"Obwód sprzęgła klimatyzacji (A/C) - usterka"  
B0311,"Obwód sprzęgła klimatyzacji (A/C) - sygnał poza zakresem/wydajność"  
B0312,"Obwód sprzęgła klimatyzacji (A/C) - niski sygnał wejściowy"  
B0313,"Obwód sprzęgła klimatyzacji (A/C) - wysoki sygnał wejściowy"  
B0315,"Obwód ciśnienia #1 klimatyzacji (A/C) - usterka"  
B0316,"Obwód ciśnienia #1 klimatyzacji (A/C) - sygnał poza zakresem/wydajność"  
B0317,"Obwód ciśnienia #1 klimatyzacji (A/C) - niski sygnał wejściowy"  
B0318,"Obwód ciśnienia #1 klimatyzacji (A/C) - wysoki sygnał wejściowy"  
B0320,"Obwód ciśnienia #2 klimatyzacji (A/C) - usterka"  
B0321,"Obwód ciśnienia #2 klimatyzacji (A/C) - sygnał poza zakresem/wydajność"  
B0322,"Obwód ciśnienia #2 klimatyzacji (A/C) - niski sygnał wejściowy"  
B0323,"Obwód ciśnienia #2 klimatyzacji (A/C) - wysoki sygnał wejściowy"  
B0325,"Sygnał wzorcowy ciśnienia klimatyzacji (A/C) - usterka"  
B0326,"Sygnał wzorcowy ciśnienia klimatyzacji (A/C) - sygnał poza zakresem/wydajność"  
B0327,"Sygnał wzorcowy ciśnienia klimatyzacji (A/C) - niski sygnał wejściowy"  
B0328,"Sygnał wzorcowy ciśnienia klimatyzacji (A/C) - wysoki sygnał wejściowy"  
B0330,"Czujnik temp. powietrza zewnętrznego - usterka"  
B0331,"Czujnik temp. powietrza zewnętrznego - sygnał poza zakresem/wydajność"  
B0332,"Czujnik temp. powietrza zewnętrznego - niski sygnał wejściowy"  
B0333,"Czujnik temp. powietrza zewnętrznego - wysoki sygnał wejściowy"  
B0335,"Czujnik #1 temp. powietrza wewnętrznego - usterka"  
B0336,"Czujnik #1 temp. powietrza wewnętrznego - sygnał poza zakresem/wydajność"  
B0337,"Czujnik #1 temp. powietrza wewnętrznego - niski sygnał wejściowy"  
B0338,"Czujnik #1 temp. powietrza wewnętrznego - wysoki sygnał wejściowy"  
B0340,"Czujnik #2 temp. powietrza wewnętrznego - usterka"  
B0341,"Czujnik #2 temp. powietrza wewnętrznego - sygnał poza zakresem/wydajność"  
B0342,"Czujnik #2 temp. powietrza wewnętrznego - niski sygnał wejściowy"  
B0343,"Czujnik #2 temp. powietrza wewnętrznego - wysoki sygnał wejściowy"  
B0345,"Czujnik #1 ładowania słonecznego - usterka"  
B0346,"Czujnik #1 ładowania słonecznego - sygnał poza zakresem/wydajność"  
B0347,"Czujnik #1 ładowania słonecznego - niski sygnał wejściowy"  
B0348,"Czujnik #1 ładowania słonecznego - wysoki sygnał wejściowy"  
B0350,"Czujnik #2 ładowania słonecznego - usterka"  
B0351,"Czujnik #2 ładowania słonecznego - sygnał poza zakresem/wydajność"  
B0352,"Czujnik #2 ładowania słonecznego - niski sygnał wejściowy"  
B0353,"Czujnik #2 ładowania słonecznego - wysoki sygnał wejściowy"  
B0355,"Silnik dmuchawy #1, obwód prędkości - usterka"  
B0356,"Silnik dmuchawy #1, obwód prędkości - sygnał poza zakresem/wydajność"  
B0357,"Silnik dmuchawy #1, obwód prędkości - niski sygnał wejściowy"  
B0358,"Silnik dmuchawy #1, obwód prędkości - wysoki sygnał wejściowy"  
B0360,"Silnik dmuchawy #1, obwód zasilania - usterka"

B0361,"Silnik dmuchawy #1, obwód zasilania - sygnał poza zakresem/wydajność"  
B0362,"Silnik dmuchawy #1, obwód zasilania - niski sygnał wejściowy"  
B0363,"Silnik dmuchawy #1, obwód zasilania - wysoki sygnał wejściowy"  
B0365,"Silnik dmuchawy #1, obwód masy - usterka"  
B0366,"Silnik dmuchawy #1, obwód masy - sygnał poza zakresem/wydajność"  
B0367,"Silnik dmuchawy #1, obwód masy - niski sygnał wejściowy"  
B0368,"Silnik dmuchawy #1, obwód masy - wysoki sygnał wejściowy"  
B0370,"Czujnik temp. po wysokiej stronie klimatyzacji (A/C) - usterka"  
B0371,"Czujnik temp. po wysokiej stronie klimatyzacji (A/C) - sygnał poza zakresem/wydajność"  
B0372,"Czujnik temp. po wysokiej stronie klimatyzacji (A/C) - niski sygnał wejściowy"  
B0373,"Czujnik temp. po wysokiej stronie klimatyzacji (A/C) - wysoki sygnał wejściowy"  
B0375,"Czujnik temp. wlotu parownika klimatyzacji (A/C) - usterka"  
B0376,"Czujnik temp. wlotu parownika klimatyzacji (A/C) - sygnał poza zakresem/wydajność"  
B0377,"Czujnik temp. wlotu parownika klimatyzacji (A/C) - niski sygnał wejściowy"  
B0378,"Czujnik temp. wlotu parownika klimatyzacji (A/C) - wysoki sygnał wejściowy"  
B0380,"Klimatyzacja (A/C) - podciśnienie czynnika chłodzącego"  
B0381,"Klimatyzacja (A/C) - nadciśnienie czynnika chłodzącego"  
B0400,"Kontrola przepływu powietrza #1 - odszraniacz - usterka"  
B0401,"Kontrola przepływu powietrza #1 - odszraniacz - sygnał poza zakresem/wydajność"  
B0402,"Kontrola przepływu powietrza #1 - odszraniacz - niski sygnał wejściowy"  
B0403,"Kontrola przepływu powietrza #1 - odszraniacz - wysoki sygnał wejściowy"  
B0405,"Kontrola przepływu powietrza #2 - podgrzewacz - usterka"  
B0406,"Kontrola przepływu powietrza #2 - podgrzewacz - sygnał poza zakresem/wydajność"  
B0407,"Kontrola przepływu powietrza #2 - podgrzewacz - niski sygnał wejściowy"  
B0408,"Kontrola przepływu powietrza #2 - podgrzewacz - wysoki sygnał wejściowy"  
B0410,"Kontrola przepływu powietrza #3 - (blend) - usterka"  
B0411,"Kontrola przepływu powietrza #3 - (blend) - sygnał poza zakresem/wydajność"  
B0412,"Kontrola przepływu powietrza #3 - (blend) - niski sygnał wejściowy"  
B0413,"Kontrola przepływu powietrza #3 - (blend) - wysoki sygnał wejściowy"  
B0415,"Kontrola przepływu powietrza #4 - odpowietrznik - usterka"  
B0416,"Kontrola przepływu powietrza #4 - odpowietrznik - sygnał poza zakresem/wydajność"  
B0417,"Kontrola przepływu powietrza #4 - odpowietrznik - niskie wejście"  
B0418,"Kontrola przepływu powietrza #4 - odpowietrznik - wysokie wejście"  
B0420,"Kontrola przepływu powietrza #5 - A/C - usterka"  
B0421,"Kontrola przepływu powietrza #5 - A/C - sygnał poza zakresem/wydajność"  
B0422,"Kontrola przepływu powietrza #5 - A/C - niski sygnał wejściowy"  
B0423,"Kontrola przepływu powietrza #5 - A/C - wysoki sygnał wejściowy"  
B0425,"Kontrola przepływu powietrza #6 - recyrkulacja - usterka"  
B0426,"Kontrola przepływu powietrza #6 - recyrkulacja - sygnał poza zakresem/wydajność"  
B0427,"Kontrola przepływu powietrza #6 - recyrkulacja - niski sygnał wejściowy"  
B0428,"Kontrola przepływu powietrza #6 - recyrkulacja - wysoki sygnał wejściowy"  
B0430,"Obwód odszraniania tylnej szyby - usterka"  
B0431,"Obwód odszraniania tylnej szyby - sygnał poza zakresem/wydajność"  
B0432,"Obwód odszraniania tylnej szyby - niski sygnał wejściowy"  
B0433,"Obwód odszraniania tylnej szyby - wysoki sygnał wejściowy"  
B0435,"Obwód ustawienia klimatyzacji (A/C) - usterka"  
B0436,"Obwód ustawienia klimatyzacji (A/C) - sygnał poza zakresem/wydajność"  
B0437,"Obwód ustawienia klimatyzacji (A/C) - niski sygnał wejściowy"  
B0438,"Obwód ustawienia klimatyzacji (A/C) - wysoki sygnał wejściowy"  
B0440,"Obwód sprzężenia zwrotnego sterowania głowicy #1 - usterka"  
B0441,"Obwód sprzężenia zwrotnego sterowania głowicy #1 - sygnał poza zakresem/wydajność"  
B0442,"Obwód sprzężenia zwrotnego sterowania głowicy #1 - niski sygnał wejściowy"  
B0443,"Obwód sprzężenia zwrotnego sterowania głowicy #1 - wysoki sygnał wejściowy"  
B0445,"Obwód sprzężenia zwrotnego sterowania głowicy #2 - usterka"  
B0446,"Obwód sprzężenia zwrotnego sterowania głowicy #2 - sygnał poza zakresem/wydajność"  
B0447,"Obwód sprzężenia zwrotnego sterowania głowicy #2 - niski sygnał wejściowy"  
B0448,"Obwód sprzężenia zwrotnego sterowania głowicy #2 - wysoki sygnał wejściowy"  
B0500,"Kierunkowskaz prawy - usterka"  
B0501,"Kierunkowskaz prawy - sygnał poza zakresem/wydajność"  
B0502,"Kierunkowskaz prawy - niski sygnał wejściowy"

B0503,"Kierunkowskaz prawy - wysoki sygnał wejściowy"  
B0505,"Kierunkowskaz lewy - usterka"  
B0506,"Kierunkowskaz lewy - sygnał poza zakresem/wydajność"  
B0507,"Kierunkowskaz lewy - niski sygnał wejściowy"  
B0508,"Kierunkowskaz lewy - wysoki sygnał wejściowy"  
B0510,"Wskaźniki świateł przednich - usterka"  
B0511,"Wskaźniki świateł przednich - sygnał poza zakresem/wydajność"  
B0512,"Wskaźniki świateł przednich - niski sygnał wejściowy"  
B0513,"Wskaźniki świateł przednich - wysoki sygnał wejściowy"  
B0515,"Obwód prędkościomierza - usterka"  
B0516,"Obwód prędkościomierza - sygnał poza zakresem/wydajność"  
B0517,"Obwód prędkościomierza - niski sygnał wejściowy"  
B0518,"Obwód prędkościomierza - wysoki sygnał wejściowy"  
B0520,"Obwód obrotomierza - usterka"  
B0521,"Obwód obrotomierza - sygnał poza zakresem/wydajność"  
B0522,"Obwód obrotomierza - niski sygnał wejściowy"  
B0523,"Obwód obrotomierza - wysoki sygnał wejściowy"  
B0525,"Obwód wskaźnika temperatury - usterka"  
B0526,"Obwód wskaźnika temperatury - sygnał poza zakresem/wydajność"  
B0527,"Obwód wskaźnika temperatury - niski sygnał wejściowy"  
B0528,"Obwód wskaźnika temperatury - wysoki sygnał wejściowy"  
B0530,"Wskaźnik poziomu paliwa - usterka"  
B0531,"Wskaźnik poziomu paliwa - sygnał poza zakresem/wydajność"  
B0532,"Wskaźnik poziomu paliwa - niski sygnał wejściowy"  
B0533,"Wskaźnik poziomu paliwa - wysoki sygnał wejściowy"  
B0535,"Obwód turbodoładowania - usterka"  
B0536,"Obwód turbodoładowania - sygnał poza zakresem/wydajność"  
B0537,"Obwód turbodoładowania - niski sygnał wejściowy"  
B0538,"Obwód turbodoładowania - wysoki sygnał wejściowy"  
B0540,"Wskaźnik mocowania pasa bezpieczeństwa - usterka"  
B0541,"Wskaźnik mocowania pasa bezpieczeństwa - sygnał poza zakresem/wydajność"  
B0542,"Wskaźnik mocowania pasa bezpieczeństwa - niski sygnał wejściowy"  
B0543,"Wskaźnik mocowania pasa bezpieczeństwa - wysoki sygnał wejściowy"  
B0545,"Wskaźnik drzwi niezamkniętych #1 - usterka"  
B0546,"Wskaźnik drzwi niezamkniętych #1 - sygnał poza zakresem/wydajność"  
B0547,"Wskaźnik drzwi niezamkniętych #1 - niski sygnał wejściowy"  
B0548,"Wskaźnik drzwi niezamkniętych #1 - wysoki sygnał wejściowy"  
B0550,"Wskaźnik drzwi niezamkniętych #2 - usterka"  
B0551,"Wskaźnik drzwi niezamkniętych #2 - sygnał poza zakresem/wydajność"  
B0552,"Wskaźnik drzwi niezamkniętych #2 - niski sygnał wejściowy"  
B0553,"Wskaźnik drzwi niezamkniętych #2 - wysoki sygnał wejściowy"  
B0555,"Wskaźnik hamulca - usterka"  
B0556,"Wskaźnik hamulca - sygnał poza zakresem/wydajność"  
B0557,"Wskaźnik hamulca - niski sygnał wejściowy"  
B0558,"Wskaźnik hamulca - wysoki sygnał wejściowy"  
B0560,"Lampka kontrolna poduszki powietrznej #1 - usterka"  
B0561,"Lampka kontrolna poduszki powietrznej #1 - sygnał poza zakresem/wydajność"  
B0562,"Lampka kontrolna poduszki powietrznej #1 - niski sygnał wejściowy"  
B0563,"Lampka kontrolna poduszki powietrznej #1 - wysoki sygnał wejściowy"  
B0565,"Obwód zabezpieczenia informacji - usterka"  
B0566,"Obwód zabezpieczenia informacji - sygnał poza zakresem/wydajność"  
B0567,"Obwód zabezpieczenia informacji - niski sygnał wejściowy"  
B0568,"Obwód zabezpieczenia informacji - wysoki sygnał wejściowy"  
B0600,"Błąd konfiguracji opcji"  
B0601,"Zerowanie /reset/ KAM"  
B0602,"Układ nadzorujący COP - usterka"  
B0603,"Pamięć EEPROM - błąd zapisu"  
B0604,"Pamięć EEPROM - błąd kalibracji"  
B0605,"Pamięć EEPROM - błąd sumy kontrolnej"  
B0606,"Uszkodzenie pamięci RAM"

B0607,"Błąd wewnętrzny"  
B0608,"Błąd inicjalizacji"  
B0800,"Obwód zasilania urządzenia #1 - usterka"  
B0801,"Obwód zasilania urządzenia #1 - sygnał poza zakresem/wydajność"  
B0802,"Obwód zasilania urządzenia #1 - niski sygnał wejściowy"  
B0803,"Obwód zasilania urządzenia #1 - wysoki sygnał wejściowy"  
B0805,"Obwód zasilania urządzenia #2 - usterka"  
B0806,"Obwód zasilania urządzenia #2 - sygnał poza zakresem/wydajność"  
B0807,"Obwód zasilania urządzenia #2 - niski sygnał wejściowy"  
B0808,"Obwód zasilania urządzenia #2 - wysoki sygnał wejściowy"  
B0810,"Obwód zasilania urządzenia #3 - usterka"  
B0811,"Obwód zasilania urządzenia #3 - sygnał poza zakresem/wydajność"  
B0812,"Obwód zasilania urządzenia #3 - niski sygnał wejściowy"  
B0813,"Obwód zasilania urządzenia #3 - wysoki sygnał wejściowy"  
B0815,"Obwód masy urządzenia #1 - usterka"  
B0816,"Obwód masy urządzenia #1 - sygnał poza zakresem/wydajność"  
B0817,"Obwód masy urządzenia #1 - niski sygnał wejściowy"  
B0818,"Obwód masy urządzenia #1 - wysoki sygnał wejściowy"  
B0820,"Obwód masy urządzenia #2 - usterka"  
B0821,"Obwód masy urządzenia #2 - sygnał poza zakresem/wydajność"  
B0822,"Obwód masy urządzenia #2 - niski sygnał wejściowy"  
B0823,"Obwód masy urządzenia #2 - wysoki sygnał wejściowy"  
B0825,"Obwód masy urządzenia #3 - usterka"  
B0826,"Obwód masy urządzenia #3 - sygnał poza zakresem/wydajność"  
B0827,"Obwód masy urządzenia #3 - niski sygnał wejściowy"  
B0828,"Obwód masy urządzenia #3 - wysoki sygnał wejściowy"  
B0830,"Obwód zapłonu #0 - usterka"  
B0831,"Obwód zapłonu #0 - sygnał poza zakresem/wydajność"  
B0832,"Obwód zapłonu #0 - niski sygnał wejściowy"  
B0833,"Obwód zapłonu #0 - wysoki sygnał wejściowy"  
B0835,"Obwód zapłonu #1 - usterka"  
B0836,"Obwód zapłonu #1 - sygnał poza zakresem/wydajność"  
B0837,"Obwód zapłonu #1 - niski sygnał wejściowy"  
B0838,"Obwód zapłonu #1 - wysoki sygnał wejściowy"  
B0840,"Obwód zapłonu #3 - usterka"  
B0841,"Obwód zapłonu #3 - sygnał poza zakresem/wydajność"  
B0842,"Obwód zapłonu #3 - niski sygnał wejściowy"  
B0843,"Obwód zapłonu #3 - wysoki sygnał wejściowy"  
B0845,"Obwód napięcia odniesienia 5V - usterka"  
B0846,"Obwód napięcia odniesienia 5V - sygnał poza zakresem/wydajność"  
B0847,"Obwód napięcia odniesienia 5V - niski sygnał wejściowy"  
B0848,"Obwód napięcia odniesienia 5V - wysoki sygnał wejściowy"  
B0850,"Obwód akumulatora (czystego) - usterka"  
B0851,"Obwód akumulatora (czystego) - sygnał poza zakresem/wydajność"  
B0852,"Obwód akumulatora (czystego) - niski sygnał wejściowy"  
B0853,"Obwód akumulatora (czystego) - wysoki sygnał wejściowy"  
B0855,"Obwód akumulatora (zanieczyszczzonego) - usterka"  
B0856,"Obwód akumulatora (zanieczyszczzonego) - sygnał poza zakresem/wydajność"  
B0857,"Obwód akumulatora (zanieczyszczzonego) - niski sygnał wejściowy"  
B0858,"Obwód akumulatora (zanieczyszczzonego) - wysoki sygnał wejściowy"  
B0859,"Napięcie systemu - sygnał zbyt niski"  
B0860,"Napięcie systemu - sygnał zbyt wysoki"  
C0200,"Czujnik prędkości koła prawy przedni - usterka"  
C0201,"Czujnik prędkości koła prawy przedni - sygnał poza zakresem/wydajność"  
C0202,"Czujnik prędkości koła prawy przedni - niski sygnał wejściowy"  
C0203,"Czujnik prędkości koła prawy przedni - wysoki sygnał wejściowy"  
C0205,"Czujnik prędkości koła lewy przedni - usterka"  
C0206,"Czujnik prędkości koła lewy przedni - sygnał poza zakresem/wydajność"  
C0207,"Czujnik prędkości koła lewy przedni - niski sygnał wejściowy"  
C0208,"Czujnik prędkości koła lewy przedni - wysoki sygnał wejściowy"

C0210,"Czujnik prędkości koła prawy tylny - usterka"  
C0211,"Czujnik prędkości koła prawy tylny - sygnał poza zakresem/wydajność"  
C0212,"Czujnik prędkości koła prawy tylny - niski sygnał wejściowy"  
C0213,"Czujnik prędkości koła prawy tylny - wysoki sygnał wyjściowy"  
C0215,"Czujnik prędkości koła lewy tylny - usterka"  
C0216,"Czujnik prędkości koła lewy tylny - sygnał poza zakresem/wydajność"  
C0217,"Czujnik prędkości koła lewy tylny - niski sygnał wejściowy"  
C0218,"Czujnik prędkości koła lewy tylny - wysoki sygnał wejściowy"  
C0220,"Czujnik prędkości tylnych kół - usterka"  
C0221,"Czujnik prędkości tylnych kół - sygnał poza zakresem/wydajność"  
C0222,"Czujnik prędkości tylnych kół - niski sygnał wejściowy"  
C0223,"Czujnik prędkości tylnych kół - wysoki sygnał wejściowy"  
C0225,"Czujnik prędkości kół - błąd częstotliwości"  
C0226,"Elektromagnes/miernik #1 ABS prawy przedni - usterka"  
C0227,"Elektromagnes/miernik #1 ABS prawy przedni - sygnał poza zakresem/wydajność"  
C0228,"Elektromagnes/miernik #1 ABS prawy przedni - niski sygnał wejściowy"  
C0229,"Elektromagnes/miernik #1 ABS prawy przedni - wysoki sygnał wejściowy"  
C0231,"Elektromagnes/miernik #2 ABS prawy przedni - usterka"  
C0232,"Elektromagnes/miernik #2 ABS prawy przedni - sygnał poza zakresem/wydajność"  
C0233,"Elektromagnes/miernik #2 ABS prawy przedni - niski sygnał wejściowy"  
C0234,"Elektromagnes/miernik #2 ABS prawy przedni - wysoki sygnał wejściowy"  
C0236,"Elektromagnes/miernik #1 ABS lewy przedni - usterka"  
C0237,"Elektromagnes/miernik #1 ABS lewy przedni - sygnał poza zakresem/wydajność"  
C0238,"Elektromagnes/miernik #1 ABS lewy przedni - niski sygnał wejściowy"  
C0239,"Elektromagnes/miernik #1 ABS lewy przedni - wysoki sygnał wejściowy"  
C0241,"Elektromagnes/miernik #2 ABS lewy przedni - usterka"  
C0242,"Elektromagnes/miernik #2 ABS lewy przedni - sygnał poza zakresem/wydajność"  
C0243,"Elektromagnes/miernik #2 ABS lewy przedni - niski sygnał wejściowy"  
C0244,"Elektromagnes/miernik #2 ABS lewy przedni - wysoki sygnał wejściowy"  
C0246,"Elektromagnes/miernik #1 ABS prawy tylny - usterka"  
C0247,"Elektromagnes/miernik #1 ABS prawy tylny - sygnał poza zakresem/wydajność"  
C0248,"Elektromagnes/miernik #1 ABS prawy tylny - niski sygnał wejściowy"  
C0249,"Elektromagnes/miernik #1 ABS prawy tylny - wysoki sygnał wejściowy"  
C0251,"Elektromagnes/miernik #2 ABS prawy tylny - usterka"  
C0252,"Elektromagnes/miernik #2 ABS prawy tylny - sygnał poza zakresem/wydajność"  
C0253,"Elektromagnes/miernik #2 ABS prawy tylny - niski sygnał wejściowy"  
C0254,"Elektromagnes/miernik #2 ABS prawy tylny - wysoki sygnał wejściowy"  
C0256,"Elektromagnes/miernik #1 ABS lewy tylny - usterka"  
C0257,"Elektromagnes/miernik #1 ABS lewy tylny - sygnał poza zakresem/wydajność"  
C0258,"Elektromagnes/miernik #1 ABS lewy tylny - niski sygnał wejściowy"  
C0259,"Elektromagnes/miernik #1 ABS lewy tylny - wysoki sygnał wejściowy"  
C0261,"Elektromagnes/miernik #2 ABS lewy tylny - usterka"  
C0262,"Elektromagnes/miernik #2 ABS lewy tylny - sygnał poza zakresem/wydajność"  
C0263,"Elektromagnes/miernik #2 ABS lewy tylny - niski sygnał wejściowy"  
C0264,"Elektromagnes/miernik #2 ABS lewy tylny - wysoki sygnał wejściowy"  
C0266,"Obwód silnika pompy - usterka"  
C0267,"Obwód silnika pompy - sygnał poza zakresem/wydajność"  
C0268,"Obwód silnika pompy - niski sygnał wejściowy"  
C0269,"Obwód silnika pompy - wysoki sygnał wejściowy"  
C0271,"Obwód przekąźnika silnika pompy - usterka"  
C0272,"Obwód przekąźnika silnika pompy - sygnał poza zakresem/wydajność"  
C0273,"Obwód przekąźnika silnika pompy - niski sygnał wejściowy"  
C0274,"Obwód przekąźnika silnika pompy - wysoki sygnał wejściowy"  
C0276,"Obwód przekąźnika zaworu - usterka"  
C0277,"Obwód przekąźnika zaworu - sygnał poza zakresem/wydajność"  
C0278,"Obwód przekąźnika zaworu - niski sygnał wejściowy"  
C0279,"Obwód przekąźnika zaworu - wysoki sygnał wejściowy"  
C0300,"Elektromagnes/miernik TCS #1 prawy przedni - usterka"  
C0301,"Elektromagnes/miernik TCS #1 prawy przedni - sygnał poza zakresem/wydajność"  
C0302,"Elektromagnes/miernik TCS #1 prawy przedni - niski sygnał wejściowy"

C0303,"Elektromagnes/miernik TCS #1 prawy przedni - wysoki sygnał wejściowy"  
C0305,"Elektromagnes/miernik TCS #2 prawy przedni - usterka"  
C0306,"Elektromagnes/miernik TCS #2 prawy przedni - sygnał poza zakresem/wydajność"  
C0307,"Elektromagnes/miernik TCS #2 prawy przedni - niski sygnał wejściowy"  
C0308,"Elektromagnes/miernik TCS #2 prawy przedni - wysoki sygnał wejściowy"  
C0310,"Elektromagnes/miernik TCS #1 lewy przedni - usterka"  
C0311,"Elektromagnes/miernik TCS #1 lewy przedni - sygnał poza zakresem/wydajność"  
C0312,"Elektromagnes/miernik TCS #1 lewy przedni - niski sygnał wejściowy"  
C0313,"Elektromagnes/miernik TCS #1 lewy przedni - wysoki sygnał wejściowy"  
C0315,"Elektromagnes/miernik TCS #2 lewy przedni - usterka"  
C0316,"Elektromagnes/miernik TCS #2 lewy przedni - sygnał poza zakresem/wydajność"  
C0317,"Elektromagnes/miernik TCS #2 lewy przedni - niski sygnał wejściowy"  
C0318,"Elektromagnes/miernik TCS #2 lewy przedni - wysoki sygnał wejściowy"  
C0320,"Elektromagnes/miernik TCS #1 prawy tylny - usterka"  
C0321,"Elektromagnes/miernik TCS #1 prawy tylny - sygnał poza zakresem/wydajność"  
C0322,"Elektromagnes/miernik TCS #1 prawy tylny - niski sygnał wejściowy"  
C0323,"Elektromagnes/miernik TCS #1 prawy tylny - wysoki sygnał wejściowy"  
C0325,"Elektromagnes/miernik TCS #2 prawy tylny - usterka"  
C0326,"Elektromagnes/miernik TCS #2 prawy tylny - sygnał poza zakresem/wydajność"  
C0327,"Elektromagnes/miernik TCS #2 prawy tylny - niski sygnał wejściowy"  
C0328,"Elektromagnes/miernik TCS #2 prawy tylny - wysoki sygnał wejściowy"  
C0330,"Elektromagnes/miernik TCS #1 lewy tylny - usterka"  
C0331,"Elektromagnes/miernik TCS #1 lewy tylny - sygnał poza zakresem/wydajność"  
C0332,"Elektromagnes/miernik TCS #1 lewy tylny - niski sygnał wejściowy"  
C0333,"Elektromagnes/miernik TCS #1 lewy tylny - wysoki sygnał wejściowy"  
C0335,"Elektromagnes/miernik TCS #2 lewy tylny - usterka"  
C0336,"Elektromagnes/miernik TCS #2 lewy tylny - sygnał poza zakresem/wydajność"  
C0337,"Elektromagnes/miernik TCS #2 lewy tylny - niski sygnał wejściowy"  
C0338,"Elektromagnes/miernik TCS #2 lewy tylny - wysoki sygnał wejściowy"  
C0340,"Przełącznik hamulca ABS/TCS - usterka"  
C0341,"Przełącznik hamulca ABS/TCS - sygnał poza zakresem/wydajność"  
C0342,"Przełącznik hamulca ABS/TCS - niski sygnał wejściowy"  
C0343,"Przełącznik hamulca ABS/TCS - wysoki sygnał wejściowy"  
C0345,"Obwód niskiego poziomu płynu hamulcowego - usterka"  
C0346,"Obwód niskiego poziomu płynu hamulcowego - sygnał poza zakresem/wydajność"  
C0347,"Obwód niskiego poziomu płynu hamulcowego - niski sygnał wejściowy"  
C0348,"Obwód niskiego poziomu płynu hamulcowego - wysoki sygnał wejściowy"  
C0350,"Elektromagnes/miernik #1 tylny - usterka"  
C0351,"Elektromagnes/miernik #1 tylny - sygnał poza zakresem/wydajność"  
C0352,"Elektromagnes/miernik #1 tylny - niski sygnał wejściowy"  
C0353,"Elektromagnes/miernik #1 tylny - wysoki sygnał wejściowy"  
C0355,"Obwód miernika przemykania przepustnicy - usterka"  
C0356,"Obwód miernika przemykania przepustnicy - sygnał poza zakresem/wydajność"  
C0357,"Obwód miernika przemykania przepustnicy - niski sygnał wejściowy"  
C0358,"Obwód miernika przemykania przepustnicy - wysoki sygnał wejściowy"  
C0360,"Obwód ciśnienia w systemie - usterka"  
C0361,"Obwód ciśnienia w systemie - sygnał poza zakresem/wydajność"  
C0362,"Obwód ciśnienia w systemie - niski sygnał wejściowy"  
C0363,"Obwód ciśnienia w systemie - wysoki sygnał wejściowy"  
C0365,"Przyspieszeniomierz boczny/poprzeczny/ - usterka"  
C0366,"Przyspieszeniomierz boczny/poprzeczny/ - sygnał poza zakresem/wydajność"  
C0367,"Przyspieszeniomierz boczny/poprzeczny/ - niski sygnał wejściowy"  
C0368,"Przyspieszeniomierz boczny/poprzeczny/ - wysoki sygnał wejściowy"  
C0370,"Obwód odchylenia kierunkowego - usterka"  
C0371,"Obwód odchylenia kierunkowego - sygnał poza zakresem/wydajność"  
C0372,"Obwód odchylenia kierunkowego - niski sygnał wejściowy"  
C0373,"Obwód odchylenia kierunkowego - wysoki sygnał wejściowy"  
C0500,"Układ wspomagania kierownicy, elektromagnes - usterka"  
C0501,"Układ wspomagania kierownicy, elektromagnes - sygnał poza zakresem/wydajność"  
C0502,"Układ wspomagania kierownicy, elektromagnes - niski sygnał wejściowy"

C0503,"Układ wspomagania kierownicy, elektromagnes - wysoki sygnał wejściowy"  
C0505,"Układ wspomagania, czujnik położenia kierownicy - usterka"  
C0506,"Układ wspomagania, czujnik położenia kierownicy - sygnał poza zakresem/wydajność"  
C0507,"Układ wspomagania, czujnik położenia kierownicy - niski sygnał wejściowy"  
C0508,"Układ wspomagania, czujnik położenia kierownicy - wysoki sygnał wejściowy"  
C0510,"Czujnik zmiany wielkości położenia kierownicy - usterka"  
C0511,"Czujnik zmiany wielkości położenia kierownicy - sygnał poza zakresem/wydajność"  
C0512,"Czujnik zmiany wielkości położenia kierownicy - niski sygnał wejściowy"  
C0513,"Czujnik zmiany wielkości położenia kierownicy - wysoki sygnał wejściowy"  
C0700,"Elektromagnes lewy przedni - usterka"  
C0701,"Elektromagnes lewy przedni - sygnał poza zakresem/wydajność"  
C0702,"Elektromagnes lewy przedni - niski sygnał wejściowy"  
C0703,"Elektromagnes lewy przedni - wysoki sygnał wejściowy"  
C0705,"Elektromagnes prawy przedni - usterka"  
C0706,"Elektromagnes prawy przedni - sygnał poza zakresem/wydajność"  
C0707,"Elektromagnes prawy przedni - niski sygnał wejściowy"  
C0708,"Elektromagnes prawy przedni - wysoki sygnał wejściowy"  
C0710,"Elektromagnes lewy tylny - usterka"  
C0711,"Elektromagnes lewy tylny - sygnał poza zakresem/wydajność"  
C0712,"Elektromagnes lewy tylny - niski sygnał wejściowy"  
C0713,"Elektromagnes lewy tylny - wysoki sygnał wejściowy"  
C0715,"Elektromagnes prawy tylny - usterka"  
C0716,"Elektromagnes prawy tylny - sygnał poza zakresem/wydajność"  
C0717,"Elektromagnes prawy tylny - niski sygnał wejściowy"  
C0718,"Elektromagnes prawy tylny - wysoki sygnał wejściowy"  
C0720,"Przyspieszeniomierz lewy przedni - usterka"  
C0721,"Przyspieszeniomierz lewy przedni - sygnał poza zakresem/wydajność"  
C0722,"Przyspieszeniomierz lewy przedni - niski sygnał wejściowy"  
C0723,"Przyspieszeniomierz lewy przedni - wysoki sygnał wejściowy"  
C0725,"Przyspieszeniomierz prawy przedni - usterka"  
C0726,"Przyspieszeniomierz prawy przedni - sygnał poza zakresem/wydajność"  
C0727,"Przyspieszeniomierz prawy przedni - niski sygnał wejściowy"  
C0728,"Przyspieszeniomierz prawy przedni - wysoki sygnał wejściowy"  
C0730,"Przyspieszeniomierz lewy tylny - usterka"  
C0731,"Przyspieszeniomierz lewy tylny - sygnał poza zakresem/wydajność"  
C0732,"Przyspieszeniomierz lewy tylny - niski sygnał wejściowy"  
C0733,"Przyspieszeniomierz lewy tylny - wysoki sygnał wejściowy"  
C0735,"Przyspieszeniomierz prawy tylny - usterka"  
C0736,"Przyspieszeniomierz prawy tylny - sygnał poza zakresem/wydajność"  
C0737,"Przyspieszeniomierz prawy tylny - niski sygnał wejściowy"  
C0738,"Przyspieszeniomierz prawy tylny - wysoki sygnał wejściowy"  
C0740,"Czujnik położenia lewy przedni - usterka"  
C0741,"Czujnik położenia lewy przedni - sygnał poza zakresem/wydajność"  
C0742,"Czujnik położenia lewy przedni - niski sygnał wejściowy"  
C0743,"Czujnik położenia lewy przedni - wysoki sygnał wejściowy"  
C0745,"Czujnik położenia prawy przedni - usterka"  
C0746,"Czujnik położenia prawy przedni - sygnał poza zakresem/wydajność"  
C0747,"Czujnik położenia prawy przedni - niski sygnał wejściowy"  
C0748,"Czujnik położenia prawy przedni - wysoki sygnał wejściowy"  
C0750,"Czujnik położenia lewy tylny - usterka"  
C0751,"Czujnik położenia lewy tylny - sygnał poza zakresem/wydajność"  
C0752,"Czujnik położenia lewy tylny - niski sygnał wejściowy"  
C0753,"Czujnik położenia lewy tylny - wysoki sygnał wejściowy"  
C0755,"Czujnik położenia prawy tylny - usterka"  
C0756,"Czujnik położenia prawy tylny - sygnał poza zakresem/wydajność"  
C0757,"Czujnik położenia prawy tylny - niski sygnał wejściowy"  
C0758,"Czujnik położenia prawy tylny - wysoki sygnał wejściowy"  
P0100,"Czujnik masowego lub objętościowego przepływu powietrza - usterka"  
P0101,"Czujnik masowego lub objętościowego przepływu powietrza - sygnał poza zakresem/wydajność"  
P0102,"Czujnik masowego lub objętościowego przepływu powietrza - niski sygnał wejściowy"



P0103,"Czujnik masowego lub objętościowego przepływu powietrza - wysoki sygnał wejściowy"  
P0104,"Czujnik masowego lub objętościowego przepływu powietrza - przerwa"  
P0105,"Czujnik ciśnienia absol.kolektora/ciśnienia atmosferycznego - usterka"  
P0106,"Czujnik ciśnienia absol.kolektora/ciśnienia atmosferycznego - sygnał poza zakresem/wydajność"  
P0107,"Czujnik ciśnienia absol.kolektora/ciśnienia atmosferycznego - niski sygnał wejściowy"  
P0108,"Czujnik ciśnienia absol.kolektora/ciśnienia atmosferycznego - wysoki sygnał wejściowy"  
P0109,"Czujnik ciśnienia absol.kolektora/ciśnienia atmosferycznego - przerwa"  
P0110,"Czujnik temp. powietrza wlotowego - usterka"  
P0111,"Czujnik temp. powietrza wlotowego - sygnał poza zakresem/wydajność"  
P0112,"Czujnik temp. powietrza wlotowego - niski sygnał wejściowy"  
P0113,"Czujnik temp. powietrza wlotowego - wysoki sygnał wejściowy"  
P0114,"Czujnik temp. powietrza wlotowego - przerwa"  
P0115,"Czujnik temp. czynnika chłodzącego silnik - usterka"  
P0116,"Czujnik temp. czynnika chłodzącego silnik - sygnał poza zakresem/wydajność"  
P0117,"Czujnik temp. czynnika chłodzącego silnik - niski sygnał wejściowy"  
P0118,"Czujnik temp. czynnika chłodzącego silnik - wysoki sygnał wejściowy"  
P0119,"Czujnik temp. czynnika chłodzącego silnik - przerwa"  
P0120,"Przepustnica /czujnik położenia pedału /przełącznik A - usterka"  
P0121,"Przepustnica /czujnik położenia pedału /przełącznik A - sygnał poza zakresem/wydajność"  
P0122,"Przepustnica /czujnik położenia pedału /przełącznik A - niski sygnał wejściowy"  
P0123,"Przepustnica /czujnik położenia pedału /przełącznik A - wysoki sygnał wejściowy"  
P0124,"Przepustnica /czujnik położenia pedału /przełącznik A - przerwa"  
P0125,"Niewystarczająca temp. czynnika chłodzącego dla zamkniętej pętli regulacji paliwa"  
P0126,"Niewystarczająca temp. czynnika chłodzącego dla stabilnej pracy"  
P0130,"Czujnik O2 (Bank 1 Czujnik 1) - usterka"  
P0131,"Czujnik O2 (Bank 1 Czujnik 1) - niskie napięcie"  
P0132,"Czujnik O2 (Bank 1 Czujnik 1) - wysokie napięcie"  
P0133,"Czujnik O2 (Bank 1 Czujnik 1) - powolna reakcja /odpowiedź/"  
P0134,"Czujnik O2 (Bank 1 Czujnik 1) - brak aktywności"  
P0135,"Podgrzewacz czujnika O2 (Bank 1 Czujnik 1) - usterka"  
P0136,"Czujnik O2 (Bank 1 Czujnik 2) - usterka"  
P0137,"Czujnik O2 (Bank 1 Czujnik 2) - niskie napięcie"  
P0138,"Czujnik O2 (Bank 1 Czujnik 2) - wysokie napięcie"  
P0139,"Czujnik O2 (Bank 1 Czujnik 2) - powolna reakcja"  
P0140,"Czujnik O2 (Bank 1 Czujnik 2) - brak aktywności"  
P0141,"Podgrzewacz czujnika O2 (Bank 1 Czujnik 2) - usterka"  
P0142,"Czujnik O2 (Bank 1 Czujnik 3) - usterka"  
P0143,"Czujnik O2 (Bank 1 Czujnik 3) - niskie napięcie"  
P0144,"Czujnik O2 (Bank 1 Czujnik 3) - wysokie napięcie"  
P0145,"Czujnik O2 (Bank 1 Czujnik 3) - powolna reakcja"  
P0146,"Czujnik O2 (Bank 1 Czujnik 3) - brak aktywności"  
P0147,"Podgrzewacz czujnika O2 (Bank 1 Czujnik 3) - usterka"  
P0150,"Czujnik O2 (Bank 2 Czujnik 1) - usterka"  
P0151,"Czujnik O2 (Bank 2 Czujnik 1) - niskie napięcie"  
P0152,"Czujnik O2 (Bank 2 Czujnik 1) - wysokie napięcie"  
P0153,"Czujnik O2 (Bank 2 Czujnik 1) - powolna reakcja"  
P0154,"Czujnik O2 (Bank 2 Czujnik 1) - brak aktywności"  
P0155,"Podgrzewacz czujnika O2 (Bank 2 Czujnik 1) - usterka"  
P0156,"Czujnik O2 (Bank 2 Czujnik 2) - usterka"  
P0157,"Czujnik O2 (Bank 2 Czujnik 2) - niskie napięcie"  
P0158,"Czujnik O2 (Bank 2 Czujnik 2) - wysokie napięcie"  
P0159,"Czujnik O2 (Bank 2 Czujnik 2) - powolna reakcja"  
P0160,"Czujnik O2 (Bank 2 Czujnik 2) - brak aktywności"  
P0161,"Podgrzewacz czujnika O2 (Bank 2 Czujnik 2) - usterka"  
P0162,"Czujnik O2 (Bank 2 Czujnik 3) - usterka"  
P0163,"Czujnik O2 (Bank 2 Czujnik 3) - niskie napięcie"  
P0164,"Czujnik O2 (Bank 2 Czujnik 3) - wysokie napięcie"  
P0165,"Czujnik O2 (Bank 2 Czujnik 3) - powolna reakcja"  
P0166,"Czujnik O2 (Bank 2 Czujnik 3) - brak aktywności"  
P0167,"Podgrzewacz czujnika O2 (Bank 2 Czujnik 3) - usterka"

P0170,"Czujnik O2 (Bank 1) - usterka dostrajania paliwa"  
P0171,"Czujnik O2 (Bank 1) - mieszanka zbyt uboga"  
P0172,"Czujnik O2 (Bank 1) - mieszanka zbyt bogata"  
P0173,"Czujnik O2 (Bank 2) - usterka dostrajania paliwa"  
P0174,"Czujnik O2 (Bank 2) - mieszanka zbyt uboga"  
P0175,"Czujnik O2 (Bank 2) - mieszanka zbyt bogata"  
P0176,"Czujnik składu paliwa - usterka"  
P0177,"Czujnik składu paliwa - sygnał poza zakresem/wydajność"  
P0178,"Czujnik składu paliwa - niski sygnał wejściowy"  
P0179,"Czujnik składu paliwa - wysoki sygnał wejściowy"  
P0180,"Czujnik A temp. paliwa - usterka"  
P0181,"Czujnik A temp. paliwa - sygnał poza zakresem/wydajność"  
P0182,"Czujnik A temp. paliwa - niski sygnał wejściowy"  
P0183,"Czujnik A temp. paliwa - wysoki sygnał wejściowy"  
P0184,"Czujnik A temp. paliwa - przerwa"  
P0185,"Czujnik B temp. paliwa - usterka"  
P0186,"Czujnik B temp. paliwa - sygnał poza zakresem/wydajność"  
P0187,"Czujnik B temp. paliwa - niski sygnał wejściowy"  
P0188,"Czujnik B temp. paliwa - wysoki sygnał wejściowy"  
P0189,"Czujnik B temp. paliwa - przerwa"  
P0190,"Czujnik ciśnienia zbiornika zasilania (listwy) paliwa - usterka"  
P0191,"Czujnik ciśnienia zbiornika zasilania (listwy) paliwa - sygnał poza zakresem/wydajność"  
P0192,"Czujnik ciśnienia zbiornika zasilania (listwy) paliwa - niski sygnał wejściowy"  
P0193,"Czujnik ciśnienia zbiornika zasilania (listwy) paliwa - wysoki sygnał wejściowy"  
P0194,"Czujnik ciśnienia listwy paliwowej - przerwa"  
P0195,"Czujnik temp. oleju silnika - usterka"  
P0196,"Czujnik temp. oleju silnika - sygnał poza zakresem/wydajność"  
P0197,"Czujnik temp. oleju silnika - niski sygnał wejściowy"  
P0198,"Czujnik temp. oleju silnika - wysoki sygnał wejściowy"  
P0199,"Czujnik temp. oleju silnika - przerwa"  
P0200,"Obwód wtryskiwacza - usterka"  
P0201,"Obwód wtryskiwacza, cylinder 1 - usterka"  
P0202,"Obwód wtryskiwacza, cylinder 2 - usterka"  
P0203,"Obwód wtryskiwacza, cylinder 3 - usterka"  
P0204,"Obwód wtryskiwacza, cylinder 4 - usterka"  
P0205,"Obwód wtryskiwacza, cylinder 5 - usterka"  
P0206,"Obwód wtryskiwacza, cylinder 6 - usterka"  
P0207,"Obwód wtryskiwacza, cylinder 7 - usterka"  
P0208,"Obwód wtryskiwacza, cylinder 8 - usterka"  
P0209,"Obwód wtryskiwacza, cylinder 9 - usterka"  
P0210,"Obwód wtryskiwacza, cylinder 10 - usterka"  
P0211,"Obwód wtryskiwacza, cylinder 11 - usterka"  
P0212,"Obwód wtryskiwacza, cylinder 12 - usterka"  
P0213,"Zimny rozruch wtryskiwacza 1 - usterka"  
P0214,"Zimny rozruch wtryskiwacza 2 - usterka"  
P0215,"Elektromagnes/cewka odcięcia silnika - usterka"  
P0216,"Układ kontroli czasu wtrysku - usterka"  
P0217,"Stan nadmiernej temp. silnika"  
P0218,"Stan nadmiernej temp. skrzyni biegów"  
P0219,"Stan nadmiernej prędkości obrotowej silnika"  
P0220,"Przepustnica /czujnik położenia pedału /przełącznik B - usterka"  
P0221,"Przepustnica /czujnik położenia pedału /przełącznik B - sygnał poza zakresem/wydajność"  
P0222,"Przepustnica /czujnik położenia pedału /przełącznik B - niski sygnał wejściowy"  
P0223,"Przepustnica /czujnik położenia pedału /przełącznik B - wysoki sygnał wejściowy"  
P0224,"Przepustnica /czujnik położenia pedału /przełącznik B - przerwa"  
P0225,"Przepustnica /czujnik położenia pedału /przełącznik C - usterka"  
P0226,"Przepustnica /czujnik położenia pedału /przełącznik C - sygnał poza zakresem/wydajność"  
P0227,"Przepustnica /czujnik położenia pedału /przełącznik C - niski sygnał wejściowy"  
P0228,"Przepustnica /czujnik położenia pedału /przełącznik C - wysoki sygnał wejściowy"  
P0229,"Przepustnica /czujnik położenia pedału /przełącznik C - przerwa"

P0230,"Pompa paliwowa, obwód pierwotny - usterka"  
P0231,"Pompa paliwowa, obwód wtórny - niski sygnał"  
P0232,"Pompa paliwowa, obwód wtórny - wysoki sygnał"  
P0233,"Pompa paliwowa, obwód wtórny - przerwa"  
P0234,"Stan przeładowania /nadmiernego ładowania/ silnika"  
P0235,"Czujnik A wspomagania turbosprężarki - usterka"  
P0236,"Czujnik A wspomagania turbosprężarki - sygnał poza zakresem/wydajność"  
P0237,"Czujnik A wspomagania turbosprężarki - niski sygnał wejściowy"  
P0238,"Czujnik A wspomagania turbosprężarki - wysoki sygnał wejściowy"  
P0239,"Czujnik B wspomagania turbosprężarki - usterka"  
P0240,"Czujnik B wspomagania turbosprężarki - sygnał poza zakresem/wydajność"  
P0241,"Czujnik B wspomagania turbosprężarki - niski sygnał wejściowy"  
P0242,"Czujnik B wspomagania turbosprężarki - wysoki sygnał wejściowy"  
P0243,"Elektromagnes A przepustnicy spalin turbosprężarki - usterka"  
P0244,"Elektromagnes A przepustnicy spalin turbosprężarki - sygnał poza zakresem/wydajność"  
P0245,"Elektromagnes A przepustnicy spalin turbosprężarki - niski sygnał"  
P0246,"Elektromagnes A przepustnicy spalin turbosprężarki - wysoki sygnał"  
P0247,"Elektromagnes B przepustnicy spalin turbosprężarki - usterka"  
P0248,"Elektromagnes B przepustnicy spalin turbosprężarki - sygnał poza zakresem/wydajność"  
P0249,"Elektromagnes B przepustnicy spalin turbosprężarki - niski sygnał"  
P0250,"Elektromagnes B przepustnicy spalin turbosprężarki - wysoki sygnał"  
P0251,"Wirnik/krzywka pompy wtryskowej A - usterka"  
P0252,"Wirnik/krzywka pompy wtryskowej A - sygnał poza zakresem/wydajność"  
P0253,"Wirnik/krzywka pompy wtryskowej A - niski sygnał"  
P0254,"Wirnik/krzywka pompy wtryskowej A - wysoki sygnał"  
P0255,"Wirnik/krzywka pompy wtryskowej A - przerwa"  
P0256,"Wirnik/krzywka pompy wtryskowej B - usterka"  
P0257,"Wirnik/krzywka pompy wtryskowej B - sygnał poza zakresem/wydajność"  
P0258,"Wirnik/krzywka pompy wtryskowej B - niski sygnał"  
P0259,"Wirnik/krzywka pompy wtryskowej B - wysoki sygnał"  
P0260,"Wirnik/krzywka pompy wtryskowej B - przerwa"  
P0261,"Wtryskiwacz cylindra 1 - niski sygnał"  
P0262,"Wtryskiwacz cylindra 1 - wysoki sygnał"  
P0263,"Cylinder 1 - błąd udziału /zrównoważenia"  
P0264,"Wtryskiwacz cylindra 2 - niski sygnał"  
P0265,"Wtryskiwacz cylindra 2 - wysoki sygnał"  
P0266,"Cylinder 2 - błąd udziału /zrównoważenia"  
P0267,"Wtryskiwacz cylindra 3 - niski sygnał"  
P0268,"Wtryskiwacz cylindra 3 - wysoki sygnał"  
P0269,"Cylinder 3 - błąd udziału /zrównoważenia"  
P0270,"Wtryskiwacz cylindra 4 - niski sygnał"  
P0271,"Wtryskiwacz cylindra 4 - wysoki sygnał"  
P0272,"Cylinder 4 - błąd udziału /zrównoważenia"  
P0273,"Wtryskiwacz cylindra 5 - niski sygnał"  
P0274,"Wtryskiwacz cylindra 5 - wysoki sygnał"  
P0275,"Cylinder 5 - błąd udziału /zrównoważenia"  
P0276,"Wtryskiwacz cylindra 6 - niski sygnał"  
P0277,"Wtryskiwacz cylindra 6 - wysoki sygnał"  
P0278,"Cylinder 6 - błąd udziału /zrównoważenia"  
P0279,"Wtryskiwacz cylindra 7 - niski sygnał"  
P0280,"Wtryskiwacz cylindra 7 - wysoki sygnał"  
P0281,"Cylinder 7 - błąd udziału /zrównoważenia"  
P0282,"Wtryskiwacz cylindra 8 - niski sygnał"  
P0283,"Wtryskiwacz cylindra 8 - wysoki sygnał"  
P0284,"Cylinder 8 - błąd udziału /zrównoważenia"  
P0285,"Wtryskiwacz cylindra 9 - niski sygnał"  
P0286,"Wtryskiwacz cylindra 9 - wysoki sygnał"  
P0287,"Cylinder 9 - błąd udziału /zrównoważenia"  
P0288,"Wtryskiwacz cylindra 10 - niski sygnał"  
P0289,"Wtryskiwacz cylindra 10 - wysoki sygnał"

P0290,"Cylinder 10 - błąd udziału /zrównoważenia"  
P0291,"Wtryskiwacz cylindra 11 - niski sygnał"  
P0292,"Wtryskiwacz cylindra 11 - wysoki sygnał"  
P0293,"Cylinder 11 - błąd udziału /zrównoważenia"  
P0294,"Wtryskiwacz cylindra 12 - niski sygnał"  
P0295,"Wtryskiwacz cylindra 12 - wysoki sygnał"  
P0296,"Cylinder 12 - błąd udziału /zrównoważenia"  
P0300,"Wykryte przypadkowe/wielokrotne wypadanie zapłonów w cylindrach"  
P0301,"Cylinder 1 - wykryte wypadanie zapłonów"  
P0302,"Cylinder 2 - wykryte wypadanie zapłonów"  
P0303,"Cylinder 3 - wykryte wypadanie zapłonów"  
P0304,"Cylinder 4 - wykryte wypadanie zapłonów"  
P0305,"Cylinder 5 - wykryte wypadanie zapłonów"  
P0306,"Cylinder 6 - wykryte wypadanie zapłonów"  
P0307,"Cylinder 7 - wykryte wypadanie zapłonów"  
P0308,"Cylinder 8 - wykryte wypadanie zapłonów"  
P0309,"Cylinder 9 - wykryte wypadanie zapłonów"  
P0310,"Cylinder 10 - wykryte wypadanie zapłonów"  
P0311,"Cylinder 11 - wykryte wypadanie zapłonów"  
P0312,"Cylinder 12 - wykryte wypadanie zapłonów"  
P0320,"Obwód wejścia prędkości silnika dla rozdzielacza /zapłonu - usterka"  
P0321,"Obwód wejścia prędkości silnika dla rozdzielacza /zapłonu - sygnał poza zakresem/wydajność"  
P0322,"Obwód wejścia prędkości silnika dla rozdzielacza /zapłonu - brak sygnału"  
P0323,"Obwód wejścia prędkości silnika dla rozdzielacza /zapłonu - przerwa"  
P0325,"Czujnik spalania stukowego 1 (Bank 1 lub poj.czujnik) - usterka"  
P0326,"Czujnik spalania stukowego 1 (Bank 1 lub poj.czujnik) - sygnał poza zakresem/wydajność"  
P0327,"Czujnik spalania stukowego 1 (Bank 1 lub poj.czujnik) - niski sygnał wejściowy"  
P0328,"Czujnik spalania stukowego 1 (Bank 1 lub poj.czujnik) - wysoki sygnał wejściowy"  
P0329,"Czujnik spalania stukowego 1 (Bank 1 lub poj.czujnik) - przerwa"  
P0330,"Czujnik spalania stukowego 2 (Bank 2) - usterka"  
P0331,"Czujnik spalania stukowego 2 (Bank 2) - sygnał poza zakresem/wydajność"  
P0332,"Czujnik spalania stukowego 2 (Bank 2) - niski sygnał wejściowy"  
P0333,"Czujnik spalania stukowego 2 (Bank 2) - wysoki sygnał wejściowy"  
P0334,"Czujnik spalania stukowego 2 (Bank 2) - przerwa"  
P0335,"Czujnik A położenia wału korbowego - usterka"  
P0336,"Czujnik A położenia wału korbowego - sygnał poza prawidłowym zakresem"  
P0337,"Czujnik A położenia wału korbowego - niski sygnał wejściowy"  
P0338,"Czujnik A położenia wału korbowego - wysoki sygnał wejściowy"  
P0339,"Czujnik A położenia wału korbowego - przerwa"  
P0340,"Czujnik położenia wału rozrządu - usterka"  
P0341,"Czujnik położenia wału rozrządu - sygnał poza zakresem/wydajność"  
P0342,"Czujnik położenia wału rozrządu - niski sygnał wejściowy"  
P0343,"Czujnik położenia wału rozrządu - wysoki sygnał wejściowy"  
P0344,"Czujnik położenia wału rozrządu - przerwa"  
P0350,"Obwód pierwotny/wtórny cewki zapłonowej - usterka"  
P0351,"Obwód pierwotny/wtórny cewki zapłonowej A - usterka"  
P0352,"Obwód pierwotny/wtórny cewki zapłonowej B - usterka"  
P0353,"Obwód pierwotny/wtórny cewki zapłonowej C - usterka"  
P0354,"Obwód pierwotny/wtórny cewki zapłonowej D - usterka"  
P0355,"Obwód pierwotny/wtórny cewki zapłonowej E - usterka"  
P0356,"Obwód pierwotny/wtórny cewki zapłonowej F - usterka"  
P0357,"Obwód pierwotny/wtórny cewki zapłonowej G - usterka"  
P0358,"Obwód pierwotny/wtórny cewki zapłonowej H - usterka"  
P0359,"Obwód pierwotny/wtórny cewki zapłonowej I - usterka"  
P0360,"Obwód pierwotny/wtórny cewki zapłonowej J - usterka"  
P0361,"Obwód pierwotny/wtórny cewki zapłonowej K - usterka"  
P0362,"Obwód pierwotny/wtórny cewki zapłonowej L - usterka"  
P0370,"Czasowy sygnał referencyjny A o wysokiej rozdzielczości - usterka"  
P0371,"Czasowy sygnał referencyjny A o wysokiej rozdzielczości - za dużo impulsów"  
P0372,"Czasowy sygnał referencyjny A o wysokiej rozdzielczości - za mało impulsów"

P0373,"Czasowy sygnał referencyjny A o wysokiej rozdzielczości - impulsy błędne /przerwa"  
P0374,"Czasowy sygnał referencyjny A o wysokiej rozdzielczości - brak impulsów"  
P0375,"Czasowy sygnał referencyjny B o wysokiej rozdzielczości - usterka"  
P0376,"Czasowy sygnał referencyjny B o wysokiej rozdzielczości - za dużo impulsów"  
P0377,"Czasowy sygnał referencyjny B o wysokiej rozdzielczości - za mało impulsów"  
P0378,"Czasowy sygnał referencyjny B o wysokiej rozdzielczości - impulsy błędne /przerwa"  
P0379,"Czasowy sygnał referencyjny B o wysokiej rozdzielczości - brak impulsów"  
P0380,"Obwód grzałki /świecy żarowej - usterka"  
P0381,"Obwód wskaźnika grzałki /świecy żarowej - usterka"  
P0382,"Obwód grzałki /świecy żarowej B - usterka"  
P0385,"Czujnik B położenia wału korbowego - usterka"  
P0386,"Czujnik B położenia wału korbowego - sygnał poza zakresem/wydajność"  
P0387,"Czujnik B położenia wału korbowego - niski sygnał wejściowy"  
P0388,"Czujnik B położenia wału korbowego - wysoki sygnał wejściowy"  
P0389,"Czujnik B położenia wału korbowego - przerwa"  
P0400,"Układ recyrkulacji spalin - błędny przepływ"  
P0401,"Układ recyrkulacji spalin - wykryty niewystarczający przepływ"  
P0402,"Układ recyrkulacji spalin - wykryty nadmierny przepływ"  
P0403,"Układ recyrkulacji spalin - usterka"  
P0404,"Układ recyrkulacji spalin - sygnał poza zakresem/wydajność"  
P0405,"Czujnik A recyrkulacji spalin - niski sygnał wejściowy"  
P0406,"Czujnik A recyrkulacji spalin - wysoki sygnał wejściowy"  
P0407,"Czujnik B recyrkulacji spalin - niski sygnał wejściowy"  
P0408,"Czujnik B recyrkulacji spalin - wysoki sygnał wejściowy"  
P0410,"System wtrysku powietrza wtórnego - usterka"  
P0411,"System wtrysku powietrza wtórnego - wykryty nieprawidłowy przepływ"  
P0412,"System wtrysku powietrza wtórnego, zawór przełączający A - usterka"  
P0413,"System wtrysku powietrza wtórnego, zawór przełączający A - przerwa"  
P0414,"System wtrysku powietrza wtórnego, zawór przełączający A - zwarcie"  
P0415,"System wtrysku powietrza wtórnego, zawór przełączający B - usterka"  
P0416,"System wtrysku powietrza wtórnego, zawór przełączający B - przerwa"  
P0417,"System wtrysku powietrza wtórnego, zawór przełączający B - zwarcie"  
P0418,"System wtrysku powietrza wtórnego, przełącznik A - usterka"  
P0419,"System wtrysku powietrza wtórnego, przełącznik B - usterka"  
P0420,"System katalizatora (Bank 1) - wydajność poniżej progu "  
P0421,"Nagrzany katalizator (Bank 1) - wydajność poniżej progu"  
P0422,"Główny katalizator (Bank 1) - wydajność poniżej progu"  
P0423,"Grzany katalizator (Bank 1) - wydajność poniżej progu "  
P0424,"Grzany katalizator (Bank 1) - temperatura poniżej progu"  
P0430,"System katalizatora (Bank 2) - wydajność poniżej progu "  
P0431,"Nagrzany katalizator (Bank 2) - wydajność poniżej progu"  
P0432,"Główny katalizator (Bank 2) - wydajność poniżej progu"  
P0433,"Grzany katalizator (Bank 2) - wydajność poniżej progu"  
P0434,"Grzany katalizator (Bank 2) - temperatura poniżej progu"  
P0440,"Układ odprowadzania par paliwa - usterka"  
P0441,"Układ odprowadzania par paliwa - błędny przepływ oczyszczania"  
P0442,"Układ odprowadzania par paliwa - wykryta nieszczelność (mała)"  
P0443,"Układ odprowadzania par paliwa, obwód ster.zaworu oczyszcz. - usterka"  
P0444,"Układ odprowadzania par paliwa, obwód ster.zaworu oczyszcz. - przerwa"  
P0445,"Układ odprowadzania par paliwa, obwód ster.zaworu oczyszcz. - zwarcie"  
P0446,"Układ odprowadzania par paliwa, obwód ster.went. - usterka"  
P0447,"Układ odprowadzania par paliwa, obwód ster.went. - przerwa"  
P0448,"Układ odprowadzania par paliwa, obwód ster.went. - zwarcie"  
P0449,"Układ odprowadzania par paliwa - usterka serwowymotora/uzwojenia zaworu odpowietrznika"  
P0450,"Układ odprowadzania par paliwa, czujnik ciśnienia - usterka"  
P0451,"Układ odprowadzania par paliwa, czujnik ciśnienia - sygnał poza zakresem/wydajność"  
P0452,"Układ odprowadzania par paliwa, czujnik ciśnienia - niski sygnał wejściowy"  
P0453,"Układ odprowadzania par paliwa, czujnik ciśnienia - wysoki sygnał wejściowy"  
P0454,"Układ odprowadzania par paliwa, czujnik ciśnienia - przerwa"  
P0455,"Układ odprowadzania par paliwa - wykryta nieszczelność (duża)"

P0456,"Układ odprowadzania par paliwa - wykryta nieszczelność (b.mała)"  
P0460,"Czujnik poziomu paliwa - usterka"  
P0461,"Czujnik poziomu paliwa - sygnał poza zakresem/wydajność"  
P0462,"Czujnik poziomu paliwa - niski sygnał wejściowy"  
P0463,"Czujnik poziomu paliwa - wysoki sygnał wejściowy"  
P0464,"Czujnik poziomu paliwa - przerwa"  
P0465,"Czujnik przepływu oczyszcz. - usterka"  
P0466,"Czujnik przepływu oczyszcz. - sygnał poza zakresem/wydajność"  
P0467,"Czujnik przepływu oczyszcz. - niski sygnał wejściowy"  
P0468,"Czujnik przepływu oczyszcz. - wysoki sygnał wejściowy"  
P0469,"Czujnik przepływu oczyszcz. - przerwa"  
P0470,"Czujnik ciśnienia wylotowego - usterka"  
P0471,"Czujnik ciśnienia wylotowego - sygnał poza zakresem/wydajność"  
P0472,"Czujnik ciśnienia wylotowego - niski sygnał wejściowy"  
P0473,"Czujnik ciśnienia wylotowego - wysoki sygnał wejściowy"  
P0474,"Czujnik ciśnienia wylotowego - przerwa"  
P0475,"Zawór kontrolny ciśnienia wylotowego - usterka"  
P0476,"Zawór kontrolny ciśnienia wylotowego - sygnał poza zakresem/wydajność"  
P0477,"Zawór kontrolny ciśnienia wylotowego - niski sygnał wejściowy"  
P0478,"Zawór kontrolny ciśnienia wylotowego - wysoki sygnał wejściowy"  
P0479,"Zawór kontrolny ciśnienia wylotowego - przerwa"  
P0480,"Obwód kontroli wentylatora chłodzącego 1 - usterka"  
P0481,"Obwód kontroli wentylatora chłodzącego 2 - usterka"  
P0482,"Obwód kontroli wentylatora chłodzącego 3 - usterka"  
P0483,"Obwód wentylatora chłodzącego - kontrola racjonalności"  
P0484,"Obwód wentylatora chłodzącego - nadmierny prąd"  
P0485,"Obwód zasilania/masy wentylatora chłodzącego - usterka"  
P0500,"Czujnik prędkości pojazdu - usterka"  
P0501,"Czujnik prędkości pojazdu - sygnał poza zakresem/wydajność"  
P0502,"Czujnik prędkości pojazdu - niski sygnał wejściowy"  
P0503,"Czujnik prędkości pojazdu - wysoki/błędny/przerwany sygnał"  
P0505,"Układ regulacji biegu jałowego - usterka"  
P0506,"Układ regulacji biegu jałowego - obroty niższe niż oczekiwane"  
P0507,"Układ regulacji biegu jałowego - obroty wyższe niż oczekiwane"  
P0510,"Przełącznik położenia zamkniętej przepustnicy - usterka"  
P0520,"Przełącznik ciśnienia oleju silnika - usterka"  
P0521,"Przełącznik ciśnienia oleju silnika - sygnał poza zakresem/wydajność"  
P0522,"Przełącznik ciśnienia oleju silnika - niski sygnał wejściowy"  
P0523,"Przełącznik ciśnienia oleju silnika - wysoki sygnał wejściowy"  
P0530,"Czujnik ciśnienia czynnika chłodzącego A/C - usterka"  
P0531,"Czujnik ciśnienia czynnika chłodzącego A/C - sygnał poza zakresem/wydajność"  
P0532,"Czujnik ciśnienia czynnika chłodzącego A/C - niski sygnał wejściowy"  
P0533,"Czujnik ciśnienia czynnika chłodzącego A/C - wysoki sygnał wejściowy"  
P0534,"Ubytek ładunku czynnika chłodzącego A/C"  
P0540,"Układ kontroli grzałki powietrza wlotowego - usterka"  
P0541,"Układ kontroli grzałki powietrza wlotowego - niski sygnał"  
P0542,"Układ kontroli grzałki powietrza wlotowego - wysoki sygnał"  
P0550,"Czujnik ciśnienia układu wspomagania - usterka"  
P0551,"Czujnik ciśnienia układu wspomagania - sygnał poza zakresem/wydajność"  
P0552,"Czujnik ciśnienia układu wspomagania - niski sygnał wejściowy"  
P0553,"Czujnik ciśnienia układu wspomagania - wysoki sygnał wejściowy"  
P0554,"Czujnik ciśnienia układu wspomagania - przerwa"  
P0560,"Napięcie zasilania systemu - usterka"  
P0561,"Napięcie zasilania systemu - niestabilny sygnał"  
P0562,"Napięcie zasilania systemu - niski sygnał"  
P0563,"Napięcie zasilania systemu - wysoki sygnał"  
P0565,"Układ ster. prędkością, sygnał ON - usterka"  
P0566,"Układ ster. prędkością, sygnał OFF - usterka"  
P0567,"Układ ster. prędkością, sygnał RESUME - usterka"  
P0568,"Układ ster. prędkością, sygnał SET - usterka"

P0569,"Układ ster. prędkością, sygnał COAST - usterka"  
P0570,"Układ ster. prędkością, sygnał ACCEL - usterka"  
P0571,"Układ ster. prędkością /przełącznik A hamulca - usterka"  
P0572,"Układ ster. prędkością /przełącznik A hamulca - niski sygnał wejściowy"  
P0573,"Układ ster. prędkością /przełącznik A hamulca - wysoki sygnał wejściowy"  
P0574,"Układ ster. prędkością (Cruise Control)" // reserved  
P0575,"Układ ster. prędkością (Cruise Control)" // reserved  
P0576,"Układ ster. prędkością (Cruise Control)" // reserved  
P0577,"Układ ster. prędkością (Cruise Control)" // reserved  
P0578,"Układ ster. prędkością (Cruise Control)" // reserved  
P0579,"Układ ster. prędkością (Cruise Control)" // reserved  
P0580,"Układ ster. prędkością (Cruise Control)" // reserved  
P0600,"Szeregowe łącze komunikacyjne - usterka"  
P0601,"Wewnętrzny moduł sterujący - błąd sumy kontrolnej pamięci"  
P0602,"Wewnętrzny moduł sterujący - błąd programowania"  
P0603,"Wewnętrzny moduł sterujący - błąd pamięci podtrzymywanej (KAM)"  
P0604,"Wewnętrzny moduł sterujący - błąd pamięci o dostępie swobodnym (RAM)"  
P0605,"Wewnętrzny moduł sterujący - błąd pamięci stałej (ROM)"  
P0606,"Procesor modułu sterującego ECM/PCM - usterka"  
P0608,"Wyjście A sygnału prędkości (VSS) modułu sterującego"  
P0609,"Wyjście B sygnału prędkości (VSS) modułu sterującego"  
P0620,"Obwód sterujący alternatora - usterka"  
P0621,"Obwód sterujący L lampą alternatora - usterka"  
P0622,"Obwód sterujący F polem alternatora - usterka"  
P0650,"Obwód sterujący lampki uszkodzeń MIL - usterka"  
P0654,"Obwód wyjściowy prędkości obrotowej silnika - usterka"  
P0655,"Obwód wyjściowy lampki przegrzania silnika - usterka"  
P0656,"Obwodu wyjściowy poziomu paliwa - usterka"  
P0700,"System kontroli przełożenia /przenoszenia napędu/ - usterka"  
P0701,"System kontroli przełożenia /przenoszenia napędu/ - sygnał poza zakresem/wydajność"  
P0702,"System kontroli przełożenia /przenoszenia napędu/ - usterka elektryczna"  
P0703,"Przetwornik momentu obr./przełącznik B hamulca - usterka"  
P0704,"Obwód wejściowy przełącznika sprzęgła - usterka"  
P0705,"Czujnik zakresu przełożenia - usterka"  
P0706,"Czujnik zakresu przełożenia - sygnał poza zakresem/wydajność"  
P0707,"Czujnik zakresu przełożenia - niskie wejście"  
P0708,"Czujnik zakresu przełożenia - wysokie wejście"  
P0709,"Czujnik zakresu przełożenia - przerwa"  
P0710,"Czujnik temp. cieczy przekładniowej - usterka"  
P0711,"Czujnik temp. cieczy przekładniowej - sygnał poza zakresem/wydajność"  
P0712,"Czujnik temp. cieczy przekładniowej - niski sygnał wejściowy"  
P0713,"Czujnik temp. cieczy przekładniowej - wysoki sygnał wejściowy"  
P0714,"Czujnik temp. cieczy przekładniowej - przerwa"  
P0715,"Czujnik prędkości wejściowej turbiny - usterka"  
P0716,"Czujnik prędkości wejściowej turbiny - sygnał poza zakresem/wydajność"  
P0717,"Czujnik prędkości wejściowej turbiny - brak sygnału"  
P0718,"Czujnik prędkości wejściowej turbiny - przerwa"  
P0719,"Przetwornik momentu obr./przełącznik B hamulca - niski sygnał"  
P0720,"Obwód wyjściowy prędkości silnika - usterka"  
P0721,"Obwód wyjściowy prędkości silnika - sygnał poza zakresem/wydajność"  
P0722,"Obwód wyjściowy prędkości silnika - brak sygnału"  
P0723,"Obwód wyjściowy prędkości silnika - przerwa"  
P0724,"Przetwornik momentu obr./przełącznik B hamulca - wysoki sygnał"  
P0725,"Obwód wejściowy prędkości silnika - usterka"  
P0726,"Obwód wejściowy prędkości silnika - sygnał poza zakresem/wydajność"  
P0727,"Obwód wejściowy prędkości silnika - brak sygnału"  
P0728,"Obwód wejściowy prędkości silnika - przerwa"  
P0730,"Błędne przełożenie biegu"  
P0731,"Błędne przełożenie biegu 1"  
P0732,"Błędne przełożenie biegu 2"

P0733,"Błędne przełożenie biegu 3"  
P0734,"Błędne przełożenie biegu 4"  
P0735,"Błędne przełożenie biegu 5"  
P0736,"Błędne przełożenie biegu wstecznego"  
P0740,"Sprzęgło przetwornika momentu - usterka"  
P0741,"Sprzęgło przetwornika momentu - problemy z osiągnięciem lub zatrzymanie"  
P0742,"Sprzęgło przetwornika momentu - problemy z wciągnięciem"  
P0743,"Sprzęgło przetwornika momentu - usterka elektryczna"  
P0744,"Sprzęgło przetwornika momentu - przerwa"  
P0745,"Elektromagnes/cewka kontroli ciśnienia - usterka"  
P0746,"Elektromagnes/cewka kontroli ciśnienia - problemy z osiągnięciem lub zatrzymanie"  
P0747,"Elektromagnes/cewka kontroli ciśnienia - problemy z wciągnięciem"  
P0748,"Elektromagnes/cewka kontroli ciśnienia - usterka elektryczna"  
P0749,"Elektromagnes/cewka kontroli ciśnienia - przerwa"  
P0750,"Elektromagnes/cewka przesuwu A - usterka"  
P0751,"Elektromagnes/cewka przesuwu A - problemy z osiągnięciem lub zatrzymanie"  
P0752,"Elektromagnes/cewka przesuwu A - zatrzymanie"  
P0753,"Elektromagnes/cewka przesuwu A - usterka elektryczna"  
P0754,"Elektromagnes/cewka przesuwu A - przerwa"  
P0755,"Elektromagnes/cewka przesuwu B - usterka"  
P0756,"Elektromagnes/cewka przesuwu B - problemy z osiągnięciem lub zatrzymanie"  
P0757,"Elektromagnes/cewka przesuwu B - zatrzymanie"  
P0758,"Elektromagnes/cewka przesuwu B - usterka elektryczna"  
P0759,"Elektromagnes/cewka przesuwu B - przerwa"  
P0760,"Elektromagnes/cewka przesuwu C - usterka"  
P0761,"Elektromagnes/cewka przesuwu C - problemy z osiągnięciem lub zatrzymanie"  
P0762,"Elektromagnes/cewka przesuwu C - zatrzymanie"  
P0763,"Elektromagnes/cewka przesuwu C - usterka elektryczna"  
P0764,"Elektromagnes/cewka przesuwu C - przerwa"  
P0765,"Elektromagnes/cewka przesuwu D - usterka"  
P0766,"Elektromagnes/cewka przesuwu D - problemy z osiągnięciem lub zatrzymanie"  
P0767,"Elektromagnes/cewka przesuwu D - zatrzymanie"  
P0768,"Elektromagnes/cewka przesuwu D - usterka elektryczna"  
P0769,"Elektromagnes/cewka przesuwu D - przerwa"  
P0770,"Elektromagnes/cewka przesuwu E - usterka"  
P0771,"Elektromagnes/cewka przesuwu E - problemy z osiągnięciem lub zatrzymanie"  
P0772,"Elektromagnes/cewka przesuwu E - zatrzymanie"  
P0773,"Elektromagnes/cewka przesuwu E - usterka elektryczna"  
P0774,"Elektromagnes/cewka przesuwu E - przerwa"  
P0775,"Układ kontroli ciśnienia /cewka B - usterka"  
P0776,"Układ kontroli ciśnienia /cewka B - problemy z osiągnięciem lub zatrzymanie"  
P0777,"Układ kontroli ciśnienia /cewka B - zatrzymanie"  
P0779,"Układ kontroli ciśnienia /cewka B - przerwa"  
P0780,"usterka przełożenia"  
P0781,"usterka przełożenia 1



**Lista kodów błędów z opisami w j. angielskim.**

P0100 Mass or Volume Air Flow Circuit Malfunction  
P0101 Mass or Volume Air Flow Circuit Range/Performance Problem  
P0102 Mass or Volume Air Flow Circuit Low Input  
P0103 Mass or Volume Air Flow Circuit High Input  
P0104 Mass or Volume Air Flow Circuit Intermittent  
P0105 Manifold Absolute Pressure/Barometric Pressure Circuit Malfunction  
P0106 Manifold Absolute Pressure/Barometric Pressure Circuit Range/Performance Problem  
P0107 Manifold Absolute Pressure/Barometric Pressure Circuit Low Input  
P0108 Manifold Absolute Pressure/Barometric Pressure Circuit High Input  
P0109 Manifold Absolute Pressure/Barometric Pressure Circuit Intermittent  
P0110 Intake Air Temperature Circuit Malfunction  
P0111 Intake Air Temperature Circuit Range/Performance Problem  
P0112 Intake Air Temperature Circuit Low Input  
P0113 Intake Air Temperature Circuit High Input  
P0114 Intake Air Temperature Circuit Intermittent  
P0115 Engine Coolant Temperature Circuit Malfunction  
P0116 Engine Coolant Temperature Circuit Range/Performance Problem  
P0117 Engine Coolant Temperature Circuit Low Input  
P0118 Engine Coolant Temperature Circuit High Input  
P0119 Engine Coolant Temperature Circuit Intermittent  
P0120 Throttle Position Sensor/Switch A Circuit Malfunction  
P0121 Throttle Position Sensor/Switch A Circuit Range/Performance Problem  
P0122 Throttle Position Sensor/Switch A Circuit Low Input  
P0123 Throttle Position Sensor/Switch A Circuit High Input  
P0124 Throttle Position Sensor/Switch A Circuit Intermittent  
P0125 Insufficient Coolant Temperature for Closed Loop Fuel Control; ECT Excessive Time to Closed Loop Fuel Control  
P0126 Insufficient Coolant Temperature for Stable Operation  
P0128 Coolant Thermostat Malfunction  
P0130 O2 Sensor Circuit Malfunction (Bank 1 Sensor 1)  
P0131 O2 Sensor Circuit Low Voltage (Bank 1 Sensor 1)  
P0132 O2 Sensor Circuit High Voltage (Bank 1 Sensor 1)  
P0133 O2 Sensor Circuit Slow Response (Bank 1 Sensor 1)  
P0134 O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 1)  
P0135 O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 1)  
P0136 O2 Sensor Circuit Malfunction (Bank 1 Sensor 2)  
P0137 O2 Sensor Circuit Low Voltage (Bank 1 Sensor 2)  
P0138 O2 Sensor Circuit High Voltage (Bank 1 Sensor 2)  
P0139 O2 Sensor Circuit Slow Response (Bank 1 Sensor 2)  
P0140 O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 2)  
P0141 O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 2)  
P0142 O2 Sensor Circuit Malfunction (Bank 1 Sensor 3)  
P0143 O2 Sensor Circuit Low Voltage (Bank 1 Sensor 3)  
P0144 O2 Sensor Circuit High Voltage (Bank 1 Sensor 3)  
P0145 O2 Sensor Circuit Slow Response (Bank 1 Sensor 3)  
P0146 O2 Sensor Circuit No Activity Detected (Bank 1 Sensor 3)  
P0147 O2 Sensor Heater Circuit Malfunction (Bank 1 Sensor 3)  
P0150 O2 Sensor Circuit Malfunction (Bank 2 Sensor 1)  
P0151 O2 Sensor Circuit Low Voltage (Bank 2 Sensor 1)  
P0152 O2 Sensor Circuit High Voltage (Bank 2 Sensor 1)  
P0153 O2 Sensor Circuit Slow Response (Bank 2 Sensor 1)  
P0154 O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 1)  
P0155 O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 1)  
P0156 O2 Sensor Circuit Malfunction (Bank 2 Sensor 2)  
P0157 O2 Sensor Circuit Low Voltage (Bank 2 Sensor 2)  
P0158 O2 Sensor Circuit High Voltage (Bank 2 Sensor 2)  
P0159 O2 Sensor Circuit Slow Response (Bank 2 Sensor 2)  
P0160 O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 2)  
P0161 O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 2)

P0162 O2 Sensor Circuit Malfunction (Bank 2 Sensor 3)  
P0163 O2 Sensor Circuit Low Voltage (Bank 2 Sensor 3)  
P0164 O2 Sensor Circuit High Voltage (Bank 2 Sensor 3)  
P0165 O2 Sensor Circuit Slow Response (Bank 2 Sensor 3)  
P0166 O2 Sensor Circuit No Activity Detected (Bank 2 Sensor 3)  
P0167 O2 Sensor Heater Circuit Malfunction (Bank 2 Sensor 3)  
P0170 Fuel Trim Malfunction (Bank 1)  
P0171 Fuel Trim too rich (Bank 1)  
P0172 Fuel Trim too Rich (Bank 1)  
P0173 Fuel Trim Malfunction (Bank 2)  
P0174 Fuel Trim too Lean (Bank 2)  
P0175 Fuel Trim too Rich (Bank 2)  
P0176 Fuel Composition Sensor Circuit Malfunction  
P0177 Fuel Composition Sensor Circuit Range/Performance  
P0178 Fuel Composition Sensor Circuit Low Input  
P0179 Fuel Composition Sensor Circuit High Input  
P0180 Fuel Temperature Sensor A Circuit Malfunction  
P0181 Fuel Temperature Sensor A Circuit Range/Performance  
P0182 Fuel Temperature Sensor A Circuit Low Input  
P0183 Fuel Temperature Sensor A Circuit High Input  
P0184 Fuel Temperature Sensor A Circuit Intermittent  
P0185 Fuel Temperature Sensor B Circuit Malfunction  
P0186 Fuel Temperature Sensor B Circuit Range/Performance  
P0187 Fuel Temperature Sensor B Circuit Low Input  
P0188 Fuel Temperature Sensor B Circuit High Input  
P0189 Fuel Temperature Sensor B Circuit Intermittent  
P0190 Fuel Rail Pressure Sensor Circuit Malfunction  
P0191 Fuel Rail Pressure Sensor Circuit Range/Performance  
P0192 Fuel Rail Pressure Sensor Circuit Low Input  
P0193 Fuel Rail Pressure Sensor Circuit High Input  
P0194 Fuel Rail Pressure Sensor Circuit Intermittent  
P0195 Engine Oil Temperature Sensor Malfunction  
P0196 Engine Oil Temperature Sensor Range/Performance  
P0197 Engine Oil Temperature Sensor Low  
P0198 Engine Oil Temperature Sensor High  
P0199 Engine Oil Temperature Sensor Intermittent  
P0200 Injector Circuit Malfunction  
P0201 Injector Circuit Malfunction - Cylinder 1  
P0202 Injector Circuit Malfunction - Cylinder 2  
P0203 Injector Circuit Malfunction - Cylinder 3  
P0204 Injector Circuit Malfunction - Cylinder 4  
P0205 Injector Circuit Malfunction - Cylinder 5  
P0206 Injector Circuit Malfunction - Cylinder 6  
P0207 Injector Circuit Malfunction - Cylinder 7  
P0208 Injector Circuit Malfunction - Cylinder 8  
P0209 Injector Circuit Malfunction - Cylinder 9  
P0210 Injector Circuit Malfunction - Cylinder 10  
P0211 Injector Circuit Malfunction - Cylinder 11  
P0212 Injector Circuit Malfunction - Cylinder 12  
P0213 Cold Start Injector 1 Malfunction  
P0214 Cold Start Injector 2 Malfunction  
P0215 Engine Shutoff Solenoid Malfunction  
P0216 Injection Timing Control Circuit Malfunction  
P0217 Engine Overtemp Condition  
P0218 Transmission Over Temperature Condition  
P0219 Engine Overspeed Condition  
P0220 Throttle/Petal Position Sensor/Switch B Circuit Malfunction  
P0221 Throttle/Petal Position Sensor/Switch B Circuit Range/Performance Problem  
P0222 Throttle/Petal Position Sensor/Switch B Circuit Low Input  
P0223 Throttle/Petal Position Sensor/Switch B Circuit High Input

P0224 Throttle/Petal Position Sensor/Switch B Circuit Intermittent  
P0225 Throttle/Petal Position Sensor/Switch C Circuit Malfunction  
P0226 Throttle/Petal Position Sensor/Switch C Circuit Range/Performance Problem  
P0227 Throttle/Petal Position Sensor/Switch C Circuit Low Input  
P0228 Throttle/Petal Position Sensor/Switch C Circuit High Input  
P0229 Throttle/Petal Position Sensor/Switch C Circuit Intermittent  
P0230 Fuel Pump Primary Circuit Malfunction  
P0231 Fuel Pump Secondary Circuit Low  
P0232 Fuel Pump Secondary Circuit High  
P0233 Fuel Pump Secondary Circuit Intermittent  
P0234 Engine Overboost Condition  
P0235 Turbocharger Boost Sensor A Circuit Malfunction  
P0236 Turbocharger Boost Sensor A Circuit Range/Performance  
P0237 Turbocharger Boost Sensor A Circuit Low  
P0238 Turbocharger Boost Sensor A Circuit High  
P0239 Turbocharger Boost Sensor B Malfunction  
P0240 Turbocharger Boost Sensor B Circuit Range/Performance  
P0241 Turbocharger Boost Sensor B Circuit Low  
P0242 Turbocharger Boost Sensor B Circuit High  
P0243 Turbocharger Wastegate Solenoid A Malfunction  
P0244 Turbocharger Wastegate Solenoid A Range/Performance  
P0245 Turbocharger Wastegate Solenoid A Low  
P0246 Turbocharger Wastegate Solenoid A High  
P0247 Turbocharger Wastegate Solenoid B Malfunction  
P0248 Turbocharger Wastegate Solenoid B Range/Performance  
P0249 Turbocharger Wastegate Solenoid B Low  
P0250 Turbocharger Wastegate Solenoid B High  
P0251 Injection Pump Fuel Metering Control "A" Malfunction (Cam/Rotor/Injector)  
P0252 Injection Pump Fuel Metering Control "A" Range/Performance (Cam/Rotor/Injector)  
P0253 Injection Pump Fuel Metering Control "A" Low (Cam/Rotor/Injector)  
P0254 Injection Pump Fuel Metering Control "A" High (Cam/Rotor/Injector)  
P0255 Injection Pump Fuel Metering Control "A" Intermittent (Cam/Rotor/Injector)  
P0256 Injection Pump Fuel Metering Control "B" Malfunction (Cam/Rotor/Injector)  
P0257 Injection Pump Fuel Metering Control "B" Range/Performance (Cam/Rotor/Injector)  
P0258 Injection Pump Fuel Metering Control "B" Low (Cam/Rotor/Injector)  
P0259 Injection Pump Fuel Metering Control "B" High (Cam/Rotor/Injector)  
P0260 Injection Pump Fuel Metering Control "B" Intermittent (Cam/Rotor/Injector)  
P0261 Cylinder 1 Injector Circuit Low  
P0262 Cylinder 1 Injector Circuit High  
P0263 Cylinder 1 Contribution/Balance Fault  
P0264 Cylinder 2 Injector Circuit Low  
P0265 Cylinder 2 Injector Circuit High  
P0266 Cylinder 2 Contribution/Balance Fault  
P0267 Cylinder 3 Injector Circuit Low  
P0268 Cylinder 3 Injector Circuit High  
P0269 Cylinder 3 Contribution/Balance Fault  
P0270 Cylinder 4 Injector Circuit Low  
P0271 Cylinder 4 Injector Circuit High  
P0272 Cylinder 4 Contribution/Balance Fault  
P0273 Cylinder 5 Injector Circuit Low  
P0274 Cylinder 5 Injector Circuit High  
P0275 Cylinder 5 Contribution/Balance Fault  
P0276 Cylinder 6 Injector Circuit Low  
P0277 Cylinder 6 Injector Circuit High  
P0278 Cylinder 6 Contribution/Balance Fault  
P0279 Cylinder 7 Injector Circuit Low  
P0280 Cylinder 7 Injector Circuit High  
P0281 Cylinder 7 Contribution/Balance Fault  
P0282 Cylinder 8 Injector Circuit Low  
P0283 Cylinder 8 Injector Circuit High

P0284 Cylinder 8 Contribution/Balance Fault  
P0285 Cylinder 9 Injector Circuit Low  
P0286 Cylinder 9 Injector Circuit High  
P0287 Cylinder 9 Contribution/Balance Fault  
P0288 Cylinder 10 Injector Circuit Low  
P0289 Cylinder 10 Injector Circuit High  
P0290 Cylinder 10 Contribution/Balance Fault  
P0291 Cylinder 11 Injector Circuit Low  
P0292 Cylinder 11 Injector Circuit High  
P0293 Cylinder 11 Contribution/Balance Fault  
P0294 Cylinder 12 Injector Circuit Low  
P0295 Cylinder 12 Injector Circuit High  
P0296 Cylinder 12 Contribution/Range Fault  
P0300 Random/Multiple Cylinder Misfire Detected  
P0301 Cylinder 1 Misfire Detected  
P0302 Cylinder 2 Misfire Detected  
P0303 Cylinder 3 Misfire Detected  
P0304 Cylinder 4 Misfire Detected  
P0305 Cylinder 5 Misfire Detected  
P0306 Cylinder 6 Misfire Detected  
P0307 Cylinder 7 Misfire Detected  
P0308 Cylinder 8 Misfire Detected  
P0309 Cylinder 9 Misfire Detected  
P0310 Cylinder 10 Misfire Detected  
P0311 Cylinder 11 Misfire Detected  
P0312 Cylinder 12 Misfire Detected  
P0320 Ignition/Distributor Engine Speed Input Circuit Malfunction  
P0321 Ignition/Distributor Engine Speed Input Circuit Range/Performance  
P0322 Ignition/Distributor Engine Speed Input Circuit No Signal  
P0323 Ignition/Distributor Engine Speed Input Circuit Intermittent  
P0325 Knock Sensor 1 Circuit Malfunction (Bank 1 or Single Sensor)  
P0326 Knock Sensor 1 Circuit Range/Performance (Bank 1 or Single Sensor)  
P0327 Knock Sensor 1 Circuit Low Input (Bank 1 or Single Sensor)  
P0328 Knock Sensor 1 Circuit High Input (Bank 1 or Single Sensor)  
P0329 Knock Sensor 1 Circuit Intermittent (Bank 1 or Single Sensor)  
P0330 Knock Sensor 2 Circuit Malfunction (Bank 2)  
P0331 Knock Sensor 2 Circuit Range/Performance (Bank 2)  
P0332 Knock Sensor 2 Circuit Low Input (Bank 2)  
P0333 Knock Sensor 2 Circuit High Input (Bank 2)  
P0334 Knock Sensor 2 Circuit Intermittent (Bank 2)  
P0335 Crankshaft Position Sensor A Circuit Malfunction  
P0336 Crankshaft Position Sensor A Circuit Range/Performance  
P0337 Crankshaft Position Sensor A Circuit Low Input  
P0338 Crankshaft Position Sensor A Circuit High Input  
P0339 Crankshaft Position Sensor A Circuit Intermittent  
P0340 Camshaft Position Sensor Circuit Malfunction  
P0341 Camshaft Position Sensor Circuit Range/Performance  
P0342 Camshaft Position Sensor Circuit Low Input  
P0343 Camshaft Position Sensor Circuit High Input  
P0344 Camshaft Position Sensor Circuit Intermittent  
P0350 Ignition Coil Primary/Secondary Circuit Malfunction  
P0351 Ignition Coil A Primary/Secondary Circuit Malfunction  
P0352 Ignition Coil B Primary/Secondary Circuit Malfunction  
P0353 Ignition Coil C Primary/Secondary Circuit Malfunction  
P0354 Ignition Coil D Primary/Secondary Circuit Malfunction  
P0355 Ignition Coil E Primary/Secondary Circuit Malfunction  
P0356 Ignition Coil F Primary/Secondary Circuit Malfunction  
P0357 Ignition Coil G Primary/Secondary Circuit Malfunction  
P0358 Ignition Coil H Primary/Secondary Circuit Malfunction  
P0359 Ignition Coil I Primary/Secondary Circuit Malfunction

P0360 Ignition Coil J Primary/Secondary Circuit Malfunction  
P0361 Ignition Coil K Primary/Secondary Circuit Malfunction  
P0362 Ignition Coil L Primary/Secondary Circuit Malfunction  
P0370 Timing Reference High Resolution Signal A Malfunction  
P0371 Timing Reference High Resolution Signal A Too Many Pulses  
P0372 Timing Reference High Resolution Signal A Too Few Pulses  
P0373 Timing Reference High Resolution Signal A Intermittent/Erratic Pulses  
P0374 Timing Reference High Resolution Signal A No Pulses  
P0375 Timing Reference High Resolution Signal B Malfunction  
P0376 Timing Reference High Resolution Signal B Too Many Pulses  
P0377 Timing Reference High Resolution Signal B Too Few Pulses  
P0378 Timing Reference High Resolution Signal B Intermittent/Erratic Pulses  
P0379 Timing Reference High Resolution Signal B No Pulses  
P0380 Glow Plug/Heater Circuit "A" Malfunction  
P0381 Glow Plug/Heater Indicator Circuit Malfunction  
P0382 Exhaust Gas Recirculation Flow Malfunction  
P0385 Crankshaft Position Sensor B Circuit Malfunction  
P0386 Crankshaft Position Sensor B Circuit Range/Performance  
P0387 Crankshaft Position Sensor B Circuit Low Input  
P0388 Crankshaft Position Sensor B Circuit High Input  
P0389 Crankshaft Position Sensor B Circuit Intermittent  
P0400 Exhaust Gas Recirculation Flow Malfunction  
P0401 Exhaust Gas Recirculation Flow Insufficient Detected  
P0402 Exhaust Gas Recirculation Flow Excessive Detected  
P0403 Exhaust Gas Recirculation Circuit Malfunction  
P0404 Exhaust Gas Recirculation Circuit Range/Performance  
P0405 Exhaust Gas Recirculation Sensor A Circuit Low  
P0406 Exhaust Gas Recirculation Sensor A Circuit High  
P0407 Exhaust Gas Recirculation Sensor B Circuit Low  
P0408 Exhaust Gas Recirculation Sensor B Circuit High  
P0410 Secondary Air Injection System Malfunction  
P0411 Secondary Air Injection System Incorrect Flow Detected  
P0412 Secondary Air Injection System Switching Valve A Circuit Malfunction  
P0413 Secondary Air Injection System Switching Valve A Circuit Open  
P0414 Secondary Air Injection System Switching Valve A Circuit Shorted  
P0415 Secondary Air Injection System Switching Valve B Circuit Malfunction  
P0416 Secondary Air Injection System Switching Valve B Circuit Open  
P0417 Secondary Air Injection System Switching Valve B Circuit Shorted  
P0418 Secondary Air Injection System Relay "A" Circuit Malfunction  
P0419 Secondary Air Injection System Relay "B" Circuit Malfunction  
P0420 Catalyst System Efficiency Below Threshold (Bank 1)  
P0421 Warm Up Catalyst Efficiency Below Threshold (Bank 1)  
P0422 Main Catalyst Efficiency Below Threshold (Bank 1)  
P0423 Heated Catalyst Efficiency Below Threshold (Bank 1)  
P0424 Heated Catalyst Temperature Below Threshold (Bank 1)  
P0426 Catalyst Temperature Sensor Range/Performance (Bank 1)  
P0427 Catalyst Temperature Sensor Low Input (Bank 1)  
P0428 Catalyst Temperature Sensor High Input (Bank 1)  
P0430 Catalyst System Efficiency Below Threshold (Bank 2)  
P0431 Warm Up Catalyst Efficiency Below Threshold (Bank 2)  
P0432 Main Catalyst Efficiency Below Threshold (Bank 2)  
P0433 Heated Catalyst Efficiency Below Threshold (Bank 2)  
P0434 Heated Catalyst Temperature Below Threshold (Bank 2)  
P0436 Catalyst Temperature Sensor Range/Performance (Bank 2)  
P0437 Catalyst Temperature Sensor Low Input (Bank 2)  
P0438 Catalyst Temperature Sensor High Input (Bank 2)  
P0440 Evaporative Emission Control System Malfunction  
P0441 Evaporative Emission Control System Incorrect Purge Flow  
P0442 Evaporative Emission Control System Leak Detected (small leak)  
P0443 Evaporative Emission Control System Purge Control Valve Circuit Malfunction

P0444 Evaporative Emission Control System Purge Control Valve Circuit Open  
P0445 Evaporative Emission Control System Purge Control Valve Circuit Shorted  
P0446 Evaporative Emission Control System Vent Control Circuit Malfunction  
P0447 Evaporative Emission Control System Vent Control Circuit Open  
P0448 Evaporative Emission Control System Vent Control Circuit Shorted  
P0449 Evaporative Emission Control System Vent Valve/Solenoid Circuit Malfunction  
P0450 Evaporative Emission Control System Pressure Sensor Malfunction  
P0451 Evaporative Emission Control System Pressure Sensor Range/Performance  
P0452 Evaporative Emission Control System Pressure Sensor Low Input  
P0453 Evaporative Emission Control System Pressure Sensor High Input  
P0454 Evaporative Emission Control System Pressure Sensor Intermittent  
P0455 Evaporative Emission Control System Leak Detected (gross leak)  
P0460 Fuel Level Sensor Circuit Malfunction  
P0461 Fuel Level Sensor Circuit Range/Performance  
P0462 Fuel Level Sensor Circuit Low Input  
P0463 Fuel Level Sensor Circuit High Input  
P0464 Fuel Level Sensor Circuit Intermittent  
P0465 Purge Flow Sensor Circuit Malfunction  
P0466 Purge Flow Sensor Circuit Range/Performance  
P0467 Purge Flow Sensor Circuit Low Input  
P0468 Purge Flow Sensor Circuit High Input  
P0469 Purge Flow Sensor Circuit Intermittent  
P0470 Exhaust Pressure Sensor Malfunction  
P0471 Exhaust Pressure Sensor Range/Performance  
P0472 Exhaust Pressure Sensor Low  
P0473 Exhaust Pressure Sensor High  
P0474 Exhaust Pressure Sensor Intermittent  
P0475 Exhaust Pressure Control Valve Malfunction  
P0476 Exhaust Pressure Control Valve Range/Performance  
P0477 Exhaust Pressure Control Valve Low  
P0478 Exhaust Pressure Control Valve High  
P0479 Exhaust Pressure Control Valve Intermittent  
P0480 Cooling Fan 1 Control Circuit Malfunction  
P0481 Cooling Fan 2 Control Circuit Malfunction  
P0482 Cooling Fan 3 Control Circuit Malfunction  
P0483 Cooling Fan Rationality Check Malfunction  
P0484 Cooling Fan Circuit Over Current  
P0485 Cooling Fan Power/Ground Circuit Malfunction  
P0500 Vehicle Speed Sensor Malfunction  
P0501 Vehicle Speed Sensor Range/Performance  
P0502 Vehicle Speed Sensor Low Input  
P0503 Vehicle Speed Sensor Intermittent/Erratic/High  
P0505 Idle Control System Malfunction  
P0506 Idle Control System RPM Lower Than Expected  
P0507 Idle Control System RPM Higher Than Expected  
P0510 Closed Throttle Position Switch Malfunction  
P0520 Engine Oil Pressure Sensor/Switch Circuit Malfunction  
P0521 Engine Oil Pressure Sensor/Switch Circuit Range/Performance  
P0522 Engine Oil Pressure Sensor/Switch Circuit Low Voltage  
P0523 Engine Oil Pressure Sensor/Switch Circuit High Voltage  
P0530 A/C Refrigerant Pressure Sensor Circuit Malfunction  
P0531 A/C Refrigerant Pressure Sensor Circuit Range/Performance  
P0532 A/C Refrigerant Pressure Sensor Circuit Low Input  
P0533 A/C Refrigerant Pressure Sensor Circuit High Input  
P0534 Air Conditioner Refrigerant Charge Loss  
P0550 Power Steering Pressure Sensor Circuit Malfunction  
P0551 Power Steering Pressure Sensor Circuit Range/Performance  
P0552 Power Steering Pressure Sensor Circuit Low Input  
P0553 Power Steering Pressure Sensor Circuit High Input  
P0554 Power Steering Pressure Sensor Circuit Intermittent

P0560 System Voltage Malfunction  
P0561 System Voltage Unstable  
P0562 System Voltage Low  
P0562 A/C pressure sensor low voltage(Chrysler)  
P0563 System Voltage High  
P0565 Cruise Control On Signal Malfunction  
P0566 Cruise Control Off Signal Malfunction  
P0567 Cruise Control Resume Signal Malfunction  
P0568 Cruise Control Set Signal Malfunction  
P0569 Cruise Control Coast Signal Malfunction  
P0570 Cruise Control Accel Signal Malfunction  
P0571 Cruise Control/Brake Switch A Circuit Malfunction  
P0572 Cruise Control/Brake Switch A Circuit Low  
P0573 Cruise Control/Brake Switch A Circuit High  
P0574 Cruise Control Related Malfunction  
P0575 Cruise Control Related Malfunction  
P0576 Cruise Control Related Malfunction  
P0576 Cruise Control Related Malfunction  
P0578 Cruise Control Related Malfunction  
P0579 Cruise Control Related Malfunction  
P0580 Cruise Control Related Malfunction  
P0600 Serial Communication Link Malfunction  
P0601 Control Module Read Only Memory(ROM)  
P0602 Control Module Programming Error  
P0603 Internal Control Module Keep Alive Memory (KAM) Error  
P0604 Internal Control Module Random Access Memory (RAM) Error  
P0605 Internal Control Module Read Only Memory (ROM) Error  
P0606 PCM Processor Fault  
P0608 Control Module VSS Output "A" Malfunction  
P0609 Control Module VSS Output "B" Malfunction  
P0620 Generator Control Circuit Malfunction  
P0621 Generator Lamp "L" Control Circuit Malfunction  
P0622 Generator Field "F" Control Circuit Malfunction  
P0650 Malfunction Indicator Lamp (MIL) Control Circuit Malfunction  
P0654 Engine RPM Output Circuit Malfunction  
P0655 Engine Hot Lamp Output Control Circuit Malfunction  
P0656 Fuel Level Output Circuit Malfunction  
P0700 Transmission Control System Malfunction  
P0701 Transmission Control System Range/Performance  
P0702 Transmission Control System Electrical  
P0703 Torque Converter/Brake Switch B Circuit Malfunction  
P0704 Clutch Switch Input Circuit Malfunction  
P0705 Transmission Range Sensor Circuit malfunction (PRNDL Input)  
P0706 Transmission Range Sensor Circuit Range/Performance  
P0707 Transmission Range Sensor Circuit Low Input  
P0708 Transmission Range Sensor Circuit High Input  
P0709 Transmission Range Sensor Circuit Intermittent  
P0710 Transmission Fluid Temperature Sensor Circuit Malfunction  
P0711 Transmission Fluid Temperature Sensor Circuit Range/Performance  
P0712 Transmission Fluid Temperature Sensor Circuit Low Input  
P0713 Transmission Fluid Temperature Sensor Circuit High Input  
P0714 Transmission Fluid Temperature Sensor Circuit Intermittent  
P0715 Input/Turbine Speed Sensor Circuit Malfunction  
P0716 Input/Turbine Speed Sensor Circuit Range/Performance  
P0717 Input/Turbine Speed Sensor Circuit No Signal  
P0718 Input/Turbine Speed Sensor Circuit Intermittent  
P0719 Torque Converter/Brake Switch B Circuit Low  
P0720 Output Speed Sensor Circuit Malfunction  
P0721 Output Speed Sensor Range/Performance  
P0722 Output Speed Sensor No Signal

P0723 Output Speed Sensor Intermittent  
P0724 Torque Converter/Brake Switch B Circuit High  
P0725 Engine Speed input Circuit Malfunction  
P0726 Engine Speed Input Circuit Range/Performance  
P0727 Engine Speed Input Circuit No Signal  
P0728 Engine Speed Input Circuit Intermittent  
P0730 Incorrect Gear Ratio  
P0731 Gear 1 Incorrect ratio  
P0732 Gear 2 Incorrect ratio  
P0733 Gear 3 Incorrect ratio  
P0734 Gear 4 Incorrect ratio  
P0735 Gear 5 Incorrect ratio  
P0736 Reverse incorrect gear ratio  
P0740 Torque Converter Clutch Circuit Malfunction  
P0741 Torque Converter Clutch Circuit Performance or Stuck Off  
P0742 Torque Converter Clutch Circuit Stuck On  
P0743 Torque Converter Clutch Circuit Electrical  
P0744 Torque Converter Clutch Circuit Intermittent  
P0745 Pressure Control Solenoid Malfunction  
P0746 Pressure Control Solenoid Performance or Stuck Off  
P0747 Pressure Control Solenoid Stuck On  
P0748 Pressure Control Solenoid Electrical  
P0749 Pressure Control Solenoid Intermittent  
P0750 Shift Solenoid A Malfunction  
P0751 Shift Solenoid A Performance or Stuck Off/1-2 Shift Solenoid Valve Performance  
P0752 Shift Solenoid A Stuck On  
P0753 Shift Solenoid A Electrical/1-2 Shift Solenoid Circuit Electrical  
P0754 Shift Solenoid A Intermittent  
P0755 Shift Solenoid B Malfunction  
P0756 Shift Solenoid B Performance or Stuck Off/2-3 Shift Solenoid Valve Performance  
P0757 Shift Solenoid B Stuck On  
P0758 Shift Solenoid B Electrical/2-3 Shift Solenoid Circuit Electrical  
P0759 Shift Solenoid B Intermittent  
P0760 Shift Solenoid C Malfunction  
P0761 Shift Solenoid C Performance or Stuck Off  
P0762 Shift Solenoid C Stuck On  
P0763 Shift Solenoid C Electrical  
P0764 Shift Solenoid C Intermittent  
P0765 Shift Solenoid D Malfunction  
P0766 Shift Solenoid D Performance or Stuck Off  
P0767 Shift Solenoid D Stuck On  
P0768 Shift Solenoid D Electrical  
P0769 Shift Solenoid D Intermittent  
P0770 Shift Solenoid E Malfunction  
P0771 Shift Solenoid E Performance or Stuck Off  
P0772 Shift Solenoid E Stuck On  
P0773 Shift Solenoid E Electrical  
P0774 Shift Solenoid E Intermittent  
P0775 Pressure Control Solenoid B Malfunction  
P0776 Pressure Control Solenoid B Performance  
P0777 Pressure Control Solenoid B Stuck On  
P0778 Pressure Control Solenoid B Electrical  
P0779 Pressure Control Solenoid B Intermittent  
P0780 Shift Malfunction  
P0781 1-2 Shift Malfunction  
P0782 2-3 Shift Malfunction  
P0783 3-4 Shift Malfunction  
P0784 4-5 Shift Malfunction  
P0785 Shift/Timing Solenoid Malfunction/ 3-2 Shift Solenoid Circuit Electrical  
P0786 Shift/Timing Solenoid Range/Performance



P0787 Shift/Timing Solenoid Low  
P0788 Shift/Timing Solenoid High  
P0789 Shift/Timing Solenoid Intermittent  
P0790 Normal/Performance Switch Circuit Malfunction  
P0801 Reverse Inhibit Control Circuit Malfunction  
P0803 1-4 Upshift (Skip Shift) Solenoid Control Circuit Malfunction  
P0804 1-4 Upshift (Skip Shift) Lamp Control Circuit Malfunction  
P1100 MAF Sensor Intermittent/ Check of all OBDII Systems Not Complete  
P1101 MAF Sensor Out Of Self Test Range./KOER Not Able To Complete KOER Aborted  
P1102 MAF Sensor In Range But Lower Than Expected  
P1103 MAF Sensor In Range But Higher Than Expected  
P1104 MAF Ground Malfunction  
P1105 Dual Alternator Upper Fault  
P1106 Dual Alternator Lower Fault/ Manifold Absolute Pressure (MAP) Sensor Circuit Intermittent High Voltage  
P1107 Dual Alternator Lower Circuit Malfunction/ Manifold Absolute Pressure (MAP) Sensor Circuit Intermittent Low Voltage  
P1108 Dual Alternator Battery Lamp Circuit Malfunction  
P1109 IAT - B Sensor Intermittent  
P1110 IAT Sensor (D/C) Open/Short  
P1111 Intake Air Temperature (IAT) Sensor Circuit Intermittent High Voltage  
P1112 Intake Air Temperature (IAT) Sensor Circuit Intermittent Low Voltage  
P1113 IAT Sensor Open/Short  
P1114 Engine Coolant Temperature (ECT) Sensor Circuit Intermittent Low Voltage/IAT - B Circuit Low Input  
P1115 Engine Coolant Temperature (ECT) Sensor Circuit Intermittent High Voltage/IAT - B Circuit High Input  
P1116 Engine Coolant sensor out of range/ECT Sensor Out Of Self Test Range  
P1117 Engine Coolant Sensor intermittent/ECT Sensor Intermittent  
P1118 Manifold Absolute Temperature Circuit Low Input  
P1119 Manifold Absolute Temperature Circuit High Input  
P1120 Throttle position sensor out of range  
P1121 Throttle Position (TP) Sensor Circuit Intermittent High Voltage  
P1122 Throttle Position (TP) Sensor Circuit Intermittent Low Voltage  
P1123 Throttle Position Sensor In Range But Higher Than Expected  
P1124 Throttle Position Sensor Out Of Self Test Range  
P1125 Throttle position sensor intermittent  
P1126 Throttle Position (Narrow Range) Sensor Circuit Malfunction  
P1127 Exhaust Not Warm, Downstream O2 Sensor  
P1128 Upstream Heated O2 Sensors Swapped  
P1129 Downstream Heated O2 Sensors Swapped  
P1130 Lack Of HO2S Switch - Adaptive Fuel At Limit  
P1131 Lack Of HO2S Switch - Sensor Indicates Lean  
P1132 Lack Of HO2S Switch - Sensor Indicates Rich  
P1133 HO2S Insufficient Switching Sensor 1  
P1134 HO2S Transition Time Ratio Sensor 1  
P1135 Pedal Position Sensor A Circuit Intermittent  
P1136 Fan Control Circuit Malfunction  
P1137 Lack Of HO2S Switch - Sensor Indicates Lean  
P1138 Lack Of HO2S12 Switch - Sensor Indicates Rich  
P1139 Water In Fuel Indicator Circuit Malfunction  
P1140 Water In Fuel Condition  
P1141 Fuel Restriction Indicator Circuit Malfunction  
P1142 Fuel Restriction Condition  
P1143 Air Assist Control Valve Range/Performance  
P1144 Air Assist Control Valve Circuit Malfunction  
P1150 Lack Of HO2S21 Switch - Adaptive Fuel At Limit  
P1151 Lack Of HO2S21 Switch - Sensor Indicates Lean  
P1152 Lack Of HO2S21 Switch - Sensor Indicates Rich  
P1153 Bank 2 Fuel Control Shifted Lean  
P1154 Bank 2 Fuel Control Shifted Rich  
P1155 Alternative Fuel Controller

P1156 Fuel Select Switch Malfunction  
P1157 Lack Of HO2S22 Switch - Sensor Indicates Lean  
P1158 Lack Of HO2S22 Switch - Sensor Indicates Rich  
P1159 Fuel Stepper Motor Malfunction  
P1167 Invalid Test,throttle not depressed  
P1168 Fuel Rail Sensor In-Range Low Failure  
P1169 Fuel Rail Sensor In-Range High Failure  
P1170 ESO - Engine Shut Off Solenoid Fault  
P1171 Rotor Sensor Fault  
P1172 Rotor Control Fault  
P1173 Rotor Calibration Fault  
P1174 Cam Sensor Fault  
P1175 Cam Control Fault  
P1176 Cam Calibration Fault  
P1177 Synchronization Fault  
P1178 ( open )  
P1180 Fuel Delivery System Malfunction - Low  
P1181 Fuel Delivery System Malfunction - High  
P1182 Fuel Shut Off Solenoid Malfunction  
P1183 Engine Oil Temperature Circuit Malfunction  
P1184 Engine Oil Temperature Out Of Self Test Range  
P1185 FTS High - Fuel Pump Temperature Sensor High  
P1186 FTS Low - Fuel Pump Temperature Sensor Low  
P1187 Variant Selection  
P1188 Calibration Memory Fault  
P1189 Pump Speed Signal Fault  
P1190 Calibration Resistor Out Of Range  
P1191 Key Line Voltage  
P1192 Voltage External  
P1193 EGR Drive Overcurrent  
P1194 ECU A/D Converter  
P1195 SCP HBCC Failed To Initialize  
P1196 Key Off Voltage High  
P1197 Key Off Voltage Low  
P1198 Pump Rotor Control Underfueling  
P1199 Fuel Level Input Circuit Low  
P1200 Injector Control Circuit  
P1201 Injector Circuit Open / Shorted - Cylinder #1  
P1202 Injector Circuit Open / Shorted - Cylinder #2  
P1203 Injector Circuit Open / Shorted - Cylinder #3  
P1204 Injector Circuit Open / Shorted - Cylinder #4  
P1205 Injector Circuit Open / Shorted - Cylinder #5  
P1206 Injector Circuit Open / Shorted - Cylinder #6  
P1209 Injector Control Pressure System Fault  
P1210 Injector Control Pressure Above Expected Level  
P1211 Injector Control Pressure Sensor Above / Below Desired  
P1212 Injector Control Pressure Not Detected During Crank  
P1213 Start Injector Circuit Malfunction  
P1214 Pedal Position Sensor B Circuit Intermittent  
P1215 Pedal Position Sensor C Circuit Low Input  
P1216 Pedal Position Sensor C Circuit High Input  
P1217 Pedal Position Sensor C Circuit Intermittent  
P1218 CID High  
P1219 CID Low  
P1220 Series Throttle Control System Malfunction  
P1221 Traction Control System Malfunction  
P1222 Traction Control Output Circuit Malfunction  
P1223 Pedal Demand Sensor B Circuit High Input  
P1224 Throttle Position Sensor B Out Of Self Test Range  
P1225 Needle Lift Sensor Malfunction

P1226 Control Sleeve Sensor Malfunction  
P1227 Wastegate Failed Closed (Over Pressure)  
P1228 Wastegate Failed Open (Under Pressure)  
P1229 Intercooler Pump Driver Fault  
P1230 Fuel Pump Low Speed Malfunction  
P1231 Fuel Pump Secondary Circuit Low, High Speed  
P1232 Fuel Pump Speed Primary Circuit Malfunction  
P1233 Fuel Pump Driver Module Off Line  
P1234 Fuel Pump Driver Module Off Line  
P1235 Fuel Pump Control Out Of Range  
P1236 Fuel Pump Control Out Of Range  
P1237 Fuel Pump Secondary Circuit Malfunction  
P1238 Fuel Pump Secondary Circuit Malfunction  
P1239 Speed Fuel Pump Positive Feed Fault  
P1240 Sensor Power Supply Malfunction  
P1241 Sensor Power Supply Low Input  
P1242 Sensor Power Supply High Input  
P1243 Second Fuel Pump Faulty or Ground Fault  
P1244 Alternator Load Input Failed High  
P1245 Alternator Load Input Failed Low  
P1246 Alternator Load Input Failed  
P1247 Turbo Boost Pressure Low  
P1248 Turbo Boost Pressure Not Detected  
P1249 Wastegate Control Valve Performance  
P1250 PRC Solenoid Circuit Malfunction  
P1251 Air Mixture Solenoid Circuit Malfunction  
P1252 Pedal Correlation PDS1 and LPDS High  
P1253 Pedal Correlation PDS1 and LPDS Low  
P1254 Pedal Correlation PDS2 and LPDS High  
P1255 Pedal Correlation PDS2 and LPDS Low  
P1256 Pedal Correlation PDS1 and HPDS  
P1257 Pedal Correlation PDS2 and HPDS  
P1258 Pedal Correlation PDS1 and PDS2  
P1259 Immobilizer to PCM Signal Error  
P1260 THEFT Detected, Vehicle Immobilized  
P1261 Cylinder #1 High To Low Side Short  
P1262 Cylinder #2 High To Low Side Short  
P1263 Cylinder #3 High To Low Side Short  
P1264 Cylinder #4 High To Low Side Short  
P1265 Cylinder #5 High To Low Side Short  
P1266 Cylinder #6 High To Low Side Short  
P1267 Cylinder #7 High To Low Side Short  
P1268 Cylinder #8 High To Low Side Short  
P1269 Immobilizer Code Not Programmed  
P1270 Engine RPM Or Speed Limiter Reached  
P1271 Cylinder #1 High To Low Side Open  
P1272 Cylinder #2 High To Low Side Open  
P1273 Cylinder #3 High To Low Side Open  
P1274 Cylinder #4 High To Low Side Open  
P1275 Cylinder #5 High To Low Side Open  
P1276 Cylinder #6 High To Low Side Open  
P1277 Cylinder #7 High To Low Side Open  
P1278 Cylinder #8 High To Low Side Open  
P1280 Injection Control Pressure Out Of Range Low  
P1281 Injection Control Pressure Out Of Range High  
P1282 Excessive Injection Control Pressure  
P1283 IPR Circuit Failure  
P1284 Aborted KOER - ICP Failure  
P1285 Cylinder head over temp sensed  
P1286 Fuel Pulse In Range But Lower Than Expected

P1287 Fuel Pulse In Range But Higher Than Expected  
P1288 Cylinder Head Temp Sensor Out Of Self Test Range  
P1289 Cylinder Head Temp Sensor High Input  
P1290 Cylinder Head Temp Sensor Low Input  
P1291 Injector High Side Short To GND Or VBATT - Bank 1  
P1292 Injector High Side Short To GND Or VBATT - Bank 2  
P1293 Injector High Side Open - Bank 1  
P1294 Injector High Side Open - Bank 2/Target idle not reached  
P1295 Multi-faults - Bank 1 - With Low Side Shorts  
P1296 Multi-faults - Bank 2 - With Low Side Shorts  
P1297 Injector High Sides Shorted Together  
P1298 IDM Failure  
P1299 Cylinder Head Overtemperature Protection Active  
P1300 Boost Calibration Fault  
P1301 Boost Calibration High  
P1302 Boost Calibration Low  
P1303 EGR Calibration Fault  
P1304 EGR Calibration High  
P1305 EGR Calibration Low  
P1306 Kickdown Relay Pull - In Circuit Fault  
P1307 Kickdown Relay Hold Circuit Fault  
P1308 A/C Clutch Circuit Fault  
P1309 Misfire Monitor AICE Chip Fault  
P1313 Misfire Rate Catalyst Damage Fault - Bank 1  
P1314 Misfire Rate Catalyst Damage Fault - Bank 2  
P1315 Persistent Misfire  
P1316 Injector Circuit / IDM Codes Detected  
P1317 Injector Circuit / IDM Codes Not Updated  
P1336 Crank / Cam Sensor Range / Performance  
P1340 Camshaft Position Sensor B Circuit Malfunction  
P1341 Camshaft Position Sensor B Range / Performance  
P1345 SGC (Cam Position) Sensor Circuit Malfunction/ Crankshaft Position - Camshaft Position Correlation  
P1346 Fuel Level Sensor B Circuit Malfunction  
P1347 Fuel Level Sensor B Range / Performance  
P1348 Fuel Level Sensor B Circuit Low  
P1349 Fuel Level Sensor B Circuit High  
P1350 Fuel Level Sensor B Intermittent/Bypass Line Monitor  
P1351 IDM Input Circuit Malfunction/ Ignition Coil Control Circuit High Voltage  
P1352 Ignition Coil A Primary Circuit Malfunction  
P1353 Ignition Coil B Primary Circuit Malfunction  
P1354 Ignition Coil C Primary Circuit Malfunction  
P1355 Ignition Coil D Primary Circuit Malfunction  
P1360 Ignition Coil A Secondary Circuit Malfunction  
P1361 Ignition Control (IC) Circuit Low Voltage  
P1362 Ignition Coil C Secondary Circuit Malfunction  
P1363 Ignition Coil D Secondary Circuit Malfunction  
P1364 Ignition Coil Primary Circuit Failure  
P1365 Ignition Coil Secondary Circuit Failure  
P1366 Ignition Spare  
P1367 Ignition Spare  
P1368 Ignition Spare  
P1369 Engine Temperature Light Monitor Failure  
P1370 Insufficient RMP Increase During Spark Test  
P1371 Ignition Coil - Cylinder 1 - Early Activation Fault  
P1372 Ignition Coil - Cylinder 2 - Early Activation Fault  
P1373 Ignition Coil - Cylinder 3 - Early Activation Fault  
P1374 Crankshaft Position (CKP)/Ignition Coil - Cylinder 4 - Early Activation Fault  
P1375 Ignition Coil - Cylinder 5 - Early Activation Fault  
P1376 Ignition Coil - Cylinder 6 - Early Activation Fault  
P1380 Misfire Detected - Rough Road Data Not Available

P1381 Variable Cam Timing Overadvanced (Bank #1)/ Misfire Detected - No Communication with BCM  
P1382 Variable Cam Timing Solenoid #1 Circuit Malfunction  
P1383 Variable Cam Timing Overretarded (Bank #1)  
P1384 VVT Solenoid A Malfunction  
P1385 Variable Cam Timing Solenoid B Malfunction  
P1386 Variable Cam Timing Overadvanced (Bank #2)  
P1387 Variable Cam Timing Solenoid #2 Circuit Malfunction  
P1388 Variable Cam Timing Overretarded (Bank #2)  
P1389 Glow Plug Circuit High Side Low Input  
P1390 Octane Adjust Pin Out Of Self Test Range  
P1391 Glow Plug Circuit Low Input (Bank #1)  
P1392 Glow Plug Circuit High Input (Bank #1)  
P1393 Glow Plug Circuit Low Input (Bank #2)  
P1394 Glow Plug Circuit High Input (Bank #2)  
P1395 Glow Plug Monitor Fault (Bank #1)  
P1396 Glow Plug Monitor Fault (Bank #2)  
P1397 System Voltage Out Of Self Test Range  
P1398 VVT Solenoid B Circuit High Input  
P1399 Glow Plug Circuit High Side, High Input  
P1400 DPFE Circuit Low Input  
P1401 DPFE Circuit High Input  
P1402 EGR Metering Orifice Restricted  
P1403 DPFE Sensor Hoses Reversed  
P1404 IAT - B Circuit Malfunction/ Exhaust Gas Recirculation Closed Position Performance  
P1405 DPFE Sensor Upstream Hose Off Or Plugged  
P1406 Exhaust Gas Recirculation (EGR) Position Sensor Performance  
P1407 EGR No Flow Detected  
P1408 EGR Flow Out Of Self Test Range  
P1409 EVR Control Circuit Malfunction  
P1411 SAI System Incorrect Downstream Flow Detected  
P1413 SAI System Monitor Circuit Low Input  
P1414 SAI System Monitor Circuit High Input  
P1415 Air Pump Circuit Malfunction/ (AIR) System Bank 1  
P1416 Port Air Circuit Malfunction/ (AIR) System Bank 2  
P1417 Port Air Relief Circuit Malfunction  
P1418 Split Air #1 Circuit Malfunction  
P1419 Split Air #2 Circuit Malfunction  
P1420 Catalyst Temperature Sensor Failure  
P1421 Catalyst Damage  
P1422 EGI Temperature Sensor Failure  
P1423 EGI Functionality Test Failed  
P1424 EGI Glow Plug Primary Failure  
P1425 EGI Glow Plug Secondary Failure  
P1426 EGI Mini - MAF Failed Out Of Range  
P1427 EGI Mini - MAF Failed Short Circuit  
P1428 EGI Mini - MAF Failed Open Circuit  
P1429 Electric Air Pump Primary Failure  
P1430 Electric Air Pump Secondary Failure  
P1433 A/C Refrigerant Temperature Circuit Low  
P1434 A/C Refrigerant Temperature Circuit High  
P1435 A/C Refrigerant Temperature Circuit Range/Performance  
P1436 A/C Evaporator Air Temperature Circuit Low  
P1437 A/C Evaporator Air Temperature Circuit High  
P1438 A/C Evaporator Air Temperature Circuit Range/Performance  
P1439 Floor Temperature Switch Circuit Malfunction  
P1440 Purge Valve Stuck Open  
P1441 Evaporative Emission (EVAP) System Flow During Non-Purge Chevrolet Only  
P1441 Evaporative Emission (EVAP) System Flow During Non-Purge Oldsmobile Only  
P1442 Evaporative Emission Control System Leak Detected  
P1443 Evaporative Emission Control System Control Valve

P1444 Purge Flow Sensor Circuit Low Input  
P1445 Purge Flow Sensor Circuit High Input  
P1446 Evaporative Vac Solenoid Circuit Malfunction  
P1447 ELC System Closure Valve Flow Fault  
P1448 ELC System 2 Fault  
P1449 Evaporative Check Solenoid Circuit Malfunction  
P1450 Unable To Bleed Up Fuel Tank Vacuum  
P1451 Evap Emission Control Sys Vent Control Valve Circuit  
P1452 Unable To Bleed - Up Vacuum in Tank  
P1453 Fuel Tank Pressure Relief Valve Malfunction  
P1454 Evaporative System Vacuum Test Malfunction  
P1455 Evap Emission Control Sys Leak Detected (Gross Leak/No Flow)  
P1456 Fuel Tank Temperature Sensor Circuit Malfunction  
P1457 Unable To Pull Vacuum In Tank  
P1460 Wide open throttle A/C cutoff relay circuit  
P1461 A/C pressure sensor circuit vol

B1200 Climate Control Pushbutton Circuit Failure  
B1201 Fuel Sender Circuit Failure  
B1202 Fuel Sender Circuit Open  
B1203 Fuel Sender Circuit Short To Battery  
B1204 Fuel Sender Circuit Short To Ground  
B1205 EIC Switch-1 Assembly Circuit Failure  
B1206 EIC Switch-1 Assembly Circuit Open  
B1207 EIC Switch-1 Assembly Circuit Short To Battery  
B1208 EIC Switch-1 Assembly Circuit Short To Ground  
B1209 EIC Switch-2 Assembly Circuit Failure  
B1210 EIC Switch-2 Assembly Circuit Open  
B1211 EIC Switch-2 Assembly Circuit Short To Battery  
B1212 EIC Switch-2 Assembly Circuit Short To Ground  
B1213 Anti-Theft Number of Programmed Keys Is Below Minimum  
B1214 Running Board Lamp Circuit Failure  
B1215 Running Board Lamp Circuit Short to Battery  
B1216 Emergency & Road Side Assistance Switch Circuit Short to Ground  
B1217 Horn Relay Coil Circuit Failure  
B1218 Horn Relay Coil Circuit Short to Vbatt  
B1219 Fuel Tank Pressure Sensor Circuit Failure  
B1220 Fuel Tank Pressure Sensor Circuit Open  
B1222 Fuel Temperature Sensor #1 Circuit Failure  
B1223 Fuel Temperature Sensor #1 Circuit Open  
B1224 Fuel Temperature Sensor #1 Circuit Short to Battery  
B1225 Fuel Temperature Sensor #1 Circuit Short to Ground  
B1226 Fuel Temperature Sensor #2 Circuit Failure  
B1227 Fuel Temperature Sensor #2 Circuit Open  
B1228 Fuel Temperature Sensor #2 Circuit Short to Battery  
B1229 Fuel Temperature Sensor #2 Circuit Short to Ground  
B1231 Longitudinal Acceleration Threshold Exceeded  
B1232 See Manufacturer  
B1233 Glass Break Sensor Failure  
B1234 Mirror Switch Invalid Code  
B1235 Window Feedback Failure  
B1236 Window Feedback Loss of Signal  
B1237 Window Feedback Out of Range  
B1238 Over Temperature Fault  
B1239 Air Flow Blend Door Driver Circuit Failure  
B1240 Wiper Washer Rear Pump Relay Circuit Failure  
B1241 Wiper Washer Rear Pump Relay Circuit Short to Battery  
B1242 Air Flow Recirculation Door Driver Circuit Failure  
B1243 Express Window Down Switch Circuit Short to Battery  
B1244 Wiper Rear Motor Run Relay Circuit Failure

B1245 Wiper Rear Motor Run Relay Circuit Short to Battery  
B1246 Dim Panel Potentiometer Switch Circuit Failure  
B1247 Panel Dim Switch Circuit Open  
B1248 Passenger's Seatback Autoglide Rearward Switch Circuit Short to Ground  
B1249 Blend Door Failure  
B1250 Air Temperature Internal Sensor Circuit Failure  
B1251 Air Temperature Internal Sensor Circuit Open  
B1252 Air Temperature Internal Sensor Circuit Short To Battery  
B1253 Air Temperature Internal Sensor Circuit Short To Ground  
B1254 Air Temperature External Sensor Circuit Failure  
B1255 Air Temperature External Sensor Circuit Open  
B1256 Air Temperature External Sensor Circuit Short To Battery  
B1257 Air Temperature External Sensor Circuit Short To Ground  
B1258 Solar Radiation Sensor Circuit Failure  
B1259 Solar Radiation Sensor Circuit Open  
B1260 Solar Radiation Sensor Circuit Short To Battery  
B1261 Solar Radiation Sensor Circuit Short To Ground  
B1262 Servo Motor Defrost Circuit Failure  
B1263 Servo Motor Vent Circuit Failure  
B1264 Servo Motor Foot Circuit Failure  
B1265 Servo Motor Coolair Bypass Circuit Failure  
B1266 Servo Motor Airintake Left Circuit Failure  
B1267 Servo Motor Airintake Right Circuit Failure  
B1268 Servo Motor Potentiometer Defrost Circuit Failure  
B1269 Servo Motor Potentiometer Defrost Circuit Open  
B1270 Servo Motor Potentiometer Defrost Circuit Short To Battery  
B1271 Servo Motor Potentiometer Defrost Circuit Short To Ground  
B1272 Servo Motor Potentiometer Vent Circuit Failure  
B1273 Servo Motor Potentiometer Vent Circuit Open  
B1274 Servo Motor Potentiometer Vent Circuit Short To Battery  
B1275 Servo Motor Potentiometer Vent Circuit Short To Ground  
B1276 Servo Motor Potentiometer Foot Circuit Failure  
B1277 Servo Motor Potentiometer Foot Circuit Open  
B1278 Servo Motor Potentiometer Foot Circuit Short To Battery  
B1279 Servo Motor Potentiometer Foot Circuit Short To Ground  
B1280 Servo Motor Potentiometer Coolair Circuit Failure  
B1281 Servo Motor Potentiometer Coolair Circuit Open  
B1282 Servo Motor Potentiometer Coolair Circuit Short To Battery  
B1283 Servo Motor Potentiometer Coolair Circuit Short To Ground  
B1284 Servo Motor Potentiometer Airintake Left Circuit Failure  
B1285 Servo Motor Potentiometer Airintake Left Circuit Open  
B1286 Servo Motor Potentiometer Airintake Left Circuit Short To Battery  
B1287 Servo Motor Potentiometer Airintake Left Circuit Short To Ground  
B1288 Servo Motor Potentiometer Airintake Right Circuit Failure  
B1289 Servo Motor Potentiometer Airintake Right Circuit Open  
B1290 Servo Motor Potentiometer Airintake Right Circuit Short To Battery  
B1291 Servo Motor Potentiometer Airintake Right Circuit Short To Ground  
B1292 Battery Power Relay Circuit Failure  
B1293 Battery Power Relay Circuit Open  
B1294 Battery Power Relay Circuit Short To Battery  
B1295 Battery Power Relay Circuit Short To Ground  
B1296 Power Supply Sensor Circuit Failure  
B1297 Power Supply Sensor Circuit Open  
B1298 Power Supply Sensor Circuit Short To Battery  
B1299 Power Supply Sensor Circuit Short To Ground  
B1300 Power Door Lock Circuit Failure  
B1301 Power Door Lock Circuit Open  
B1302 Accessory Delay Relay Coil Circuit Failure  
B1303 Accessory Delay Relay Coil Circuit Open  
B1304 Accessory Delay Relay Coil Circuit Short To Battery

B1305 Accessory Delay Relay Coil Circuit Short To Ground  
B1306 Oil Level Switch Circuit Open  
B1307 Oil Level Switch Circuit Short To Battery  
B1308 Oil Level Switch Circuit Short To Ground  
B1309 Power Door Lock Circuit Short To Ground  
B1310 Power Door Unlock Circuit Failure  
B1311 Power Door Unlock Circuit Open  
B1312 Lamp Headlamp Input Circuit Short To Battery  
B1313 Battery Saver Relay Coil Circuit Failure  
B1314 Battery Saver Relay Coil Circuit Open  
B1315 Battery Saver Relay Coil Circuit Short To Battery  
B1316 Battery Saver Relay Coil Circuit Short To Ground  
B1317 Battery Voltage High  
B1318 Battery Voltage Low  
B1319 Driver Door Ajar Circuit Failure  
B1320 Driver Door Ajar Circuit Open  
B1321 Driver Door Ajar Circuit Short To Battery  
B1322 Driver Door Ajar Circuit Short To Ground  
B1323 Door Ajar Lamp Circuit Failure  
B1324 Door Ajar Lamp Circuit Open  
B1325 Door Ajar Lamp Circuit Short To Battery  
B1326 Door Ajar Lamp Circuit Short To Ground  
B1327 Passenger Door Ajar Circuit Failure  
B1328 Passenger Door Ajar Circuit Open  
B1329 Passenger Door Ajar Circuit Short To Battery  
B1330 Passenger Door Ajar Circuit Short To Ground  
B1331 Decklid Ajar Rear Door Circuit Failure  
B1332 Decklid Ajar Rear Door Circuit Open  
B1333 Decklid Ajar Rear Door Circuit Short To Battery  
B1334 Decklid Ajar Rear Door Circuit Short To Ground  
B1335 Door Ajar RR Circuit Failure  
B1336 Door Ajar RR Circuit Open  
B1337 Door Ajar RR Circuit Short To Battery  
B1338 Door Ajar RR Circuit Short To Ground  
B1339 Chime Input Request Circuit Short To Battery  
B1340 Chime Input Request Circuit Short To Ground  
B1341 Power Door Unlock Circuit Short To Ground  
B1342 ECU Is Defective  
B1343 Heated Backlite Input Circuit Failure  
B1344 Heated Backlite Input Circuit Open  
B1345 Heated Backlite Input Circuit Short To Ground  
B1346 Heated Backlite Input Circuit Short To Battery  
B1347 Heated Backlite Relay Circuit Failure  
B1348 Heated Backlite Relay Circuit Open  
B1349 Heated Backlite Relay Short To Battery  
B1350 Heated Backlite Relay Short To Ground  
B1351 Ignition Key-In Circuit Short To Battery  
B1352 Ignition Key-In Circuit Failure  
B1353 Ignition Key-In Circuit Open  
B1354 Ignition Key-In Circuit Short To Ground  
B1355 Ignition Run Circuit Failure  
B1356 Ignition Run Circuit Open  
B1357 Ignition Run Circuit Short To Battery  
B1358 Ignition Run Circuit Short To Ground  
B1359 Ignition Run/Acc Circuit Failure  
B1360 Ignition Run/Acc Circuit Open  
B1361 Ignition Run/Acc Circuit Short To Battery  
B1362 Ignition Run/Acc Circuit Short To Ground  
B1363 Ignition Start Circuit Failure  
B1364 Ignition Start Circuit Open



B1365 Ignition Start Circuit Short To Battery  
B1366 Ignition Start Circuit Short To Ground  
B1367 Ignition Tach Circuit Failure  
B1368 Ignition Tach Circuit Open  
B1369 Ignition Tach Circuit Short To Battery  
B1370 Ignition Tach Circuit Short To Ground  
B1371 Illuminated Entry Relay Circuit Failure  
B1372 Illuminated Entry Relay Circuit Open  
B1373 Illuminated Entry Relay Short To Battery  
B1374 Illuminated Entry Relay Short To Ground  
B1375 Oil Change Lamp Circuit Open  
B1376 Oil Change Lamp Circuit Short To Battery  
B1377 Oil Change Lamp Circuit Failure  
B1378 Oil Change Lamp Circuit Short To Ground  
B1379 Oil Change Reset Button Circuit Short To Ground  
B1380 Oil Change Reset Button Circuit Failure  
B1381 Oil Change Reset Button Circuit Open  
B1382 Oil Change Reset Button Circuit Short To Battery  
B1383 Oil Level Lamp Circuit Short To Battery  
B1384 Oil Level Lamp Circuit Failure  
B1385 Oil Level Lamp Circuit Open  
B1386 Oil Level Lamp Circuit Short To Ground  
B1387 Oil Temperature Sensor Circuit Open  
B1388 Oil Temperature Sensor Circuit Short To Battery  
B1389 Oil Temperature Sensor Circuit Failure  
B1390 Oil Temperature Sensor Circuit Short To Ground  
B1391 Oil Level Switch Circuit Failure  
B1392 Power Door Memory Lock Relay Circuit Failure  
B1393 Power Door Memory Lock Relay Circuit Open  
B1394 Power Door Memory Lock Relay Circuit Short To Battery  
B1395 Power Door Memory Lock Relay Circuit Short To Ground  
B1396 Power Door Lock Circuit Short To Battery  
B1397 Power Door Unlock Circuit Short To Battery  
B1398 Driver Power Window One Touch Window Relay Circuit Failure  
B1399 Driver Power Window One Touch Window Relay Circuit Open  
B1400 Driver Power Window One Touch Window Relay Circuit Short To Battery  
B1401 Driver Power Window One Touch Window Relay Circuit Short To Ground  
B1402 Driver Power Window Down Switch Circuit Failure  
B1403 Driver Power Window Up Switch Circuit Failure  
B1404 Driver Power Window Down Circuit Open  
B1405 Driver Power Window Down Circuit Short To Battery  
B1406 Driver Power Window Down Circuit Short To Ground  
B1407 Driver Power Window Up Circuit Open  
B1408 Driver Power Window Up Circuit Short To Battery  
B1409 Driver Power Window Up Circuit Short To Ground  
B1410 Driver Power Window Motor Circuit Failure  
B1411 Driver Power Window Motor Circuit Open  
B1412 Driver Power Window Motor Circuit Short To Battery  
B1413 Driver Power Window Motor Circuit Short To Ground  
B1414 Power Window LR Motor Circuit Failure  
B1415 Power Window LR Motor Circuit Open  
B1416 Power Window LR Motor Circuit Short To Battery  
B1417 Power Window LR Motor Circuit Short To Ground  
B1418 Passenger Power Window Motor Circuit Failure  
B1419 Passenger Power Window Motor Circuit Open  
B1420 Passenger Power Window Motor Circuit Short To Battery  
B1421 Passenger Power Window Motor Circuit Short To Ground  
B1422 Power Window RR Motor Circuit Failure  
B1423 Power Window RR Motor Circuit Open  
B1424 Power Window RR Motor Circuit Short To Battery

B1425 Power Window RR Motor Circuit Short To Ground  
B1426 Lamp Seat Belt Circuit Short To Battery  
B1427 Lamp Seat Belt Circuit Open  
B1428 Lamp Seat Belt Circuit Failure  
B1429 Lamp Seat Belt Circuit Short To Ground  
B1430 Seat Belt Switch Circuit Short To Ground  
B1431 Wiper Brake/Run Relay Circuit Failure  
B1432 Wiper Brake/Run Relay Circuit Short To Battery  
B1433 Wiper Brake/Run Relay Circuit Short To Ground  
B1434 Wiper Hi/Low Speed Relay Coil Circuit Failure  
B1435 Wiper Hi/Low Speed Relay Coil Circuit Open  
B1436 Wiper Hi/Low Speed Relay Coil Circuit Short To Battery  
B1437 Wiper Hi/Low Speed Relay Coil Circuit Short To Ground  
B1438 Wiper Mode Select Switch Circuit Failure  
B1439 Wiper Mode Select Switch Circuit Open  
B1440 Wiper Mode Select Switch Circuit Short To Battery  
B1441 Wiper Mode Select Switch Circuit Short To Ground  
B1442 Door Handle Switch Circuit Failure  
B1443 Door Handle Switch Circuit Open  
B1444 Door Handle Switch Circuit Short To Battery  
B1445 Door Handle Switch Circuit Short To Ground  
B1446 Wiper Park Sense Circuit Failure  
B1447 Wiper Park Sense Circuit Open  
B1448 Wiper Park Sense Circuit Short To Battery  
B1449 Wiper Park Sense Circuit Short To Ground  
B1450 Wiper Wash/Delay Switch Circuit Failure  
B1451 Wiper Wash/Delay Switch Circuit Open  
B1452 Wiper Wash/Delay Switch Circuit Short To Battery  
B1453 Wiper Wash/Delay Switch Circuit Short To Ground  
B1454 Wiper Washer Fluid Lamp Circuit Failure  
B1455 Wiper Washer Fluid Lamp Circuit Open  
B1456 Wiper Washer Fluid Lamp Circuit Short To Battery  
B1457 Wiper Washer Fluid Lamp Circuit Short To Ground  
B1458 Wiper Washer Pump Motor Relay Circuit Failure  
B1459 Wiper Washer Pump Motor Relay Coil Circuit Open  
B1460 Wiper Washer Pump Motor Relay Coil Circuit Short To Battery  
B1461 Wiper Washer Pump Motor Relay Coil Circuit Short To Ground  
B1462 Seat Belt Switch Circuit Failure  
B1463 Seat Belt Switch Circuit Open  
B1464 Seat Belt Switch Circuit Short To Battery  
B1465 Wiper Brake/Run Relay Circuit Open  
B1466 Wiper Hi/Low Speed Not Switching  
B1467 Wiper Hi/Low Speed Circuit Motor Short To Battery  
B1468 Chime Input Request Circuit Failure  
B1469 Chime Input Request Circuit Open  
B1470 Lamp Headlamp Input Circuit Failure  
B1471 Lamp Headlamp Input Circuit Open  
B1472 Lamp Headlamp Input Circuit Short To Ground  
B1473 Wiper Low Speed Circuit Motor Failure  
B1474 Battery Saver Power Relay Circuit Short To Battery  
B1475 Accessory Delay Relay Contact Short To Battery  
B1476 Wiper High Speed Circuit Motor Failure  
B1477 Wiper Hi/Low Circuit Motor Short To Ground  
B1478 Power Window One Touch Up/Down Activated Simultaneously  
B1479 Wiper Washer Fluid Level Sensor Circuit Failure  
B1480 Wiper Washer Fluid Level Sensor Circuit Open  
B1481 Wiper Washer Fluid Level Sensor Circuit Short To Battery  
B1482 Wiper Washer Fluid Level Sensor Circuit Short To Ground  
B1483 Brake Pedal Input Circuit Failure  
B1484 Brake Pedal Input Open Circuit

B1485 Brake Pedal Input Circuit Battery Short  
B1486 Brake Pedal Input Circuit Ground Short  
B1487 Door Handle Right Front Circuit Failure  
B1488 Door Handle Right Front Circuit Open  
B1489 Door Handle Right Front Short To Battery  
B1490 Door Handle Right Front Short To Ground  
B1491 Ignition Cylinder Sensor Circuit Failure  
B1492 Ignition Cylinder Sensor Open Circuit  
B1493 Ignition Cylinder Sensor Battery Short  
B1494 Ignition Cylinder Sensor Ground Short  
B1495 Decklid Punch-Out Sensor Circuit Failure  
B1496 Decklid Punch-Out Sensor Open Circuit  
B1497 Decklid Punch-Out Sensor Battery Short  
B1498 Decklid Punch-Out Sensor Ground Short  
B1499 Lamp Turn Signal Left Circuit Failure  
B1500 Lamp Turn Signal Left Circuit Open  
B1501 Lamp Turn Signal Left Circuit Short To Battery  
B1502 Lamp Turn Signal Left Circuit Short To Ground  
B1503 Lamp Turn Signal Right Circuit Failure  
B1504 Lamp Turn Signal Right Circuit Open  
B1505 Lamp Turn Signal Right Circuit Short To Battery  
B1506 Lamp Turn Signal Right Circuit Short To Ground  
B1507 Flash To Pass Switch Circuit Failure  
B1508 Flash To Pass Switch Circuit Open  
B1509 Flash To Pass Switch Circuit Short To Battery  
B1510 Flash To Pass Switch Circuit Short To Ground  
B1511 Driver Door Handle Circuit Failure  
B1512 Driver Door Handle Circuit Open  
B1513 Driver Door Handle Circuit Short To Battery  
B1514 Driver Door Handle Circuit Short To Ground  
B1515 Seat Driver Occupied Switch Circuit Failure  
B1516 Seat Driver Occupied Switch Circuit Open  
B1517 Seat Driver Occupied Switch Circuit Short To Battery  
B1518 Seat Driver Occupied Switch Circuit Short To Ground  
B1519 Hood Switch Circuit Failure  
B1520 Hood Switch Circuit Open  
B1521 Hood Switch Circuit Short To Battery  
B1522 Hood Switch Circuit Short To Ground  
B1523 Keyless Entry Circuit Failure  
B1524 Keyless Entry Circuit Open  
B1525 Keyless Entry Circuit Short To Battery  
B1526 Keyless Entry Circuit Short To Ground  
B1527 Memory Set Switch Circuit Failure  
B1528 Memory Set Switch Circuit Open  
B1529 Memory Set Switch Circuit Short To Battery  
B1530 Memory Set Switch Circuit Short To Ground  
B1531 Memory 1 Switch Circuit Failure  
B1532 Memory 1 Switch Circuit Open  
B1533 Memory 1 Switch Circuit Short To Battery  
B1534 Memory 1 Switch Circuit Short To Ground  
B1535 Memory 2 Switch Circuit Failure  
B1536 Memory 2 Switch Circuit Open  
B1537 Memory 2 Switch Circuit Short To Battery  
B1538 Memory 2 Switch Circuit Short To Ground  
B1539 Mirror Driver Switch Assembly Circuit Failure  
B1540 Mirror Driver Switch Assembly Circuit Open  
B1541 Mirror Driver Switch Assembly Circuit Short To Battery  
B1542 Mirror Driver Switch Assembly Circuit Short To Ground  
B1543 Seat Direction Switch Assembly Circuit Failure  
B1544 Seat Direction Switch Assembly Circuit Open

B1545 Seat Direction Switch Assembly Circuit Short To Battery  
B1546 Seat Direction Switch Assembly Circuit Short To Ground  
B1547 Power Window Master Circuit Failure  
B1548 Power Window Master Circuit Open  
B1549 Power Window Master Circuit Short To Battery  
B1550 Power Window Master Circuit Short To Ground  
B1551 Decklid Release Circuit Failure  
B1552 Decklid Release Circuit Open  
B1553 Decklid Release Circuit Short To Battery  
B1554 Decklid Release Circuit Short To Ground  
B1555 Ignition Run/Start Circuit Failure  
B1556 Ignition Run/Start Circuit Open  
B1557 Ignition Run/Start Circuit Short To Battery  
B1558 Ignition Run/Start Circuit Short To Ground  
B1559 Door Lock Cylinder Circuit Failure  
B1560 Door Lock Cylinder Circuit Open  
B1561 Door Lock Cylinder Circuit Short To Battery  
B1562 Door Lock Cylinder Circuit Short To Ground  
B1563 Door Ajar Circuit Failure  
B1564 Door Ajar Circuit Open  
B1565 Door Ajar Circuit Short To Battery  
B1566 Door Ajar Circuit Short To Ground  
B1567 Lamp Headlamp High-Beam Circuit Failure  
B1568 Lamp Headlamp High-Beam Circuit Open  
B1569 Lamp Headlamp High-Beam Circuit Short To Battery  
B1570 Lamp Headlamp High-Beam Circuit Short To Ground  
B1571 Door Ajar LR Circuit Failure  
B1572 Door Ajar LR Circuit Open  
B1573 Door Ajar LR Circuit Short To Battery  
B1574 Door Ajar LR Circuit Short To Ground  
B1575 Lamp Park Input Circuit Failure  
B1576 Lamp Park Input Circuit Open  
B1577 Lamp Park Input Circuit Short To Battery  
B1578 Lamp Park Input Circuit Short To Ground  
B1579 Dim Panel Increase Input Circuit Failure  
B1580 Dim Panel Increase Input Circuit Open  
B1581 Dim Panel Increase Input Circuit Short To Battery  
B1582 Dim Panel Increase Input Circuit Short To Ground  
B1583 Dim Panel Decrease Input Circuit Failure  
B1584 Dim Panel Decrease Input Circuit Open  
B1585 Dim Panel Decrease Input Circuit Short To Battery  
B1586 Dim Panel Decrease Input Circuit Short To Ground  
B1587 Autolamp Delay Increase Circuit Failure  
B1588 Autolamp Delay Increase Circuit Open  
B1589 Autolamp Delay Increase Circuit Short To Battery  
B1590 Autolamp Delay Increase Circuit Short To Ground  
B1591 Autolamp Delay Decrease Circuit Failure  
B1592 Autolamp Delay Decrease Circuit Open  
B1593 Autolamp Delay Decrease Circuit Short To Battery  
B1594 Autolamp Delay Decrease Circuit Short To Ground  
B1595 Ignition Switch Illegal Input Code  
B1596 Service Continuous Codes  
B1597 Driver's Seat Seatback Autoglide Forward Switch Circuit Short to Ground  
B1598 Driver's Seat Seatback Autoglide Rearward Switch Circuit Short to Ground  
B1599 Passenger's Seatback Autoglide Forward Switch Circuit Short to Ground  
B1600 PATS Ignition Key Transponder Signal Is Not Received  
B1601 PATS Received Incorrect Key-Code From Ignition Key Transponder  
B1602 PATS Received Invalid Format Of Key-Code From Ignition Key Transponder  
B1603 Lamp Anti-Theft Indicator Circuit Failure  
B1604 Lamp Anti-Theft Indicator Circuit Open

B1605 Lamp Anti-Theft Indicator Circuit Short To Battery  
B1606 Lamp Anti-Theft Indicator Circuit Short To Ground  
B1607 Illuminated Entry Input Circuit Failure  
B1608 Illuminated Entry Input Open Circuit  
B1609 Illuminated Entry Input Short Circuit To Battery  
B1610 Illuminated Entry Input Short Circuit To Ground  
B1611 Wiper Rear Mode Select Switch Circuit Failure  
B1612 Wiper Rear Mode Select Switch Circuit Open  
B1613 Wiper Rear Mode Select Switch Circuit Short To Battery  
B1614 Wiper Rear Mode Select Switch Circuit Short To Ground  
B1615 Wiper Rear Disable Switch Circuit Failure  
B1616 Wiper Rear Disable Switch Circuit Open  
B1617 Wiper Rear Disable Switch Circuit Short To Battery  
B1618 Wiper Rear Disable Switch Circuit Short To Ground  
B1619 Wiper Rear Low Limit Input Circuit Failure  
B1620 Wiper Rear Low Limit Input Circuit Open  
B1621 Wiper Rear Low Limit Input Circuit Short To Battery  
B1622 Wiper Rear Low Limit Input Circuit S  
B1623 Lamp Keypad Output Circuit Failure  
B1624 Lamp Keypad Output Open Circuit  
B1625 Lamp Keypad Output Short Circuit To Battery  
B1626 Lamp Keypad Output Short Circuit To Ground  
B1627 PRNDL Reverse Input Circuit Failure  
B1628 PRNDL Reverse Input Open Circuit  
B1629 PRNDL Reverse Input Short To Battery  
B1630 PRNDL Reverse Input Short Circuit To Ground  
B1631 Mirror Driver Left Circuit Failure  
B1632 Mirror Driver Left Circuit Open  
B1633 Mirror Driver Left Circuit Short To Battery  
B1634 Mirror Driver Left Circuit Short To Ground  
B1635 Mirror Driver Right Circuit Failure  
B1636 Mirror Driver Right Circuit Open  
B1637 Mirror Driver Right Circuit Short To Battery  
B1638 Mirror Driver Right Short To Ground  
B1639 Mirror Passenger Left Circuit Failure  
B1640 Mirror Passenger Left Circuit Open  
B1641 Mirror Passenger Left Circuit Short To Battery  
B1642 Mirror Passenger Left Circuit Short To Ground  
B1643 Mirror Passenger Right Circuit Failure  
B1644 Mirror Passenger Right Circuit Open  
B1645 Mirror Passenger Right Circuit Short To Battery  
B1646 Mirror Passenger Right Circuit Short To Ground  
B1647 Seat Driver Recline Forward Circuit Failure  
B1648 Seat Driver Recline Forward Circuit Open  
B1649 Seat Driver Recline Forward Circuit Short To Battery  
B1650 Seat Driver Recline Forward Circuit Short To Ground  
B1651 Seat Driver Recline Backward Circuit Failure  
B1652 Seat Driver Recline Backward Circuit Open  
B1653 Seat Driver Recline Backward Circuit Short To Battery  
B1654 Seat Driver Recline Backward Circuit Short To Ground  
B1655 Seat Driver Rear Up Circuit Failure  
B1656 Seat Driver Rear Up Circuit Open  
B1657 Seat Driver Rear Up Circuit Short To Battery  
B1658 Seat Driver Rear Up Circuit Short To Ground  
B1659 Seat Driver Front Up Circuit Failure  
B1660 Seat Driver Front Up Circuit Open  
B1661 Seat Driver Front Up Circuit Short To Battery  
B1662 Seat Driver Front Up Circuit Short To Ground  
B1663 Seat Driver Front Up/Down Motor Stalled  
B1664 Seat Driver Rear Up/Down Motor Stalled

B1665 Seat Driver Forward/Backward Motor Stalled  
B1666 Seat Driver Recline Motor Stalled  
B1667 Mirror Driver Up/Down Motor Stalled  
B1668 Mirror Driver Right/Left Motor Stalled  
B1669 Mirror Passenger Up/Down Motor Stalled  
B1670 Mirror Passenger Right/Left Motor Stalled  
B1671 Battery Module Voltage Out Of Range  
B1672 Seat Driver Occupied Input Circuit Failure  
B1673 Seat Driver Occupied Input Circuit Open  
B1674 Seat Driver Occupied Input Circuit Short To Battery  
B1675 Seat Driver Occupied Input Circuit Short To Ground  
B1676 Battery Pack Voltage Out Of Range  
B1677 Alarm Panic Input Circuit Failure  
B1678 Alarm Panic Input Circuit Open  
B1679 Alarm Panic Input Circuit Short To Battery  
B1680 Alarm Panic Input Circuit Short To Ground  
B1681 PATS Transceiver Module Signal Is Not Received  
B1682 PATS Is Disabled (Check Link Between PATS And Transponder)  
B1683 Mirror Driver/Passenger Switch Circuit Failure  
B1684 Mirror Driver/Passenger Switch Circuit Open  
B1685 Lamp Dome Input Circuit Failure  
B1686 Lamp Dome Input Circuit Open  
B1687 Lamp Dome Input Circuit Short To Battery  
B1688 Lamp Dome Input Circuit Short To Ground  
B1689 Autolamp Delay Circuit Failure  
B1690 Autolamp Delay Circuit Open  
B1691 Autolamp Delay Circuit Short To Battery  
B1692 Autolamp Delay Circuit Short To Ground  
B1693 Autolamp On Circuit Failure  
B1694 Autolamp On Circuit Open  
B1695 Autolamp On Circuit Short To Battery  
B1696 Autolamp On Circuit Short To Ground  
B1697 Mirror Driver/Passenger Switch Circuit Short To Battery  
B1698 Mirror Driver/Passenger Switch Circuit Short To Ground  
B1699 Passenger's Seat Occupied Switch Circuit Short to Ground  
B1700 Passenger's Seatbelt Tension Reducer Circuit Short to Ground  
B1701 Seat Driver Recline Forward Switch Circuit Failure  
B1702 Seat Driver Recline Forward Switch Circuit Open  
B1703 Seat Driver Recline Forward Switch Circuit Short To Battery  
B1704 Seat Driver Recline Forward Switch Circuit Short To Ground  
B1705 Seat Driver Recline Rearward Switch Circuit Failure  
B1706 Seat Driver Recline Rearward Switch Circuit Open  
B1707 Seat Driver Recline Rearward Switch Circuit Short To Battery  
B1708 Seat Driver Recline Rearward Switch Circuit Short To Ground  
B1709 Seat Driver Front Up Switch Circuit Failure  
B1710 Seat Driver Front Up Switch Circuit Open  
B1711 Seat Driver Front Up Switch Circuit Short To Battery  
B1712 Seat Driver Front Up Switch Circuit Short To Ground  
B1713 Seat Driver Front Down Switch Circuit Failure  
B1714 Seat Driver Front Down Switch Circuit Open  
B1715 Seat Driver Front Down Switch Circuit Short To Battery  
B1716 Seat Driver Front Down Switch Circuit Short To Ground  
B1717 Seat Driver Forward Switch Circuit Failure  
B1718 Seat Driver Forward Switch Circuit Open  
B1719 Seat Driver Forward Switch Circuit Short To Battery  
B1720 Seat Driver Forward Switch Circuit Short To Ground  
B1721 Seat Driver Rearward Switch Circuit Failure  
B1722 Seat Driver Rearward Switch Circuit Open  
B1723 Seat Driver Rearward Switch Circuit Short To Battery  
B1724 Seat Driver Rearward Switch Circuit Short To Ground

B1725 Seat Driver Rear Up Switch Circuit Failure  
B1726 Seat Driver Rear Up Switch Circuit Open  
B1727 Seat Driver Rear Up Switch Circuit Short To Battery  
B1728 Seat Driver Rear Up Switch Circuit Short To Ground  
B1729 Seat Driver Rear Down Switch Circuit Failure  
B1730 Seat Driver Rear Down Switch Circuit Open  
B1731 Seat Driver Rear Down Switch Circuit Short To Battery  
B1732 Seat Driver Rear Down Switch Circuit Short To Ground  
B1733 Mirror Driver Vertical Switch Circuit Failure  
B1734 Mirror Driver Vertical Switch Circuit Open  
B1735 Mirror Driver Vertical Switch Circuit Short To Battery  
B1736 Mirror Driver Vertical Switch Circuit Short To Ground  
B1737 Mirror Driver Horizontal Switch Circuit Failure  
B1738 Mirror Driver Horizontal Switch Circuit Open  
B1739 Mirror Driver Horizontal Switch Circuit Short To Battery  
B1740 Mirror Driver Horizontal Switch Circuit Short To Ground  
B1741 Mirror Passenger Vertical Switch Circuit Failure  
B1742 Mirror Passenger Vertical Switch Circuit Open  
B1743 Mirror Passenger Vertical Switch Circuit Short To Battery  
B1744 Mirror Passenger Vertical Switch Circuit Short To Ground  
B1745 Mirror Passenger Horizontal Switch Circuit Failure  
B1746 Mirror Passenger Horizontal Switch Circuit Open  
B1747 Mirror Passenger Horizontal Switch Circuit Short To Battery  
B1748 Mirror Passenger Horizontal Switch Circuit Short To Ground  
B1749 Park/Neutral Switch Circuit Failure  
B1750 Park/Neutral Switch Circuit Open  
B1751 Park/Neutral Switch Circuit Short To Battery  
B1752 Park/Neutral Switch Circuit Short To Ground  
B1753 Hazard Flash Output Circuit Failure  
B1754 Hazard Flash Output Circuit Open  
B1755 Hazard Flash Output Circuit Short Battery  
B1756 Hazard Flash Output Circuit Short To Ground  
B1757 Seat Driver Rear Down Circuit Failure  
B1758 Seat Driver Rear Down Circuit Open  
B1759 Seat Driver Rear Down Circuit Short To Battery  
B1760 Seat Driver Rear Down Circuit Short To Ground  
B1761 Seat Driver Front Down Circuit Failure  
B1762 Seat Driver Front Down Circuit Open  
B1763 Seat Driver Front Down Circuit Short To Battery  
B1764 Seat Driver Front Down Circuit Short To Ground  
B1765 Seat Driver Forward Circuit Failure  
B1766 Seat Driver Forward Circuit Open  
B1767 Seat Driver Forward Circuit Short To Battery  
B1768 Seat Driver Forward Circuit Short To Ground  
B1769 Seat Driver Backward Circuit Failure  
B1770 Seat Driver Backward Circuit Open  
B1771 Seat Driver Backward Circuit Short To Battery  
B1772 Seat Driver Backward Circuit Short To Ground  
B1773 Mirror Driver Up Circuit Failure  
B1774 Mirror Driver Up Circuit Open  
B1775 Mirror Driver Up Circuit Short To Battery  
B1776 Mirror Driver Up Circuit Short To Ground  
B1777 Driver's Seatbelt Tension Reducer Circuit Short to Ground  
B1778 Mirror Driver Down Circuit Failure  
B1779 Mirror Driver Down Circuit Open  
B1780 Mirror Driver Down Circuit Short To Battery  
B1781 Mirror Driver Down Short To Ground  
B1782 Mirror Passenger Up Circuit Failure  
B1783 Mirror Passenger Up Circuit Open  
B1784 Mirror Passenger Up Circuit Short To Battery

B1785 Mirror Passenger Up Circuit Short To Ground  
B1786 Mirror Passenger Down Circuit Failure  
B1787 Mirror Passenger Down Circuit Open  
B1788 Mirror Passenger Down Circuit Short To Battery  
B1789 Mirror Passenger Down Circuit Short To Ground  
B1790 Autolamp Sensor Input Circuit Failure  
B1791 Autolamp Sensor Input Circuit Open  
B1792 Autolamp Sensor Input Circuit Short To Battery  
B1793 Autolamp Sensor Input Circuit Short To Ground  
B1794 Lamp Headlamp Low-Beam Circuit Failure  
B1795 Lamp Headlamp Low-Beam Circuit Open  
B1796 Lamp Headlamp Low-Beam Circuit Short To Battery  
B1797 Lamp Headlamp Low-Beam Circuit Short To Ground  
B1798 Lamp Turn Signal Front Output Circuit Failure  
B1799 Lamp Turn Signal Front Output Circuit Open  
B1800 Lamp Turn Signal Front Output Circuit Short To Battery  
B1801 Lamp Turn Signal Front Output Circuit Short To Ground  
B1802 Lamp Turn Signal Rear Output Circuit Failure  
B1803 Lamp Turn Signal Rear Output Circuit Open  
B1804 Lamp Turn Signal Rear Output Circuit Short To Battery  
B1805 Lamp Turn Signal Rear Output Circuit Short To Ground  
B1806 Lamp Tail Output Circuit Failure  
B1807 Lamp Tail Output Circuit Open  
B1808 Lamp Tail Output Circuit Short To Battery  
B1809 Lamp Tail Output Circuit Short To Ground  
B1810 Lamp Backup Switch Input Circuit Failure  
B1811 Lamp Backup Switch Input Circuit Open  
B1812 Lamp Backup Switch Input Circuit Short To Battery  
B1813 Lamp Backup Switch Input Circuit Short To Ground  
B1814 Wiper Rear Motor Down Relay Coil Circuit Failure  
B1815 Wiper Rear Motor Down Relay Coil Circuit Open  
B1816 Wiper Rear Motor Down Relay Coil Circuit Short To Battery  
B1817 Wiper Rear Motor Down Relay Coil Circuit Short To Ground  
B1818 Wiper Rear Motor Up Relay Coil Circuit Failure  
B1819 Wiper Rear Motor Up Relay Coil Circuit Open  
B1820 Wiper Rear Motor Up Relay Coil Circuit Short To Battery  
B1821 Wiper Rear Motor Up Relay Coil Circuit Short To Ground  
B1822 Wiper Rear Park Sense Input Circuit Failure  
B1823 Wiper Rear Park Sense Input Circuit Open  
B1824 Wiper Rear Park Sense Input Circuit Short To Battery  
B1825 Wiper Rear Park Sense Input Circuit Short To Ground  
B1826 Wiper Rear High Limit Input Circuit Failure  
B1827 Wiper Rear High Limit Input Circuit Open  
B1828 Wiper Rear High Limit Input Circuit Short To Battery  
B1829 Wiper Rear High Limit Input Circuit Short To Ground  
B1830 Door Unlock Disarm Switch Circuit Failure  
B1831 Door Unlock Disarm Switch Circuit Open  
B1832 Door Unlock Disarm Switch Circuit Short To Battery  
B1833 Door Unlock Disarm Switch Circuit Short To Ground  
B1834 Door Unlock Disarm Output Circuit Failure  
B1835 Door Unlock Disarm Output Circuit Open  
B1836 Door Unlock Disarm Output Circuit Short To Battery  
B1837 Door Unlock Disarm Output Circuit Short To Ground  
B1838 Battery Saver Power Relay Circuit Failure  
B1839 Wiper Rear Motor Circuit Failure  
B1840 Wiper Front Power Circuit Failure  
B1841 Wiper Front Power Circuit Open  
B1842 Wiper Front Power Circuit Short To Battery  
B1843 Wiper Front Power Circuit Short To Ground  
B1844 Phone Handset Circuit Failure



B1845 Ignition Tamper Circuit Failure  
B1846 Ignition Tamper Circuit Open  
B1847 Ignition Tamper Circuit Short To Battery  
B1848 Ignition Tamper Circuit Short To Ground  
B1849 Climate Control Temperature Differential Circuit Failure  
B1850 Climate Control Temperature Differential Circuit Open  
B1851 Climate Control Temperature Differential Circuit Short To Battery  
B1852 Climate Control Temperature Differential Circuit Short To Ground  
B1853 Climate Control Air Temperature Internal Sensor Motor Circuit Failure  
B1854 Climate Control Air Temperature Internal Sensor Motor Circuit Open  
B1855 Climate Control Air Temperature Internal Sensor Motor Circuit Short To Battery  
B1856 Climate Control Air Temperature Internal Sensor Motor Circuit Short To Ground  
B1857 Climate Control On/Off Switch Circuit Failure  
B1858 Climate Control A/C Pressure Switch Circuit Failure  
B1859 Climate Control A/C Pressure Switch Circuit Open  
B1860 Climate Control A/C Pressure Switch Circuit Short To Battery  
B1861 Climate Control A/C Pressure Switch Circuit Short To Ground  
B1862 Climate Control A/C Lock Sensor Failure  
B1863 Ground ECU Circuit Open  
B1864 Battery Power Supply ECU Circuit Failure  
B1865 Battery Power Supply ECU Circuit Open  
B1866 Battery Power Supply ECU Circuit Short To Battery  
B1867 Battery Power Supply ECU Circuit Short To Ground  
B1868 Lamp Air Bag Warning Indicator Circuit Failure  
B1869 Lamp Air Bag Warning Indicator Circuit Open  
B1870 Lamp Air Bag Warning Indicator Circuit Short To Battery  
B1871 Passenger Air Bag Disable Module Fault  
B1872 Turn Signal / Hazard Power Feed Circuit Short To Battery  
B1873 Turn Signal / Hazard Power Feed Circuit Short To Ground  
B1874 Cellular Phone Handset Not Present  
B1875 Turn Signal / Hazard Switch Signal Circuit Failure  
B1876 Seatbelt Driver Pretensioner Circuit Failure  
B1877 Seatbelt Driver Pretensioner Circuit Open  
B1878 Seatbelt Driver Pretensioner Circuit Short to Battery  
B1879 Seatbelt Driver Pretensioner Circui

C1091 Speed Wheel Sensor All Coherency Failure  
C1095 ABS Hydraulic Pump Motor Circuit Failure  
C1096 ABS Hydraulic Pump Motor Circuit Open  
C1097 ABS Hydraulic Pump Motor Circuit Short To Ground  
C1098 ABS Hydraulic Pump Motor Circuit Short To Battery  
C1100 ABS Pump Switch Circuit Failure  
C1101 ABS Hydraulic Valve Circuit Failure  
C1102 ABS Acceleration Switch Circuit Failure  
C1103 ABS Hydraulic Brake Switch Circuit Failure  
C1104 Traction Control Active Lamp - Circuit Short to Battery  
C1105 Traction Control Disable Lamp - Circuit Short to Battery  
C1106 Traction Control Disable Switch Circuit Short to Battery  
C1107 ABS Function Enabled Input Circuit Failure  
C1109 Speed Control Actuator Assembly Cable Release Failure  
C1110 ABS Power Relay Coil Circuit Failure  
C1111 ABS Power Relay Coil Open Circuit  
C1112 ABS Power Relay Coil Short Circuit To Ground  
C1113 ABS Power Relay Coil Short Circuit To Battery  
C1114 ABS Power Relay Output Short Circuit To Ground  
C1115 ABS Power Relay Output Short Circuit To Battery  
C1116 Starter Motor Circuit Failure  
C1117 RPM Input Circuit Failure  
C1123 Vehicle Speed Sensor Input Short to Battery  
C1124 Input shaft speed signal missing/faulted

C1125 Brake Fluid Level Sensor Input Circuit Failure  
C1126 Cruise Control Command Switch Assembly Circuit Failure  
C1127 Cruise Control Deactivator Brake Switch Circuit Failure  
C1132 Clutch position ckt short to ground  
C1133 Clutch position ckt short to battery  
C1134 Gear Shift position short to ground  
C1135 Gear Shift position short to battery  
C1136 Gear Select position short to ground  
C1137 ECU is Defective  
C1138 Gear Select position short to Battery  
C1139 Wheel Speed Sensor Center Tone Ring Missing Tooth Fault  
C1140 Hydraulic Base Brake Failure  
C1141 Wheel Speed Sensor LF Tone Ring Tooth Missing Fault  
C1142 Wheel Speed Sensor RF Tone Ring Tooth Missing Fault  
C1143 Wheel Speed Sensor LR Tone Ring Tooth Missing Fault  
C1144 Wheel Speed Sensor RR Tone Ring Tooth Missing Fault  
C1145 Speed Wheel Sensor RF Input Circuit Failure  
C1146 Speed Wheel Sensor RF Circuit Open  
C1148 Speed Wheel Sensor RF Coherency Fault  
C1149 Hydraulic Fluid Pressure/ Flow Circuit Failure  
C1150 Two Speed Rear Axle Input Switch Circuit Short to Vbatt  
C1155 Speed Wheel Sensor LF Input Circuit Failure  
C1156 Speed Wheel Sensor LF Circuit Open  
C1157 Park Brake Actuator Assembly Switch Applied Circuit Failure  
C1158 Speed Wheel Sensor LF Coherency Fault  
C1159 Hydraulic Fluid Pressure/ Flow Circuit Short to Gnd  
C1161 Air Pressure Low Circuit Short to Gnd  
C1162 Park Brake Switch # 2 Released Circuit Failure  
C1163 Park Brake Switch # 2 Applied Circuit Short to Gnd  
C1164 Park Brake Actuator Assembly Switch Circuit Failure  
C1165 Speed Wheel Sensor RR Input Circuit Failure  
C1166 Speed Wheel Sensor RR Input Open Circuit  
C1167 Park Brake Actuator Assembly Switch Released Circuit Short to Gnd  
C1168 Speed Wheel Sensor RR Coherency Fault  
C1169 ABS Fluid Dumping Exceeds Maximum Timing  
C1170 PRNDL Switch Circuit Failure  
C1172 Park Brake Switch # 1 Applied Circuit Failure  
C1173 Park Brake Switch # 1 Released Circuit Short to Gnd  
C1174 Park Brake Switch # 2 Applied Circuit Failure  
C1175 Speed Wheel Sensor LR Input Circuit Failure  
C1176 Speed Wheel Sensor LR Circuit Open  
C1177 Park Brake Actuator Assembly Switch Released Circuit Failure  
C1178 Speed Wheel Sensor LR Coherency Fault  
C1179 Speed Control Actuator Assembly Cable Slack Failure  
C1180 Park Brake Valve Solenoid #1 Sense Input Circuit Failure  
C1181 Park Brake Valve Solenoid #1 Sense Input Circuit Short to Gound  
C1182 Park Lamp Flash Relay Circuit Failure  
C1183 Park Lamp Flash Relay Circuit Short to Battery  
C1184 ABS System Is Not Operational  
C1185 ABS Power Relay Output Circuit Failure  
C1186 ABS Power Relay Output Open Circuit  
C1187 Brake Fluid Level Sensor Input Open Circuit  
C1188 Brake Fluid Level Sensor Input Short Circuit To Battery  
C1189 Brake Fluid Level Sensor Input Short Circuit To Ground  
C1190 Speed Wheel Sensor LF Input Short Circuit To Battery  
C1191 Speed Wheel Sensor LF Input Short Circuit To Ground  
C1192 Speed Wheel Sensor RF Input Short Circuit To Battery  
C1193 Speed Wheel Sensor RF Input Short Circuit To Ground  
C1194 ABS Outlet Valve Coil LF Circuit Failure  
C1195 ABS Outlet Valve Coil LF Circuit Open

C1196 ABS Outlet Valve Coil LF Circuit Short To Battery  
C1197 ABS Outlet Valve Coil LF Circuit Short To Ground  
C1198 ABS Inlet Valve Coil LF Circuit Failure  
C1199 ABS Inlet Valve Coil LF Circuit Open  
C1200 ABS Inlet Valve Coil LF Circuit Short To Battery  
C1201 ABS Inlet Valve Coil LF Circuit Short To Ground  
C1202 ABS Outlet Valve Coil Rear Circuit Failure  
C1203 ABS Outlet Valve Coil Rear Circuit Open  
C1204 ABS Outlet Valve Coil Rear Circuit Short To Battery  
C1205 ABS Outlet Valve Coil Rear Circuit Short To Ground  
C1206 ABS Inlet Valve Coil Rear Circuit Failure  
C1207 ABS Inlet Valve Coil Rear Circuit Open  
C1208 ABS Inlet Valve Coil Rear Circuit Short To Battery  
C1209 ABS Inlet Valve Coil Rear Circuit Short To Ground  
C1210 ABS Outlet Valve Coil RF Circuit Failure  
C1211 ABS Outlet Valve Coil RF Circuit Open  
C1212 ABS Outlet Valve Coil RF Circuit Short To Battery  
C1213 ABS Outlet Valve Coil RF Circuit Short To Ground  
C1214 ABS Inlet Valve Coil RF Circuit Failure  
C1215 ABS Inlet Valve Coil RF Circuit Open  
C1216 ABS Inlet Valve Coil RF Circuit Short To Battery  
C1217 ABS Inlet Valve Coil RF Circuit Short To Ground  
C1218 Lamp ABS Warning Output Circuit Failure  
C1219 Lamp ABS Warning Output Circuit Open  
C1220 Lamp ABS Warning Output Circuit Short To Battery  
C1221 Lamp ABS Warning Output Circuit Short To Ground  
C1222 Speed Wheel Mismatch  
C1223 Lamp Brake Warning Output Circuit Failure  
C1224 Lamp Brake Warning Output Circuit Open  
C1225 Lamp Brake Warning Output Circuit Short To Battery  
C1226 Lamp Brake Warning Output Circuit Short To Ground  
C1227 Speed Wheel Sensor LR Input Short Circuit To Battery  
C1228 Speed Wheel Sensor LR Input Short Circuit To Ground  
C1229 Speed Wheel Sensor Rear Center Coherency Fault  
C1230 Speed Wheel Sensor Rear Center Input Circuit Failure  
C1231 Speed Wheel Sensor Rear Center Circuit Open  
C1232 Speed Wheel Sensor Rear Center Input Short Circuit To Battery  
C1233 Speed Wheel LF Input Signal Missing  
C1234 Speed Wheel RF Input Signal Missing  
C1235 Speed Wheel RR Input Signal Missing  
C1236 Speed Wheel LR Input Signal Missing  
C1237 Speed Wheel Rear Input Signal Missing  
C1238 ABS Hydraulic Pressure Differential Switch Input Circuit Failure  
C1239 ABS Hydraulic Pressure Differential Switch Input Open Circuit  
C1240 ABS Hydraulic Pressure Differential Switch Input Short Circuit To Battery  
C1241 ABS Hydraulic Pressure Differential Switch Input Short Circuit To Ground  
C1242 ABS Outlet Valve Coil LR Circuit Failure  
C1243 ABS Outlet Valve Coil LR Circuit Open  
C1244 ABS Outlet Valve Coil LR Circuit Short To Battery  
C1245 ABS Outlet Valve Coil LR Circuit Short To Ground  
C1246 ABS Outlet Valve Coil RR Circuit Failure  
C1247 ABS Outlet Valve Coil RR Circuit Open  
C1248 ABS Outlet Valve Coil RR Circuit Short To Battery  
C1249 ABS Outlet Valve Coil RR Circuit Short To Ground  
C1250 ABS Inlet Valve Coil LR Circuit Failure  
C1251 ABS Inlet Valve Coil LR Circuit Open  
C1252 ABS Inlet Valve Coil LR Circuit Short To Battery  
C1253 ABS Inlet Valve Coil LR Circuit Short To Ground  
C1254 ABS Inlet Valve Coil RR Circuit Failure  
C1255 ABS Inlet Valve Coil RR Circuit Open

C1256 ABS Inlet Valve Coil RR Circuit Short To Battery  
C1257 ABS Inlet Valve Coil RR Circuit Short To Ground  
C1258 Speed Wheel LF Comparison Failure  
C1259 Speed Wheel RF Comparison Failure  
C1260 Speed Wheel RR Comparison Failure  
C1261 Speed Wheel LR Comparison Failure  
C1262 Lamp Warning Relay Circuit Failure  
C1263 Lamp Warning Relay Circuit Open  
C1264 Lamp Warning Relay Circuit Short To Battery  
C1265 Lamp Warning Relay Circuit Short To Ground  
C1266 ABS Valve Power Relay Circuit Failure  
C1267 ABS Functions Temporarily Disabled  
C1268 Motor Relay # 1 Circuit Failure  
C1269 Motor Relay # 1 Circuit Short to Battery  
C1270 Motor # 1 Input Circuit Failure  
C1271 Motor # 1 Input Circuit Short to Gnd  
C1272 Motor # 2 Input Circuit Failure  
C1273 Motor # 2 Input Circuit Short to Vbat  
C1274 Solenoid Relay # 1 Circuit Failure  
C1275 Solenoid Relay # 1 Circuit Short to Vbatt  
C1276 Park Brake Actuator Assembly Switch Applied Circuit Short to Gnd  
C1277 STEERING Wheel Angle 1and 2 Circuit Failure  
C1278 STEERING Wheel Angle 1and 2 Signal Faulted  
C1279 Yaw Rate Sensor circuit Failure  
C1280 Yaw Rate Sensor Signal Fault  
C1281 Lateral Accelerometer circuit Failure  
C1282 Lateral Accelerometer Signal Fault  
C1283 Switch Test Signal Failure  
C1284 Oil Pressure Switch Failure  
C1285 Booster Solenoid circuit Failure  
C1286 Booster Mechanical Failure  
C1287 Booster Pedal Force switch circuit Failure  
C1288 Pressure Transducer Main / Primary Input Circuit Failure  
C1289 Pressure Transducer Redundant / Secondary Input Circuit Failure  
C1400 Traction Control Valve RF Circuit Failure  
C1401 Traction Control Valve RF Circuit Open  
C1402 Traction Control Valve RF Circuit Short To Ground  
C1403 Traction Control Valve RF Circuit Short To Battery  
C1404 Traction Control Valve Rear Circuit Failure  
C1405 Traction Control Valve Rear Circuit Open  
C1406 Traction Control Valve Rear Circuit Short To Ground  
C1407 Traction Control Valve Rear Circuit Short To Battery  
C1410 Traction Control Valve LF Circuit Failure  
C1411 Traction Control Valve LF Circuit Open  
C1412 Traction Control Valve LF Circuit Short To Ground  
C1413 Traction Control Valve LF Circuit Short To Battery  
C1414 Incorrect Module Design Level  
C1415 Incorrect Module Configuration  
C1416 Damper RF Circuit Short To Battery  
C1417 Damper RF Circuit Short to Ground  
C1418 Damper RF Circuit Failure  
C1419 Damper RF Circuit Open  
C1420 Hydraulic Fluid Pressure/ Flow Circuit Short to Vbatt  
C1421 Damper LF Circuit Short To Battery  
C1422 Damper LF Circuit Short to Ground  
C1423 Damper LF Circuit Failure  
C1424 Damper LF Circuit Open  
C1425 Damper RR Circuit Short to Ground  
C1426 Damper RR Circuit Short To Battery  
C1427 Damper RR Circuit Open

C1428 Damper RR Circuit Failure  
C1429 Input-shaft-speed input circuit failure  
C1430 Damper LR Circuit Open  
C1431 Damper LR Circuit Short To Battery  
C1432 Damper LR Circuit Short to Ground  
C1433 Damper LR Circuit Failure  
C1435 Accelerometer Rear Circuit Failure  
C1436 Accelerometer Rear Circuit Signal Is Not Sensed  
C1437 Accelerometer Rear Circuit Short To Ground  
C1438 Accelerometer Rear Circuit Short To Battery  
C1439 Vehicle Acceleration EEC-IV Circuit Failure  
C1440 Pressure Transducer Main / Primary signal Faulted  
C1441 Steering Phase A Circuit Signal Is Not Sensed  
C1442 Steering Phase B Circuit Signal Is Not Sensed  
C1443 Steering Phase A Circuit Short To Ground  
C1444 Steering Phase B Circuit Short To Ground  
C1445 Speed Vehicle Signal Circuit Failure  
C1446 Brake Switch Circuit Failure  
C1447 Traction Control Module Request Circuit Failure  
C1448 Lamp Adaptive Damping Warning Circuit Failure  
C1449 Traction Control Motor Coherency Fault  
C1450 Traction Control Motor Circuit Failure  
C1451 Traction Control Motor Circuit Open  
C1452 Traction Control Motor Circuit Short to Battery  
C1453 Traction Control Motor Circuit Short to Ground  
C1454 Front Lateral Accelerometer Circuit Failure  
C1455 Accelerometer Front Circuit Failure  
C1456 Accelerometer Front Circuit Is Not Sensed  
C1457 Accelerometer Front Circuit Short To Ground  
C1458 Accelerometer Front Circuit Short To Battery  
C1459 Adaptive Mode Switch Circuit Failure  
C1460 Vehicle Accelerometer Power Circuit Failure  
C1461 Vehicle Accelerometer Power Circuit Short to Battery  
C1462 Left Front Vertical Accelerometer Circuit Failure  
C1463 Right Front Vertical Accelerometer Circuit Failure  
C1464 Pressure Transducer Redundant / Secondary Signal Faulted  
C1465 Damper High Side Front Circuit Short To Battery  
C1466 Damper Circuit Failure  
C1467 Damper High Side Rear Circuit Short To Battery  
C1468 Damper Low Side Front Circuit Failure  
C1469 Damper Low Side Rear Circuit Failure  
C1495 Traction Control Motor Potentiometer Circuit Failure  
C1496 Traction Control Motor Potentiometer Circuit Open  
C1497 Traction Control Motor Potentiometer Circuit Short to Battery  
C1498 Traction Control Motor Potentiometer Circuit Short to Ground  
C1499 Transfer Case Contact Plate "A" Encoder Circuit Failure  
C1500 Transfer Case Contact Plate "B" Encoder Circuit Failure  
C1501 Transfer Case Contact Plate "C" Encoder Circuit Failure  
C1502 Transfer Case Contact Plate "D" Encoder Circuit Failure  
C1503 Dynamic Stability Control Left Front Valve Malfunction  
C1504 Dynamic Stability Control Right Front Valve Malfunction  
C1505 Dynamic Stability Control Left Rear Valve Malfunction  
C1506 Dynamic Stability Control Right Rear Valve Malfunction  
C1507 Traction Control of Brake Exceeds Time-Out  
C1508 Traction Control of Engine Exceeds Time-Out  
C1510 Right Front Wheel Pressure Reduction Performance Problem  
C1511 Left Front Wheel Pressure Reduction Performance Problem  
C1512 Right Rear Wheel Pressure Reduction Performance Problem  
C1513 Left rear Wheel Pressure Reduction Performance Problem  
C1699 Left Rear Sensor Circuit Short to Vbat

C1700 Left Rear Sensor Circuit Failure  
C1701 Left Rear Sensor Circuit Fault  
C1702 RightRear Sensor Circuit Short to Vbat  
C1703 Right Rear Sensor Circuit Failure  
C1704 Right Rear Sensor Circuit Fault  
C1705 Left Rear Center Sensor Circuit Short to Vbat  
C1706 Left Rear Center Sensor Circuit Failure  
C1707 Left Rear Center Sensor Circuit Fault  
C1708 Right Rear Center Sensor Circuit Short to Vbat  
C1709 Right Rear Center Sensor Circuit Failure  
C1710 Right Rear Center Sensor Circuit Fault  
C1711 Left Front Sensor Circuit Short to Vbat  
C1712 Left Front Sensor Circuit Failure  
C1713 Left Front Sensor Circuit Fault  
C1714 Right Front Sensor Circuit Short to Vbat  
C1715 Right Front Sensor Circuit Failure  
C1716 Right Front Sensor Circuit Fault  
C1717 Left Front Center Sensor Circuit Short to Vbat  
C1718 Left Front Center Sensor Circuit Failure  
C1719 Left Front Center Sensor Circuit Fault  
C1721 Air Suspension Height Sensor Power Circuit Open  
C1722 Air Suspension Height Sensor Power Circuit Short To Battery  
C1723 Air Suspension Height Sensor Power Circuit Short To Ground  
C1724 Air Suspension Height Sensor Power Circuit Failure  
C1725 Air Suspension Front Pneumatic Failure  
C1726 Air Suspension Rear Pneumatic Failure  
C1727 Air Suspension Reservoir Pneumatic Failure  
C1728 Transfer Case unable to transition between 2H and 4H  
C1729 Transfer Case unable to transition between 4H and 4L  
C1730 Reference Voltage Out of Range (+5 v)  
C1731 Air Suspension LF Corner Up Timeout  
C1732 Air Suspension LF Corner Down Timeout  
C1733 Air Suspension RF Corner Up Timeout  
C1734 Air Suspension RF Corner Down Timeout  
C1735 Air Suspension LR Corner Up Timeout  
C1736 Air Suspension LR Corner Down Timeout  
C1737 Air Suspension RR Corner Up Timeout  
C1738 Air Suspension RR Corner Down Timeout  
C1739 Right Front Center Sensor Circuit Short to Vbat  
C1740 Right Front Center Sensor Circuit Failure  
C1741 Right Front Center Sensor Circuit Fault  
C1742 Rear Sounder Circuit Failure  
C1743 Rear Sounder Circuit Short to Vbatt  
C1744 Front Sounder Circuit Failure  
C1745 Front Sounder Circuit Short to Vbatt  
C1748 Switch input Circuit Short to Gnd  
C1749 Trailer Input Circuit Failure  
C1750 Accelerator Position Sensor Out of Range  
C1751 Vehicle Speed Sensor # 1 Output Circuit Short to Vbatt  
C1752 Vehicle Speed Sensor # 1 Output Circuit Short to Gnd  
C1753 Hydraulic Clutch Actuator Valve Signal Fault  
C1754 Hydraulic Clutch Actuator Valve Circuit Failure  
C1755 Power Limit Shutdown Fault  
C1756 Air Suspension Front Height Sensor High (SE) Signal Circuit Failure  
C1757 Air Suspension Front Height Sensor High (SE) Signal Circuit Open  
C1758 Air Suspension Front Height Sensor High (SE) Signal Circuit Short To Battery  
C1759 Air Suspension Front Height Sensor High (SE) Signal Circuit Short To Ground  
C1760 Air Suspension Rear Height Sensor High (SE) Signal Circuit Failure  
C1761 Air Suspension Rear Height Sensor High (SE) Signal Circuit Open  
C1762 Air Suspension Rear Height Sensor High (SE) Signal Circuit Short To Battery

C1763 Air Suspension Rear Height Sensor High (SE) Signal Circuit Short To Ground  
C1765 Air Suspension Rear Height Sensor Low Signal Circuit Failure  
C1766 Air Suspension Rear Height Sensor Low Signal Circuit Open  
C1767 Air Suspension Rear Height Sensor Low Signal Circuit Short To Battery  
C1768 Air Suspension Rear Height Sensor Low Signal Circuit Short To Ground  
C1770 Air Suspension Vent Solenoid Output Circuit Failure  
C1771 Air Suspension Vent Solenoid Output Circuit Open  
C1772 Air Suspension Vent Solenoid Output Circuit Short To Battery  
C1773 Air Suspension Vent Solenoid Output Circuit Short To Ground  
C1774 Coolant Temp Out of Range  
C1775 DC-DC Converter Failure  
C1776 Heater System Failure  
C1777 Vacuum Pressure Circuit Failure  
C1778 Power Steering Failure  
C1779 Blower Switch Failure  
C1780 Temperature Select Failure  
C1781 Engine Coolant Temperature Signal Missing/Fault  
C1790 Air Suspension LR Air Spring/Shock Solenoid Output Circuit Failure  
C1791 Air Suspension LR Air Spring/Shock Solenoid Output Circuit Open  
C1792 Air Suspension LR Air Spring/Shock Solenoid Output Circuit Short To Battery  
C1793 Air Suspension LR Air Spring/Shock Solenoid Output Circuit Short To Ground  
C1795 Air Suspension RR Air Spring/Shock Solenoid Output Circuit Failure  
C1796 Air Suspension RR Air Spring/Shock Solenoid Output Circuit Open  
C1797 Air Suspension RR Air Spring/Shock Solenoid Output Circuit Short To Battery  
C1798 Air Suspension RR Air Spring/Shock Solenoid Output Circuit Short To Ground  
C1800 Air Suspension Reservoir Solenoid Circuit Failure  
C1805 Mismatched PCM and/or ABS-TC Module  
C1813 Air Suspension LR Vent Request Exceeded Max Timing  
C1814 Air Suspension RR Vent Request Exceeded Max Timing  
C1818 Air Suspension LR Air Compress Request Exceeded Max Timing  
C1819 Air Suspension RR Air Compress Request Exceeded Max Timing  
C1820 Air Suspension RF Air Compress Request Exceeded Max Timing  
C1830 Air Suspension Compressor Relay Circuit Failure  
C1831 Air Suspension Compressor Relay Circuit Open  
C1832 Air Suspension Compressor Relay Circuit Short To Battery  
C1833 Air Suspension Compressor Relay Circuit Short To Ground  
C1834 Gauge Drive Current Fault  
C1835 Current Sense Circuit Failure  
C1836 Battery Temp out of Range  
C1837 Battery Heater Circuit Failure  
C1838 Charging System Fault  
C1839 Leakage Fault  
C1840 Air Suspension Disable Switch Circuit Failure  
C1841 Air Suspension Disable Switch Circuit Open  
C1842 Air Suspension Disable Switch Circuit Short To Battery  
C1843 Air Suspension Disable Switch Circuit Short To Ground  
C1844 Air Suspension Secondary Front Inflator Solenoid Output Circuit Failure  
C1845 Air Suspension Front Inflator Solenoid Output Circuit Failure  
C1846 Air Suspension Front Inflator Solenoid Output Circuit Open  
C1847 Air Suspension Front Inflator Solenoid Output Circuit Short To Battery  
C1848 Air Suspension Front Inflator Solenoid Output Circuit Short To Ground  
C1849 Master Cylinder Pressure Out of Range  
C1850 Air Suspension Warning Lamp Circuit Failure  
C1851 Air Suspension Warning Lamp Circuit Open  
C1852 Air Suspension Warning Lamp Circuit Short To Battery  
C1853 Air Suspension Warning Lamp Circuit Short To Ground  
C1854 Motor Temperature Out of Range  
C1855 Acceleration Position Sensor Conflict  
C1856 Traction Motor Encoder circuit Failure  
C1859 PRNDL Input #2 Circuit Failure

C1860 PRNDL Input #3 Circuit Failure  
C1861 PRNDL Input #4 Circuit Failure  
C1862 Contactor Circuit Failure  
C1863 External Charging Fault  
C1864 Battery Module Fault  
C1865 Air Suspension Rear Inflator Solenoid Output Circuit Failure  
C1866 Air Suspension Rear Inflator Solenoid Output Circuit Open  
C1867 Air Suspension Rear Inflator Solenoid Output Circuit Short To Battery  
C1868 Air Suspension Rear Inflator Solenoid Output Circuit Short To Ground  
C1869 Air Suspension Gate Solenoid Output Circuit Failure  
C1870 Air Suspension Gate Solenoid Output Circuit Open  
C1871 Air Suspension Gate Solenoid Output Circuit Short To Battery  
C1872 Air Suspension Gate Solenoid Output Circuit Short To Ground  
C1873 Air Suspension RF Air Spring Solenoid Output Circuit Failure  
C1874 Air Suspension RF Air Spring Solenoid Output Circuit Open  
C1875 Air Suspension RF Air Spring Solenoid Output Circuit Short To Battery  
C1876 Air Suspension RF Air Spring Solenoid Output Circuit Short To Ground  
C1877 Air Suspension LF Air Spring Solenoid Output Circuit Failure  
C1878 Air Suspension LF Air Spring Solenoid Output Circuit Open  
C1879 Air Suspension LF Air Spring Solenoid Output Circuit Short To Battery  
C1880 Air Suspension LF Air Spring Solenoid Output Circuit Short To Ground  
C1881 Air Suspension RF Height Sensor Circuit Failure  
C1882 Air Suspension RF Height Sensor Circuit Open  
C1883 Air Suspension RF Height Sensor Circuit Short To Battery  
C1884 Air Suspension RF Height Sensor Circuit Short To Ground  
C1885 Air Suspension RR Height Sensor Circuit Failure  
C1886 Air Suspension RR Height Sensor Circuit Open  
C1887 Air Suspension RR Height Sensor Circuit Short To Battery  
C1888 Air Suspension RR Height Sensor Circuit Short To Ground  
C1889 Air Suspension LF Height Sensor Circuit Failure  
C1890 Air Suspension LF Height Sensor Circuit Open  
C1891 Air Suspension LF Height Sensor Circuit Short To Battery  
C1892 Air Suspension LF Height Sensor Circuit Short To Ground  
C1893 Air Suspension LR Height Sensor Circuit Failure  
C1894 Air Suspension LR Height Sensor Circuit Open  
C1895 Air Suspension LR Height Sensor Circuit Short To Battery  
C1896 Air Suspension LR Height Sensor Circuit Short To Ground  
C1897 Steering VAPS II Circuit Loop Failure  
C1898 Steering VAPS II Circuit Loop Open  
C1899 Steering VAPS II Circuit Loop Short To Battery  
C1900 Steering VAPS II Circuit Loop Short To Ground  
C1901 Ride Control RR Shock Actuator Circuit Failure  
C1902 Ride Control RR Shock Actuator Circuit Open  
C1903 Ride Control RR Shock Actuator Circuit Short To Battery  
C1904 Ride Control RR Shock Actuator Circuit Short To Ground  
C1905 Ride Control LR Shock Actuator Circuit Failure  
C1906 Ride Control LR Shock Actuator Circuit Open  
C1907 Ride Control LR Shock Actuator Circuit Short To Battery  
C1908 Ride Control LR Shock Actuator Circuit Short To Ground  
C1909 Ride Control RF Shock Actuator Circuit Failure  
C1910 Ride Control RF Shock Actuator Circuit Open  
C1911 Ride Control RF Shock Actuator Circuit Short To Battery  
C1912 Ride Control RF Shock Actuator Circuit Short To Ground  
C1913 Ride Control LF Shock Actuator Circuit Failure  
C1914 Ride Control LF Shock Actuator Circuit Open  
C1915 Ride Control LF Shock Actuator Circuit Short To Battery  
C1916 Ride Control LF Shock Actuator Circuit Short To Ground  
C1917 Steering EVO Out-of-Range Fault  
C1918 Air Suspension Ride Height Select Switch Circuit Failure  
C1920 Led #1 Circuit Failure



C1921 VAPS Solenoid Actuator Output Circuit Failure  
C1922 VAPS Solenoid Actuator Output Circuit Open  
C1923 VAPS Solenoid Actuator Output Circuit Short To Battery  
C1924 VAPS Solenoid Actuator Output Circuit Short To Ground  
C1925 VAPS Solenoid Actuator Return Circuit Failure  
C1926 VAPS Solenoid Actuator Return Circuit Open  
C1927 VAPS Solenoid Actuator Return Circuit Short To Battery  
C1928 VAPS Solenoid Actuator Return Circuit Short To Ground  
C1929 Air Suspension Front Compressor Relay Circuit Failure  
C1930 Air Suspension Front Compressor Relay Circuit Open  
C1931 Air Suspension Front Compressor Relay Circuit Short To Battery  
C1932 Air Suspension Front Compressor Relay Circuit Short To Ground  
C1933 Solenoid Current Out Of Range  
C1934 HPU (Hydraulic Pump Unit) Pressurisation Failure  
C1935 Chime Circuit Failure  
C1936 Hydraulic Pump Relay Circuit Failure  
C1937 Steering Wheel Angle Sensor Offset Failure  
C1938 Invalid Steering Wheel Angle Sensor ID  
C1939 Brake Pressure Switch Input Circuit Failure  
C1940 Brake Pressure Switch Mechanical Failure  
C1942 Unrecognized Powertrain Configuration  
C1943 Airbag Deployment Indication Input Fault  
C1944 Gauge Driver Circuit Fault  
C1945 Park Switch Indicates Park with Vehicle Moving  
C1946 Seat Track Position Switch Circuit Open  
C1947 Seat Track Position Switch Circuit Short to Ground  
C1948 Seat Track Position Switch Circuit Resistance Out of Range  
C1949 Accelerometer Sensor Circuit Open  
C1950 Accelerometer Sensor Circuit Failure  
C1951 Lateral Accelerometer Sensor Circuit Open  
C1952 Yaw Rate Sensor Circuit Open  
C1953 Master Cylinder Pressure Sensor Circuit Open  
C1954 Master Cylinder Pressure Sensor Circuit Failure  
C1955 Steering Angle Sensor Circuit Open  
C1956 Steering Angle Sensor Circuit Failure  
C1957 Dynamic Stability Control Valve RF Circuit Failure  
C1958 Dynamic Stability Control Valve LF Circuit Failure  
C1959 Lateral Accelerometer Sensor Circuit Failure  
C1960 Driver Brake Apply Circuit Fault  
C1961 Park Lamp Relay Coil Circuit Failure  
C1962 Park Lamp Relay Coil Short to Battery  
C1963 Stability Control Inhibit Warning  
C2767 Reserved &#8211; TBD

U1000 SCP (J1850) Invalid or Missing Data for Primary Id  
U1001 SCP (J1850) Invalid or Missing Data for Primary Id  
U1002 SCP (J1850) Invalid or Missing Data for Primary Id  
U1003 SCP (J1850) Invalid or Missing Data for Primary Id  
U1004 SCP (J1850) Invalid or Missing Data for EEC Programming  
U1005 SCP (J1850) Invalid or Missing Data for EEC Programming  
U1006 SCP (J1850) Invalid or Missing Data for Primary Id  
U1007 SCP (J1850) Invalid or Missing Data for Primary Id  
U1008 SCP (J1850) Invalid or Missing Data for Engine Torque  
U1009 SCP (J1850) Invalid or Missing Data for Engine Torque  
U1010 SCP (J1850) Invalid or Missing Data for Engine Air Intake  
U1011 SCP (J1850) Invalid or Missing Data for Engine Air Intake  
U1012 SCP (J1850) Invalid or Missing Data for Primary Id  
U1013 SCP (J1850) Invalid or Missing Data for Primary Id  
U1014 SCP (J1850) Invalid or Missing Data for Primary Id  
U1015 SCP (J1850) Invalid or Missing Data for Primary Id

U1016 SCP (J1850) Invalid or Missing Data for Primary Id  
U1017 SCP (J1850) Invalid or Missing Data for Primary Id  
U1018 SCP (J1850) Invalid or Missing Data for Throttle  
U1019 SCP (J1850) Invalid or Missing Data for Throttle  
U1020 SCP (J1850) Invalid or Missing Data for Air Conditioning Clutch  
U1021 SCP (J1850) Invalid or Missing Data for Air Conditioning Clutch  
U1022 SCP (J1850) Invalid or Missing Data for Primary Id  
U1023 SCP (J1850) Invalid or Missing Data for Primary Id  
U1024 SCP (J1850) Invalid or Missing Data for Primary Id  
U1025 SCP (J1850) Invalid or Missing Data for Primary Id  
U1026 SCP (J1850) Invalid or Missing Data for Engine RPM  
U1027 SCP (J1850) Invalid or Missing Data for Engine RPM  
U1028 SCP (J1850) Invalid or Missing Data for Primary Id  
U1029 SCP (J1850) Invalid or Missing Data for Primary Id  
U1030 SCP (J1850) Invalid or Missing Data for Experimental #1  
U1031 SCP (J1850) Invalid or Missing Data for Experimental #1  
U1032 SCP (J1850) Invalid or Missing Data for Primary Id  
U1033 SCP (J1850) Invalid or Missing Data for Primary Id  
U1034 SCP (J1850) Invalid or Missing Data for Primary Id  
U1035 SCP (J1850) Invalid or Missing Data for Primary Id  
U1036 SCP (J1850) Invalid or Missing Data for Wheels  
U1037 SCP (J1850) Invalid or Missing Data for Wheels  
U1038 SCP (J1850) Invalid or Missing Data for Primary Id  
U1039 SCP (J1850) Invalid or Missing Data for Primary Id / Vehicle Speed  
U1040 SCP (J1850) Invalid or Missing Data for Vehicle Speed  
U1041 SCP (J1850) Invalid or Missing Data for Vehicle Speed  
U1042 SCP (J1850) Invalid or Missing Data for Traction Control  
U1043 SCP (J1850) Invalid or Missing Data for Traction Control  
U1044 SCP (J1850) Invalid or Missing Data for Traction Motor  
U1045 SCP (J1850) Invalid or Missing Data for Traction Motor  
U1046 SCP (J1850) Invalid or Missing Data for Primary Id  
U1047 SCP (J1850) Invalid or Missing Data for Primary Id  
U1048 SCP (J1850) Invalid or Missing Data for Primary Id  
U1049 SCP (J1850) Invalid or Missing Data for Primary Id  
U1050 SCP (J1850) Invalid or Missing Data for Brakes  
U1051 SCP (J1850) Invalid or Missing Data for Brakes  
U1052 SCP (J1850) Invalid or Missing Data for Steering / Steering Wheel  
U1053 SCP (J1850) Invalid or Missing Data for Steering / Steering Wheel  
U1054 SCP (J1850) Invalid or Missing Data for Primary Id  
U1055 SCP (J1850) Invalid or Missing Data for Primary Id  
U1056 SCP (J1850) Invalid or Missing Data for Vehicle Configuration  
U1057 SCP (J1850) Invalid or Missing Data for Vehicle Configuration  
U1058 SCP (J1850) Invalid or Missing Data for Transmission / Transaxle / PRNDL  
U1059 SCP (J1850) Invalid or Missing Data for Transmission / Transaxle / PRNDL  
U1060 SCP (J1850) Invalid or Missing Data for Primary Id  
U1061 SCP (J1850) Invalid or Missing Data for Primary Id  
U1062 SCP (J1850) Invalid or Missing Data for Primary Id  
U1063 SCP (J1850) Invalid or Missing Data for Primary Id  
U1064 SCP (J1850) Invalid or Missing Data for Primary Id  
U1065 SCP (J1850) Invalid or Missing Data for Primary Id  
U1066 SCP (J1850) Invalid or Missing Data for Primary Id  
U1067 SCP (J1850) Invalid or Missing Data for Primary Id  
U1068 SCP (J1850) Invalid or Missing Data for Primary Id  
U1069 SCP (J1850) Invalid or Missing Data for Primary Id  
U1070 SCP (J1850) Invalid or Missing Data for Engine Sensors  
U1071 SCP (J1850) Invalid or Missing Data for Engine Sensors  
U1072 SCP (J1850) Invalid or Missing Data for Engine Coolant  
U1073 SCP (J1850) Invalid or Missing Data for Engine Coolant  
U1074 SCP (J1850) Invalid or Missing Data for Engine Oil  
U1075 SCP (J1850) Invalid or Missing Data for Engine Oil Temp

U1076 SCP (J1850) Invalid or Missing Data for Primary Id  
U1077 SCP (J1850) Invalid or Missing Data for Primary Id  
U1078 SCP (J1850) Invalid or Missing Data for Primary Id  
U1079 SCP (J1850) Invalid or Missing Data for Primary Id  
U1080 SCP (J1850) Invalid or Missing Data for Primary Id  
U1081 SCP (J1850) Invalid or Missing Data for Primary Id  
U1082 SCP (J1850) Invalid or Missing Data for Engine Systems Other  
U1083 SCP (J1850) Invalid or Missing Data for Engine Systems Other  
U1084 SCP (J1850) Invalid or Missing Data for Powertrain Status Request  
U1085 SCP (J1850) Invalid or Missing Data for Powertrain Status Request  
U1086 SCP (J1850) Invalid or Missing Data for Primary Id  
U1087 SCP (J1850) Invalid or Missing Data for Primary Id  
U1088 SCP (J1850) Invalid or Missing Data for Suspension  
U1089 SCP (J1850) Invalid or Missing Data for Suspension  
U1090 SCP (J1850) Invalid or Missing Data for Non-Legislated Diagnostics  
U1091 SCP (J1850) Invalid or Missing Data for Non-Legislated Diagnostics  
U1092 SCP (J1850) Invalid or Missing Data for Primary Id  
U1093 SCP (J1850) Invalid or Missing Data for Primary Id  
U1094 SCP (J1850) Invalid or Missing Data for Experimental #2  
U1095 SCP (J1850) Invalid or Missing Data for Experimental #2  
U1096 SCP (J1850) Invalid or Missing Data for Primary Id  
U1097 SCP (J1850) Invalid or Missing Data for Primary Id  
U1098 SCP (J1850) Invalid or Missing Data for Vehicle Speed Control  
U1099 SCP (J1850) Invalid or Missing Data for Vehicle Speed Control  
U1100 SCP (J1850) Invalid or Missing Data for Primary Id  
U1101 SCP (J1850) Invalid or Missing Data for Primary Id  
U1102 SCP (J1850) Invalid or Missing Data for Primary Id  
U1103 SCP (J1850) Invalid or Missing Data for Primary Id  
U1104 SCP (J1850) Invalid or Missing Data for Chassis Status Request  
U1105 SCP (J1850) Invalid or Missing Data for Chassis Status Request  
U1106 SCP (J1850) Invalid or Missing Data for Legislated Diagnostics  
U1107 SCP (J1850) Invalid or Missing Data for Legislated Diagnostics  
U1108 SCP (J1850) Invalid or Missing Data for Electric Traction Drive (Inverter)  
U1109 SCP (J1850) Invalid or Missing Data for Electric Traction Drive (Inverter)  
U1110 SCP (J1850) Invalid or Missing Data for Primary Id  
U1111 SCP (J1850) Invalid or Missing Data for Primary Id  
U1112 SCP (J1850) Invalid or Missing Data for Primary Id  
U1113 SCP (J1850) Invalid or Missing Data for Primary Id  
U1114 SCP (J1850) Invalid or Missing Data for Charging System  
U1115 SCP (J1850) Invalid or Missing Data for Charging System  
U1116 SCP (J1850) Invalid or Missing Data for Electrical Energy Management  
U1117 SCP (J1850) Invalid or Missing Data for Electrical Energy Management  
U1118 SCP (J1850) Invalid or Missing Data for Primary Id  
U1119 SCP (J1850) Invalid or Missing Data for Primary Id  
U1120 SCP (J1850) Invalid or Missing Data for Primary Id  
U1121 SCP (J1850) Invalid or Missing Data for Primary Id  
U1122 SCP (J1850) Invalid or Missing Data for Odometer  
U1123 SCP (J1850) Invalid or Missing Data for Odometer  
U1124 SCP (J1850) Invalid or Missing Data for Primary Id  
U1125 SCP (J1850) Invalid or Missing Data for Primary Id  
U1126 SCP (J1850) Invalid or Missing Data for Primary Id  
U1127 SCP (J1850) Invalid or Missing Data for Primary Id  
U1128 SCP (J1850) Invalid or Missing Data for Primary Id  
U1129 SCP (J1850) Invalid or Missing Data for Primary Id  
U1130 SCP (J1850) Invalid or Missing Data for Fuel System  
U1131 SCP (J1850) Invalid or Missing Data for Fuel System  
U1132 SCP (J1850) Invalid or Missing Data for Vehicle Motion  
U1133 SCP (J1850) Invalid or Missing Data for Vehicle Motion  
U1134 SCP (J1850) Invalid or Missing Data for Ignition Switch / Starter  
U1135 SCP (J1850) Invalid or Missing Data for Ignition Switch / Starter

U1136 SCP (J1850) Invalid or Missing Data for Telltales  
U1137 SCP (J1850) Invalid or Missing Data for Telltales  
U1138 SCP (J1850) Invalid or Missing Data for Primary Id  
U1139 SCP (J1850) Invalid or Missing Data for Primary Id  
U1140 SCP (J1850) Invalid or Missing Data for Gateway  
U1141 SCP (J1850) Invalid or Missing Data for Gateway  
U1142 SCP (J1850) Invalid or Missing Data for Primary Id  
U1143 SCP (J1850) Invalid or Missing Data for Primary Id  
U1144 SCP (J1850) Invalid or Missing Data for Primary Id  
U1145 SCP (J1850) Invalid or Missing Data for Primary Id  
U1146 SCP (J1850) Invalid or Missing Data for Vehicle Security  
U1147 SCP (J1850) Invalid or Missing Data for Vehicle Security  
U1148 SCP (J1850) Invalid or Missing Data for Audio Control  
U1149 SCP (J1850) Invalid or Missing Data for Audio Control  
U1150 SCP (J1850) Invalid or Missing Data for Audible Warnings  
U1151 SCP (J1850) Invalid or Missing Data for Audible Warnings  
U1152 SCP (J1850) Invalid or Missing Data for Experimental #3  
U1153 SCP (J1850) Invalid or Missing Data for Experimental #3  
U1154 SCP (J1850) Invalid or Missing Data for Compact Disc  
U1155 SCP (J1850) Invalid or Missing Data for Compact Disc  
U1156 SCP (J1850) Invalid or Missing Data for Digital Signal Processing  
U1157 SCP (J1850) Invalid or Missing Data for Digital Signal Processing  
U1158 SCP (J1850) Invalid or Missing Data for Antenna  
U1159 SCP (J1850) Invalid or Missing Data for Antenna  
U1160 SCP (J1850) Invalid or Missing Data for Primary Id  
U1161 SCP (J1850) Invalid or Missing Data for Primary Id  
U1162 SCP (J1850) Invalid or Missing Data for Digital Audio Tape  
U1163 SCP (J1850) Invalid or Missing Data for Digital Audio Tape  
U1164 SCP (J1850) Invalid or Missing Data for Tuner / Receiver  
U1165 SCP (J1850) Invalid or Missing Data for Tuner / Receiver  
U1166 SCP (J1850) Invalid or Missing Data for Cassette Tape  
U1167 SCP (J1850) Invalid or Missing Data for Cassette Tape  
U1168 SCP (J1850) Invalid or Missing Data for Primary Id  
U1169 SCP (J1850) Invalid or Missing Data for Primary Id  
U1170 SCP (J1850) Invalid or Missing Data for Cellular Phone / Paging System  
U1171 SCP (J1850) Invalid or Missing Data for Cellular Phone / Paging System  
U1172 SCP (J1850) Invalid or Missing Data for Remote Button Control  
U1173 SCP (J1850) Invalid or Missing Data for Remote Button Control  
U1174 SCP (J1850) Invalid or Missing Data for Primary Id  
U1175 SCP (J1850) Invalid or Missing Data for Primary Id  
U1176 SCP (J1850) Invalid or Missing Data for Primary Id  
U1177 SCP (J1850) Invalid or Missing Data for Primary Id  
U1178 SCP (J1850) Invalid or Missing Data for Climate Control (HVAC)  
U1179 SCP (J1850) Invalid or Missing Data for Climate Control (HVAC)  
U1180 SCP (J1850) Invalid or Missing Data for Personalization (Memory) Features  
U1181 SCP (J1850) Invalid or Missing Data for Personalization (Memory) Features  
U1182 SCP (J1850) Invalid or Missing Data for Primary Id  
U1183 SCP (J1850) Invalid or Missing Data for Primary Id  
U1184 SCP (J1850) Invalid or Missing Data for Window Wiper / Washer  
U1185 SCP (J1850) Invalid or Missing Data for Window Wiper / Washer  
U1186 SCP (J1850) Invalid or Missing Data for Primary Id  
U1187 SCP (J1850) Invalid or Missing Data for Primary Id  
U1188 SCP (J1850) Invalid or Missing Data for Primary Id  
U1189 SCP (J1850) Invalid or Missing Data for Primary Id  
U1190 SCP (J1850) Invalid or Missing Data for Primary Id  
U1191 SCP (J1850) Invalid or Missing Data for Primary Id  
U1192 SCP (J1850) Invalid or Missing Data for Primary Id  
U1193 SCP (J1850) Invalid or Missing Data for Primary Id  
U1194 SCP (J1850) Invalid or Missing Data for Mirrors  
U1195 SCP (J1850) Invalid or Missing Data for Mirrors

U1196 SCP (J1850) Invalid or Missing Data for Door Locks  
U1197 SCP (J1850) Invalid or Missing Data for Door Locks  
U1198 SCP (J1850) Invalid or Missing Data for External Access (Doors)  
U1199 SCP (J1850) Invalid or Missing Data for External Access (Doors)  
U1200 SCP (J1850) Invalid or Missing Data for Seat Motion / Control  
U1201 SCP (J1850) Invalid or Missing Data for Seat Motion / Control  
U1202 SCP (J1850) Invalid or Missing Data for Windows  
U1203 SCP (J1850) Invalid or Missing Data for Windows  
U1204 SCP (J1850) Invalid or Missing Data for Steering Column  
U1205 SCP (J1850) Invalid or Missing Data for Steering Column  
U1206 SCP (J1850) Invalid or Missing Data for Primary Id  
U1207 SCP (J1850) Invalid or Missing Data for Primary Id  
U1208 SCP (J1850) Invalid or Missing Data for Seat Switches  
U1209 SCP (J1850) Invalid or Missing Data for Seat Switches  
U1210 SCP (J1850) Invalid or Missing Data for Restraints  
U1211 SCP (J1850) Invalid or Missing Data for Restraints  
U1212 SCP (J1850) Invalid or Missing Data for Primary Id  
U1213 SCP (J1850) Invalid or Missing Data for Primary Id  
U1214 SCP (J1850) Invalid or Missing Data for Primary Id  
U1215 SCP (J1850) Invalid or Missing Data for Primary Id  
U1216 SCP (J1850) Invalid or Missing Data for External Lamp Outage  
U1217 SCP (J1850) Invalid or Missing Data for External Lamp Outage  
U1218 SCP (J1850) Invalid or Missing Data for External Lamps  
U1219 SCP (J1850) Invalid or Missing Data for External Lamps  
U1220 SCP (J1850) Invalid or Missing Data for Interior Lamp Outage  
U1221 SCP (J1850) Invalid or Missing Data for Interior Lamp Outage  
U1222 SCP (J1850) Invalid or Missing Data for Interior Lamps  
U1223 SCP (J1850) Invalid or Missing Data for Interior Lamps  
U1224 SCP (J1850) Invalid or Missing Data for Primary Id  
U1225 SCP (J1850) Invalid or Missing Data for Primary Id  
U1226 SCP (J1850) Invalid or Missing Data for Body Status Request  
U1227 SCP (J1850) Invalid or Missing Data for Body Status Request  
U1228 SCP (J1850) Invalid or Missing Data for Tires  
U1229 SCP (J1850) Invalid or Missing Data for Tires  
U1230 SCP (J1850) Invalid or Missing Data for Electric Defrost  
U1231 SCP (J1850) Invalid or Missing Data for Electric Defrost  
U1232 SCP (J1850) Invalid or Missing Data for Navigation  
U1233 SCP (J1850) Invalid or Missing Data for Navigation  
U1234 SCP (J1850) Invalid or Missing Data for Displays  
U1235 SCP (J1850) Invalid or Missing Data for Displays  
U1236 SCP (J1850) Invalid or Missing Data for Memory Storage  
U1237 SCP (J1850) Invalid or Missing Data for Memory Storage  
U1238 SCP (J1850) Invalid or Missing Data for Experimental #4  
U1239 SCP (J1850) Invalid or Missing Data for Experimental #4  
U1240 SCP (J1850) Invalid or Missing Data for Primary Id  
U1241 SCP (J1850) Invalid or Missing Data for Primary Id  
U1242 SCP (J1850) Invalid or Missing Data for Exterior Environment  
U1243 SCP (J1850) Invalid or Missing Data for Exterior Environment  
U1244 SCP (J1850) Invalid or Missing Data for Interior Environment  
U1245 SCP (J1850) Invalid or Missing Data for Interior Environment  
U1246 SCP (J1850) Invalid or Missing Data for Primary Id  
U1247 SCP (J1850) Invalid or Missing Data for Primary Id  
U1248 SCP (J1850) Invalid or Missing Data for Time / Date  
U1249 SCP (J1850) Invalid or Missing Data for Time / Date  
U1250 SCP (J1850) Invalid or Missing Data for Vehicle Id (VIN)  
U1251 SCP (J1850) Invalid or Missing Data for Vehicle Id (VIN)  
U1252 SCP (J1850) Invalid or Missing Data for Class A Functions  
U1253 SCP (J1850) Invalid or Missing Data for Class A Functions  
U1254 SCP (J1850) Invalid or Missing Data for Network Control  
U1255 SCP (J1850) Invalid or Missing Data for Network Control

U1260 SCP (J1850) Single Ended (+) Circuit Failure  
U1261 SCP (J1850) Single Ended (-) Circuit Failure  
U1262 SCP (J1850) Communication Bus Fault  
U1308 SCP (J1850) Invalid or Missing Data for Function Read Engine Torque  
U1341 SCP (J1850) Invalid or Missing Data for Function Read Vehicle Speed  
U1430 SCP (J1850) Invalid or Missing Data for Function Read Fuel System  
U1451 SCP (J1850) Invalid or Missing Data for Function Read Audible Warnings / Anti-Theft Module, Vehicle Immobilized  
U1612 SCP (J1850) Lack of Acknowledgment for Primary Id  
U1736 SCP (J1850) Lack of Acknowledgment for Telltales  
U1750 SCP (J1850) Lack of Acknowledgment for Audible Warnings  
U1794 SCP (J1850) Lack of Acknowledgment for Mirrors  
U1797 SCP (J1850) Lack of Acknowledgment for Door Locks  
U1798 SCP (J1850) Lack of Acknowledgment for External Access (Doors)  
U1806 SCP (J1850) Lack of Acknowledgment for Primary Id  
U1900 CAN Communication Bus Fault  
U1950 UPB Communication Bus Fault  
U2000 Audio Rear Control Unit is Not Responding  
U2001 Audio Tape Deck Unit is Not Responding  
U2002 Audio Bezel is Not Responding  
U2003 Audio Compact Disk / Disk Jockey Unit is Not Responding  
U2004 Audio Steering Wheel Control Unit is Not Responding  
U2005 Audio Rear Integrated Control Panel Unit is Not Responding  
U2006 Audio Remote Climate Control Unit is Not Responding  
U2007 Audio Navigation Unit is Not Responding  
U2008 Audio Phone is Not Responding  
U2009 Audio Front Control Module (ACM) is Not Responding  
U2010 Module is Not Responding (Non SCP)  
U2011 Module Transmitted Invalid Data (Non SCP)  
U2012 Communication Bus Error (Non SCP)  
U2013 Compass Module is not Responding  
U2014 Audio Subwoofer Unit is Not Responding  
U2015 Signal Link Fault (Non SCP)  
U2016 Signal Link Short to Ground (Non SCP) / From NGV Module  
U2017 Driver Side Crash Sensor Communication Fault (Non SCP)  
U2018 Passenger Side Crash Sensor Communication Fault (Non SCP)  
U2019 Audio Voice Module Not Responding  
U2020 Audio Center Amp is not responding  
U2021 Invalid /fault data received (Non SCP)  
U2150 SCP (J1850) Invalid Data from REM  
U2152 SCP (J1850) Invalid Data from GEM  
U2160 SCP (J1850) Invalid Data from IC  
U2195 SCP (J1850) Invalid Data from SCLM  
U2500 (CAN) Lack of Acknowledgement From Engine Management